

06-08-202

Uniserv Aviation, Inc.

Rev#: 20

Capability List

<u>PART NUMBER:</u>	<u>MODEL/TYPE:</u>	<u>DESCRIPTION:</u>	<u>MANUFACTURER:</u>	<u>Rev#</u>
010-005-023	010-005-023	LIQUID QUANTITY TRANSMITTER	GULL AIRBORNE INST.	
011100-1	NO MODEL#	POSITION LIGHT	BFGOODRICH	
011100-2	NO MODEL #	POSITION LIGHT	GOODRICH	
031100-1	NO MODEL#	ANTI-COLLISION LIGHT	GOODRICH	
034000-1	NO MODEL #	ANTI-COLLISION	GOODRICH	
034000-2	NO MDEL#	ANTI-COLLISION	GOODRICH	
03640-3	03640-3	BALLAST-CEILING	BRUCE INDUSTRIES	
03640-5	03640	BALLAST CEILING	BRUCE	
10-0067-7	10-0067-7	EMERGENCY EXIT LIGHT **	HONEYWELL GRIMES	
10-0067-9	10-0067-9	EMERGENCY EXIT LIGHT **	HONEYWELL GRIMES	
10-0119-1	NO MODEL #	L-T EMERGENCY	HONEYWELL	
10031-0000-01	10-60722-8	ENG.OIL QTY INDICATOR	BF GOODRICH	
10037-1000-0101	10037-1000-0101	FUEL QUANTITY INDICATOR **8	BF GOODRICH	
10037-1000-0102	10037-1000-0102	FUEL QUANTITY INDICATOR **	BF GOODRICH	
10037-1000-0103	10037-1000-0103	FUEL QUANTITY INDICATOR **	BF GOODRICH	
10037-1000-0104	10037-1000-0104	FUEL QUANTITY INDICATOR **	BF GOODRICH	
10037-1000-0105	10037-1000-0105	FUEL QUANTITY INDICATOR **	BF GOODRICH	
10037-1000-0106	10037-1000-0106	FUEL QUANTITY INDICATOR **	BF GOODRICH	
10037-1000-0107	10037-1000-0107	FUEL QUANTITY INDICATOR **	BF GOODRICH	
10037-1000-0108	10037-1000-0108	FUEL QUANTITY INDICATOR **	BF GOODRICH	
10037-1000-0109	10037-1000-0109	FUEL QUANTITY INDICATOR **	BF GOODRICH	
10037-1000-0110	10037-1000-0110	FUEL QUANTITY INDICATOR **	BF GOODRICH	
10037-1000-0111	10037-1000-0111	FUEL QUANTITY INDICATOR **	BF GOODRICH	
100-384048-1	SR-2AH	TORQUE PRESSURE INDICATOR >>	AMETEK	
100-384048-15	SR-2AT	TORQUE PRESSURE INDICATOR >>	AMETEK	
100-384048-3	SR-2AJ	TORQUE PRESSURE INDICATOR >>	AMETEK	
100-384048-5	SR-2AK	TORQUE PRESSURE INDICATOR >>	AMETEK	
100-384116-5	SR-2AR	TORQUE PRESSURE INDICATOR >>	AMETEK	
10066-0000-01	10-60722-14	LIQUID QUANTITY INDICATOR >>>	BF GOODRICH	
10-1327-1	NO MODEL#	LIGHT ASSY	HONEYWELL	
10-1327-2	NO MODEL #	LIGHT ASSY	HONEYWELL	
101-384008-3	SR-2AM	TORQUE PRESSURE INDICATOR >>	AMETEK	
10176N01R00	8SC0327	RPM INDICATOR	AMETEK	
10176N02R00	8SC0327	RPM INDICATOR	AMETEK	
102-00074	NO MODEL #	ICE PROTECTION LOW	NORWICH AERO	
102-00075	NO MODEL#	ICE PROTECTION HIGHT	NORWICH AERO	
102-0041-04	RCA22-7	GYRO HORIZON	A.I.D./R.C. ALLEN	
102076-1-5	OVC3-261-3	CONTROL OUTFLOW VALVE	AIRSEARCH	
102076-3	OVC3-26	CONTROL OUTFLOW VALVE	AIRSEARCH	
102076-5	OVC3-26	CONTROL OUTFLOW VALVE	AIRSEARCH	
102076-5-	OVC3-26	CONTROL OUTFLOW VALVE	AIRSEARCH	
102088-4-1	102088-4-1	CABIN AIR PRESSURE OUTFLOW VALVE CONTROLS	GARRET	
102088-5-1	102088-5-1	CABIN AIR PRESSURE OUTFLOW VALVE CONTROLS	GARRET	
1021-1	NO MODEL #	FREQ. CONVERTER	OLIN	
102212-11		CABIN PRESSURE CONTROL >>	HONEYWELL	
102212-12		CABIN PRESSURE CONTROL >>	HONEYWELL	
102212-13-1	102212-13-1	CABIN PRESSURE CONTROL >>	HONEYWELL	
102212-14-1		CABIN PRESSURE CONTROL >>	HONEYWELL	
102212-17		CABIN PRESSURE CONTROL >>	HONEYWELL	
102212-18		CABIN PRESSURE CONTROL >>	HONEYWELL	

06-08-202

Uniserv Aviation, Inc.

Rev#: 20

Capability List

<u>PART NUMBER:</u>	<u>MODEL/TYPE:</u>	<u>DESCRIPTION:</u>	<u>MANUFACTURER:</u>	<u>Rev#</u>
102212-19		CABIN PRESSURE CONTROL >>	HONEYWELL	
102212-20		CABIN PRESSURE CONTROL >>	HONEYWELL	
102212-21		CABIN PRESSURE CONTROL >>	HOHEYWELL	
102212-22		CABIN PRESSURE CONTROL >>	HONEYWELL	
102212-23		CABIN PRESSURE CONTROL >>	HONEYWELL	
102212-24		CABIN PRESSURE CONTROL >>	HONEYWELL	
102212-25		CABIN PRESSURE CONTROL >>	HONEYWELL	
102212-26		CABIN PRESSURE CONTROL >>	HONEYWELL	
10228506203		ELECTRONICS MODULE >>	KOLLSMAN	
102384-1	102384-1	CABIN AIR PRESSURE OUTFLOW VALVE CONTROLS	GARRET	
102384-2	102384-2	CABIN AIR PRESSURE OUTFLOW VALVE CONTROLS	GARRET	
102464		OUTFLOW VALVE CONTROL	HONEYWELL	
102538-2-1	NO MODEL#	CONTROL OUTFLOW VALVE	ALLIEDSIGNAL	
102538-3-1		CABIN AIR PRESSURE	GARRETT	
102538-5-1		CABIN AIR PRESSURE	ALLIEDSIGNAL	
102568-3-2		CONTROL AIR PRESS	HONEYWELL	
102568-5-1	102568-5-1	CONTROLLER AIR PRESS	HONEYWELL	
102568-5-2		CABIN PRESSURE CONTROLLER	HONEYWELL	
102568-6-1		CABIN AIR PRESSURE CONTROLER	HONEYWEEL	
102568-7-1		CABIN AIR PRESSURE CONTROLER	HONEYWELL	
10-353875-1	483551	IGNITION EXCITER	UNISON	
10-353875-4	571219	IGNITION EXCITER	UNISON	
103598-12	103598-12	CABIN PRESSURE CONTROL	GARRET	
10-378400-3		IGNITION EXCITER	UNISON	
10-378400-5		IGNITION EXCITER	UNISON	
10-381175-1	899580-2	IGNITION EXCITER	UNISON	
10-381175-3	3603281-3	EXCITER IGNITION	UNISON	
10-381175-6	3603281-3	IGNITION EXCITER	UNISON	
10-381175-9	3603281-7	IGNITION EXCITER	UNISON	
10-381200-11	3603281-5	IGNITION EXCITER	UNISON	
10-381550-1C		IGNITION EXCITER	UNISON	
10-381750-1	899580-1	IGNITION EXCITER	UNISON	
10-381750-14	3603281-6	IGNITION EXCITER	UNISON	
10-381750-2		IGNITION EXCITER	UNISON	
10-381750-6	3603281-2	IGNITION EXCITER	UNISON	
104-384009	521673	INDICATOR TEMP TURBINE	BEECH AIRCRAFT CO	
104-384010-3	6501-1029	SINGLE TACHOMETER INDICATOR	INSCO	
104-384012-5	SR-C-2AS	TORQUE PRESSURE INDICATOR >>	AMETEK	
104-384019	T34C	INDICATOR VERTICAL SPEED	BEECH AIRCRAFT CO	
104-384019-1	T34C	INDICATOR VERTICAL SPEED	BEECH AIRCRAFT	
104-384059-1	9036-1018	OIL TEMPERATURE/PRESSURE	INSCO	
10458N03F01		FUEL FLOW IND	AMETEK	
10-60091-101		EMERGENCY EXIT LIGHT **	HONEYWELL GRIMES	
10-60091-102		EMERGENCY EXIT LIGHT **	HONEYWELL GRIMES	
10-60722-14	10066-0000-01	LIQUID QUANTITY INDICATOR >>	BF GOODRICH	
10-60722-5	393020-01789	LIQUID QUANTITY INDICATOR >>	BF GOODRICH	
10-60722-6	393020-003	LIQUID QUANTITY INDICATOR >>	BF GOODRICH	
10-60722-7	393020-012	LIQUID QUANTITY INDICATOR >>	BF GOODRICH	
10-60737-14	2045-06-1	EPR INDICATOR >>	SMITHS INDUSTRIES	
10-60737-16	2045-08-1	EPR INDICATOR >>	SMITHS INDUSTRIES	

06-08-202

Uniserv Aviation, Inc.

Rev#: 20

Capability List

<u>PART NUMBER:</u>	<u>MODEL/TYPE:</u>	<u>DESCRIPTION:</u>	<u>MANUFACTURER:</u>	<u>Rev#</u>
10-60775-6	253884	SURFACE POSITION INDICATOR >>	AMETEK	
10-60791-10	10-60791-10	FLAP POSITION INDICATOR	COURTER	
10-60791-11	18-1299-4, -4-2	FLAP POSITION INDICATOR >>	HONEYWELL	
10-60791-12	18-1299-5, -5-2	FLAP POSITION INDICATOR >>	HONEYWELL	
10-60791-13	18-1299-6, -6-2	FLAP POSITION INDICATOR >>	HONEYWELL	
10-60791-2	18-1299	FLAP POSITION INDICATOR >>	HONEYWELL	
10-60791-4	18-1299-2	FLAP POSITION INDICATOR >>	HONEYWELL	
10-60791-6	18-1299-3, -3-2, -7-2	FLAP POSITION INDICATOR >>	HONEYWELL	
10-60791-8	10-60791-8	FLAP POSITION INDICATOR	COURTER	
10-60791-9	10-60791-9	FLAP POSITION INDICATOR	COURTER	
10-61219-111	2300-01-1	FUEL QUANTITY INDICATOR >>	SMITHS INDUSTRIES	
10-61219-2	393026-01840	FUEL QUANTITY INDICATOR >>	BF GOODRICH	
10-61219-3	393026-01837	FUEL QUANTITY INDICATOR >>	BF GOODRICH	
10-61219-31	393026-001	FUEL QUANTITY INDICATOR >>	BF GOODRICH	
10-61219-32	393026-01880	FUEL QUANTITY INDICATOR >>	BF GOODRICH	
10-61219-4	393026-01841	FUEL QUANTITY INDICATOR >>	BF GOODRICH	
10-61219-5	393026-01838	FUEL QUANTITY INDICATOR >>	BF GOODRICH	
10-614500-1	780524	IGNITION EXCITER	UNISON	
10-617075-6	3888058-5	IGNITION EXCITER	UNISON	
10-61818-151	2083-08-1	MACH AIRSPEED INDICADOR >>	SMITHS INDUSTRIES	
10-61818-161	2083-09-1	MACH AIRSPEED INDICATOR >>	SMITHS INDUSTRIES	
10-61818-171	2083-10-1	MACH AIRSPEED INDICATOR >>	SMITHS INDUSTRIES	
10-61818-18	2083-11-1	MACH AIRSPEED INDICATOR >>	SMITHS INDUSTRIES	
10-61926-1	2061-11-1	FLAP POSITION INDICATOR >>	SMITHS INDUSTRIES	
10-61926-2	2061-12-1	FLAP POSITION INDICATOR >>	SMITHS INDUSTRIES	
10-61926-3	2061-13-1	FLAP POSITION INDICATOR >>	SMITHS INDUSTRIES	
10-61926-4	2061-14-1	FLAP POSITION INDICATOR >>	SMITHS INDUSTRIES	
11-0049	11-0049	CHARGER ASSY BATTERY	RADIANT POWER CO	
11-0283-2		EMERGENCY EXIT LIGHT >>	HONEYWELL GRIMES	
11-0283-3		EMERGENCY EXIT LIGHT >>	HONEYWELL GRIMES	
11-0283-5		EMERGENCY EXIT LIGHT >>	HONEYWELL GRIMES	
11-0283-6		EMERGENCY EXIT LIGHT >>	HONEYWELL GRIMES	
11-0283-7		EMERGENCY EXIT LIGHT >>	HONEYWELL GRIMES	
1103P0281	NO MODEL#	SWITCH PRESSURE	ITT	
1140-0110-331	NO MODEL#	FLEXI-STICK	ROCWELL COLLINS	
1145-1	60B40025-35	BALLAST	AVTECH CORPORTATI	
1173T15		SWITCH TEMPERATURE		
1173T15-	NO MODEL#	SWITCH TEMPERATURE	ITT	
1173T15-1	NO MODEL#	SWITCH TEMPERATURE	ITT	
1173T19-1	NO MODEL #	SWITCH TEMP	ITT	
1173TO691	NO MODEL#	SWITCH ASSY	ITT	
119001-01-	7002C	DISPLACEMENT GYROSCOPE	LEAR SIEGLER	
119001-01-45	7002C	DISPLACEMENT GYROSCOPE	LEAR SIEGLER	
119001-01-46	7002C	DISPLACEMENT GYROSCOPE	LEAR SIEGLER	
121672-01-15	7000B	DISPLACEMENT GYROSCOPE	LEAR SIEGLER	
121672-01-17	7000B	DISPLACEMENT GYROSCOPE	LEAR SIEGLER	
1225P6	1225P6	PRESSURE SWITCH	ITT AEROSPACE CON	
1225P6-1	1225P6	PRESSURE SWITCH	ITT AEROSPACE	
1225P6-2	1225P6-2	PRESSURE SWITCH	ITT AEROSPACE CON	
124.043		DUAL TEMP.AND PRESSURE IND	KRATOS	
124.514-1	NO MODEL#	EGT. INDICATOR	ROGERSON KRATOS	

06-08-202

Uniserv Aviation, Inc.

Rev#: 20

Capability List

<u>PART NUMBER:</u>	<u>MODEL/TYPE:</u>	<u>DESCRIPTION:</u>	<u>MANUFACTURER:</u>	<u>Rev#</u>
124.514-6	NO MODEL #	EGT INDICATOR	ROGERSON KRATOS	
124.835	10-60757-25	FRECUENCY METER INDICATOE	ROGER AIRCRAFT CO	
124.838	10-60757-28	TEMPERATURE INDICATOR	ROGERSON AIRCRAF	
124-514-6	NO MODEL #	INDICATOR EGT	ROGERSON KRATOS	
124623-01-09	700E	DISPLACEMENT GYROSCOPE	LEAR SIEGLER	
124623-01-10	7000E	DISPLACEMENT GYROSCOPE	LEAR SIEGLER	
124623-01-13	7000E	DISPLACEMENT GYROSCOPE	LEAR SIEGLER	
124623-01-14	7000E	DISPLACEMENT GYROSCOPE	LEAR SIEGLER	
12672-01-15	7000B	DISPLACEMENT GYROSCOPE	LEAR SIEGLER	
130346-7	130346-7	CABIN PRESSURE CONTROL	GARRET	
131008-3	131008-3	CONTROL OUT FLOW VALVE	AIRSEARCH	
132637-01	7002E	DISPLACEMENT GYROSCOPE	LEAR SIEGLER	
14613-1AKA4	NO MODEL#	INDICATOR ATTITUDE	AVSCOM	
14613-1AK-A4	NO MODEL#	GYRO HORIZON	AVCOM	
147BDL21		ELECTRIC RESISTANCE THERMOMETER >>	HORIZON AEROSPAC	
147D2		ELECTRICAL RESISTANCE THERMOMETER	LEWIS	
1497672-002		PRESSURE TRANSMITER	BENDIX	
152BCL4		THERMOMETER EXHAUST >>	HORIZON AEROSPAC	
152BCL4A		THERMOMETER EXHAUST >>	HORIZON AEROSPAC	
152BCL4B		THERMOMETER EXHAUST >>	HORIZON AEROSPAC	
152BCL4C		THERMOMETER EXHAUST >>	HORIZON AEROSPAC	
152BCL4D		THERMOMETER EXHAUST >>	HORIZON AEROSPAC	
152BCL4F		THERMOMETER EXHAUST >>	HORIZON AEROSPAC	
152BCL4G		THERMOMETER EXHAUST >>	HORIZON AEROSPAC	
152BCL4G2		THERMOMETER EXHAUST >>	HORIZON AEROSPAC	
152BCL4H		THERMOMETER EXHAUST >>	HORIZON AEROSPAC	
152BCL4J		THERMOMETER EXHAUST >>	HORIZON AEROSPAC	
152BCL4J2		THERMOMETER EXHAUST >>	HORIZON AEROSPAC	
152BCL4J3		THERMOMETER EXHAUST >>	HORIZON AEROSPAC	
152BCL4P		THERMOMETER EXHAUST >>	HORIZON AEROSPAC	
152BCL4R		THERMOMETER EXHAUST >>	HORIZON AEROSPAC	
152BCL4S		THERMOMETER EXHAUST >>	HORIZON AEROSPAC	
152BCL4W		THERMOMETER EXHAUST >>	HORIZON AEROSPAC	
152BCL4W2		THERMOMETER EXHAUST >>	HORIZON AEROSPAC	
152BL702		TEMPERATURE INDICATOR >>	HORIZON AEROSPAC	
152BL702A		TEMPERATURE INDICATOR >>	HORIZON AEROSPAC	
152BL702C		TEMPERATURE INDICATOR >>	HORIZON AEROSPAC	
152BL702D		TEMPERATURE INDICATOR >>	HORIZON AEROSPAC	
152BL702E		TEMPERATURE INDICATOR >>	HORIZON AEROSPAC	
152BL703		TEMPERATURE INDICATOR >>	HORIZON AEROSPAC	
152BL704		TEMPERATURE INDICATOR >>	HORIZON AEROSPAC	
152BL705A		EGT. INDICATOR	LEWIS	
152BL705N		EGT INDICATOR	LEWIS	
152BL706		TEMPERATURE INDICATOR >>	HORIZON AEROSPAC	
152BL708		TEMPERATURE INDICATOR >>	HORIZON AEROSPAC	
152BL708A		TEMPERATURE INDICATOR >>	HORIZON AEROSPAC	
152BL708B		TEMPERATURE INDICATOR >>	HORIZON AEROSPAC	
152BL708H		TEMPERATURE INDICATOR >>	HORIZON AEROSPAC	
152BL709		TEMPERATURE INDICATOR >>	HORIZON AEROSPAC	
152BL709A	152BL709A	TEMPERATURE INDICATOR >>	HORIZON AEROSPAC	
152BL722	152BL722	TEMPERATURE INDICATOR >>	HORIZON AEROSPAC	

Rev#: 20

Capability List

<u>PART NUMBER:</u>	<u>MODEL/TYPE:</u>	<u>DESCRIPTION:</u>	<u>MANUFACTURER:</u>	<u>Rev#</u>
152BL801		TEMPERATURE INDICATOR >>	HORIZON AEROSPAC	
152BL801A		TEMPERATURE INDICATOR >>	HORIZON AEROSPAC	
152BL801B		TEMPERATURE INDICATOR >>	HORIZON AEROSPAC	
152BL801C	152BL801C	TEMPERATURE INDICATOR >>	HORIZON AEROSPAC	
152BL801D		TEMPERATURE INDICATOR >>	HORIZON AEROSPAC	
152BL801E		TEMPERATURE INDICATOR >>	HORIZON AEROSPAC	
152BL802A		TEMPERATURE INDICATOR >>	HORIZON AEROSPAC	
152BL802B	152BL802B	TEMPERATURE INDICATOR >>	HORIZON AEROSPAC	
152BL802C		TEMPERATURE INDICATOR >>	HORIZON AEROSPAC	
152BL802D		TEMPERATURE INDICATOR >>	HORIZON AEROSPAC	
152BL803		TEMPERATURE INDICATOR >>	HORIZON AEROSPAC	
152BL803A		TEMPERATURE INDICATOR >>	HORIZON AEROSPAC	
152BL803B		TEMPERATURE INDICATOR >>	HORIZON AEROSPAC	
152BL803C		TEMPERATURE INDICATOR >>	HORIZON AEROSPAC	
152C4		THERMOCOUPLE THERMOMETER >>	HORIZON AEROSPAC	
152C40A		THERMOCOUPLE THERMOMETER >>	HORIZON AEROSPAC	
152C40A2		THERMOCOUPLE THERMOMETER >>	HORIZON AEROSPAC	
152C4A		THERMOCOUPLE THERMOMETER >>	HORIZON AEROSPAC	
152C4B		THERMOCOUPLE THERMOMETER >>	HORIZON AEROSPAC	
154909	8047/10	2 INCH COUNTER-POINTER ALTIMETER	AERO MECHANISM	
15810-1	15810	DIRECTIONAL GYRO	KEARFOTT DIVISS	
15831-1-A	15831-1-A	THREE- AXIS RATE CONT	HONEYWELL BENDIX	
15831-2-A	15831-2-A	THREE- AXIS RATE CONT	HONEYWELL BENDIX	
15831-2-B	15831-2-B	THREE- AXIS RATE CONT	HONEYWELL BENDIX	
15837-2-C	15837-2-C	VERTICAL GYRO	HONEYWELL BENDIX	
15843-1-C	15843-1-C	VERTICAL GYRO	HONEYWELL BENDIX	
15866-1A	15866-1A	VERTICAL GYRO	HONEYWELL BENDIX	
15866-1B	15866-1B	VERTICAL GYRO	HONEYWELL BENDIX	
15866-1C	15866-1C	VERTICAL GYRO	HONEYWELL BENDIX	
15866-1D	15866-1D	VERTICAL GYRO	HONEYWELL BENDIX	
15866-2C	15866-2C	VERTICAL GYRO	HONEYWELL BENDIX	
15866-2D	15866-2D	VERTICAL GYRO	HONEYWELL BENDIX	
15866-2E	15866-2E	VERTICAL GYRO	HONEYWELL BENDIX	
15866-3A	15866-3A	VERTICAL GYRO	HONEYWELL BENDIX	
15866-3C	15866-3C	VERTICAL GYRO	HONEYWELL BENDIX	
15897-1A	15897-1A	VERTICAL GYRO	HONEYWELL BENDIX	
15897-1C	15897-1C	VERTICAL GYRO	HONEYWELL BENDIX	
15897-1D	15897-1D	VERTICAL GYRO	HONEYWELL BENDIX	
15897-2D	15897-2D	VERTICAL GYRO	HONEYWELL BENDIX	
15897-5A	15897-5A	VERTICAL GYRO	HONEYWELL BENDIX	
1611AM1		ALTIMETER	SMITHS	
161B101		ELECTRIC RESISTANCE THERMOMETER >>	HORIZON AEROSPAC	
161BCL2		ELECTRIC RESISTANCE THERMOMETER >>	HORIZON AEROSPAC	
161BL302		ELECTRIC RESISTANCE THERMOMETER >>	HORIZON AEROSPAC	
161BL501		ELECTRIC RESISTANCE THERMOMETER >>	HORIZON AEROSPAC	
161C20B		ELECTRIC RESISTANCE THERMOMETER >>	HORIZON AEROSPAC	
161C3		ELECTRIC RESISTANCE THERMOMETER >>	HORIZON AEROSPAC	
161C9		ELECTRIC RESISTANCE THERMOMETER >>	HORIZON AEROSPAC	
162B101		ELECTRIC RESISTANCE THERMOMETER >>	HORIZON AEROSPAC	
162B2		INDICATOR TEMPERATURE	NAVAIR	
162B2G		INDICATOR TEMPERATURE	NAVAIR	

06-08-202

Uniserv Aviation, Inc.

Rev#: 20

Capability List

<u>PART NUMBER:</u>	<u>MODEL/TYPE:</u>	<u>DESCRIPTION:</u>	<u>MANUFACTURER:</u>	<u>Rev#</u>
162BCL10		ELECTRIC RESISTANCE THERMOMETER >>	HORIZON AEROSPAC	
162BCL10F		ELECTRIC RESISTANCE THERMOMETER >>	HORIZON AEROSPAC	
162BCL10W		ELECTRIC RESISTANCE THERMOMETER >>	HORIZON AEROSPAC	
162BCL10WC		ELECTRIC RESISTANCE THERMOMETER >>	HORIZON AEROSPAC	
162BCL11		ELECTRIC RESISTANCE THERMOMETER >>	HORIZON AEROSPAC	
162BCL11A		ELECTRIC RESISTANCE THERMOMETER >>	HORIZON AEROSPAC	
162BCL11W		ELECTRIC RESISTANCE THERMOMETER >>	HORIZON AEROSPAC	
162BCL12		ELECTRIC RESISTANCE THERMOMETER >>	HORIZON AEROSPAC	
162BCL12W		ELECTRIC RESISTANCE THERMOMETER >>	HORIZON AEROSPAC	
162BCL15		ELECTRIC RESISTANCE THERMOMETER >>	HORIZON AEROSPAC	
162BCL15W		ELECTRIC RESISTANCE THERMOMETER >>	HORIZON AEROSPAC	
162BCL16		ELECTRIC RESISTANCE THERMOMETER >>	HORIZON AEROSPAC	
162BCL16A		ELECTRIC RESISTANCE THERMOMETER >>	HORIZON AEROSPAC	
162BCL16B		ELECTRIC RESISTANCE THERMOMETER >>	HORIZON AEROSPAC	
162BCL16W		ELECTRIC RESISTANCE THERMOMETER >>	HORIZON AEROSPAC	
162BCL16WC		ELECTRIC RESISTANCE THERMOMETER >>	HORIZON AEROSPAC	
162BCL17		ELECTRIC RESISTANCE THERMOMETER >>	HORIZON AEROSPAC	
162BCL17W		ELECTRIC RESISTANCE THERMOMETER >>	HORIZON AEROSPAC	
162BCL19		ELECTRIC RESISTANCE THERMOMETER >>	HORIZON AEROSPAC	
162BCL20		ELECTRIC RESISTANCE THERMOMETER >>	HORIZON AEROSPAC	
162BCL20A		ELECTRIC RESISTANCE THERMOMETER >>	HORIZON AEROSPAC	
162BCL20B		ELECTRIC RESISTANCE THERMOMETER >>	HORIZON AEROSPAC	
162BCL20C		ELECTRIC RESISTANCE THERMOMETER >>	HORIZON AEROSPAC	
162BCL21		ELECTRIC RESISTANCE THERMOMETER >>	HORIZON AEROSPAC	
162BCL22		ELECTRIC RESISTANCE THERMOMETER >>	HORIZON AEROSPAC	
162BCL23		ELECTRIC RESISTANCE THERMOMETER >>	HORIZON AEROSPAC	
162BCL27		ELECTRIC RESISTANCE THERMOMETER >>	HORIZON AEROSPAC	
162BCL33		ELECTRIC RESISTANCE THERMOMETER >>	HORIZON AEROSPAC	
162BCL33W		ELECTRIC RESISTANCE THERMOMETER >>	HORIZON AEROSPAC	
162BCL81		ELECTRIC RESISTANCE THERMOMETER >>	HORIZON AEROSPAC	
162BCL81W		ELECTRIC RESISTANCE THERMOMETER >>	HORIZON AEROSPAC	
162BCL82W		ELECTRIC RESISTANCE THERMOMETER >>	HORIZON AEROSPAC	
162BL402		ELECTRIC RESISTANCE THERMOMETER >>	HORIZON AEROSPAC	
162BL402A		ELECTRIC RESISTANCE THERMOMETER >>	HORIZON AEROSPAC	
162BL403		ELECTRIC RESISTANCE THERMOMETER >>	HORIZON AEROSPAC	
162BL403A		ELECTRIC RESISTANCE THERMOMETER >>	HORIZON AEROSPAC	
162BL403B		ELECTRIC RESISTANCE THERMOMETER >>	HORIZON AEROSPAC	
162BL403C		ELECTRIC RESISTANCE THERMOMETER >>	HORIZON AEROSPAC	
162BL501		ELECTRIC RESISTANCE THERMOMETER >>	HORIZON AEROSPAC	
162BL502		ELECTRIC RESISTANCE THERMOMETER >>	HORIZON AEROSPAC	
162BL503		ELECTRIC RESISTANCE THERMOMETER >>	HORIZON AEROSPAC	
162BL504		ELECTRIC RESISTANCE THERMOMETER >>	HORIZON AEROSPAC	
162BL505		ELECTRIC RESISTANCE THERMOMETER >>	HORIZON AEROSPAC	
162BL602		ELECTRIC RESISTANCE THERMOMETER >>	HORIZON AEROSPAC	
162BL701		ELECTRIC RESISTANCE THERMOMETER >>	HORIZON AEROSPAC	
162BL701A		ELECTRIC RESISTANCE THERMOMETER >>	HORIZON AEROSPAC	
162BL702		ELECTRIC RESISTANCE THERMOMETER >>	HORIZON AEROSPAC	
162BL703		ELECTRIC RESISTANCE THERMOMETER >>	HORIZON AEROSPAC	
162BL704		ELECTRIC RESISTANCE THERMOMETER >>	HORIZON AEROSPAC	
162BL704A		ELECTRIC RESISTANCE THERMOMETER >>	HORIZON AEROSPAC	
162BL704C		ELECTRIC RESISTANCE THERMOMETER >>	HORIZON AEROSPAC	

06-08-202

Uniserv Aviation, Inc.

Rev#: 20

Capability List

<u>PART NUMBER:</u>	<u>MODEL/TYPE:</u>	<u>DESCRIPTION:</u>	<u>MANUFACTURER:</u>	<u>Rev#</u>
162BL704D		ELECTRIC RESISTANCE THERMOMETER >>	HORIZON AEROSPAC	
162BL704F		ELECTRIC RESISTANCE THERMOMETER >>	HORIZON AEROSPAC	
162BL704H		ELECTRIC RESISTANCE THERMOMETER >>	HORIZON AEROSPAC	
162BL704K		ELECTRIC RESISTANCE THERMOMETER >>	HORIZON AEROSPAC	
162BL704L		ELECTRIC RESISTANCE THERMOMETER >>	HORIZON AEROSPAC	
162BL704N		ELECTRIC RESISTANCE THERMOMETER >>	HORIZON AEROSPAC	
162BL708		ELECTRIC RESISTANCE THERMOMETER >>	HORIZON AEROSPAC	
162BL709		ELECTRIC RESISTANCE THERMOMETER >>	HORIZON AEROSPAC	
162BL709A		ELECTRIC RESISTANCE THERMOMETER >>	HORIZON AEROSPAC	
162BL709B		ELECTRIC RESISTANCE THERMOMETER >>	HORIZON AEROSPAC	
162BL709C		ELECTRIC RESISTANCE THERMOMETER >>	HORIZON AEROSPAC	
162BL710		ELECTRIC RESISTANCE THERMOMETER >>	HORIZON AEROSPAC	
162BL711		ELECTRIC RESISTANCE THERMOMETER >>	HORIZON AEROSPAC	
162BL801		ELECTRIC RESISTANCE THERMOMETER >>	HORIZON AEROSPAC	
162BL802		ELECTRIC RESISTANCE THERMOMETER >>	HORIZON AEROSPAC	
162BL802A		ELECTRIC RESISTANCE THERMOMETER >>	HORIZON AEROSPAC	
162BL803		ELECTRIC RESISTANCE THERMOMETER >>	HORIZON AEROSPAC	
162BL803A		ELECTRIC RESISTANCE THERMOMETER >>	HORIZON AEROSPAC	
162BL804A		ELECTRIC RESISTANCE THERMOMETER >>	HORIZON AEROSPAC	
162BL901		ELECTRIC RESISTANCE THERMOMETER >>	HORIZON AEROSPAC	
162BL902		ELECTRIC RESISTANCE THERMOMETER >>	HORIZON AEROSPAC	
162BL903		ELECTRIC RESISTANCE THERMOMETER >>	HORIZON AEROSPAC	
162BL906		ELECTRIC RESISTANCE THERMOMETER >>	HORIZON AEROSPAC	
162BL907		ELECTRIC RESISTANCE THERMOMETER >>	HORIZON AEROSPAC	
162C16		ELECTRIC RESISTANCE THERMOMETER >>	HORIZON AEROSPAC	
162C17		ELECTRIC RESISTANCE THERMOMETER >>	HORIZON AEROSPAC	
162C18		ELECTRIC RESISTANCE THERMOMETER >>	HORIZON AEROSPAC	
162C21		ELECTRIC RESISTANCE THERMOMETER >>	HORIZON AEROSPAC	
162C22		ELECTRIC RESISTANCE THERMOMETER >>	HORIZON AEROSPAC	
162C23		ELECTRIC RESISTANCE THERMOMETER >>	HORIZON AEROSPAC	
162C23B		ELECTRIC RESISTANCE THERMOMETER >>	HORIZON AEROSPAC	
162C25		ELECTRIC RESISTANCE THERMOMETER >>	HORIZON AEROSPAC	
162C26		ELECTRIC RESISTANCE THERMOMETER >>	HORIZON AEROSPAC	
162C27		ELECTRIC RESISTANCE THERMOMETER >>	HORIZON AEROSPAC	
162C28		ELECTRIC RESISTANCE THERMOMETER >>	HORIZON AEROSPAC	
162C30		ELECTRIC RESISTANCE THERMOMETER >>	HORIZON AEROSPAC	
162C31		ELECTRIC RESISTANCE THERMOMETER >>	HORIZON AEROSPAC	
162C7		ELECTRIC RESISTANCE THERMOMETER >>	HORIZON AEROSPAC	
162C7A		TEMPERATURE INDICATOR	HORIZON AEROSPAC	
162C9		ELECTRIC RESISTANCE THERMOMETER >>	HORIZON AEROSPAC	
163BL501		ELECTRIC RESISTANCE THERMOMETER >>	HORIZON AEROSPAC	
163BL501C		ELECTRIC RESISTANCE THERMOMETER >>	HORIZON AEROSPAC	
163BL506		ELECTRIC RESISTANCE THERMOMETER >>	HORIZON AEROSPAC	
163BL507		ELECTRIC RESISTANCE THERMOMETER >>	HORIZON AEROSPAC	
163BL507B		ELECTRIC RESISTANCE THERMOMETER >>	HORIZON AEROSPAC	
163BL507H		ELECTRIC RESISTANCE THERMOMETER >>	HORIZON AEROSPAC	
163BL508		ELECTRIC RESISTANCE THERMOMETER >>	HORIZON AEROSPAC	
163BL511		ELECTRIC RESISTANCE THERMOMETER >>	HORIZON AEROSPAC	
163BL511A		ELECTRIC RESISTANCE THERMOMETER >>	HORIZON AEROSPAC	
163LC500		TEMPERATURE INDICATOR >>	HORIZON AEROSPAC	
163LC501		TEMPERATURE INDICATOR >>	HORIZON AEROSPAC	

06-08-202

Uniserv Aviation, Inc.

Rev#: 20

Capability List

<u>PART NUMBER:</u>	<u>MODEL/TYPE:</u>	<u>DESCRIPTION:</u>	<u>MANUFACTURER:</u>	<u>Rev#</u>
163LC550		TEMPERATURE INDICATOR >>	HORIZON AEROSPAC	
163LC551		TEMPERATURE INDICATOR >>	HORIZON AEROSPAC	
163LC553A		TEMPERATURE INDICATOR >>	HORIZON AEROSPAC	
163LC554		TEMPERATURE INDICATOR >>	HORIZON AEROSPAC	
163LC555		TEMPERATURE INDICATOR >>	HORIZON AEROSPAC	
16432		TRANSFORMER VARIABLE	OECO CORPORATION	
17209-6-A	17209-6-A	DIRECTIONAL GYRO TRANSMITTER	HONEYWELL BENDIX	
17238-1-A	17238-1-A	DIRECTIONAL GYRO TRANSMITTER	HONEYWELL BENDIX	
17238-1B		DIRECTIONAL GYRO	HONEYWELL/ BENDIX	
17238-1-B	17238-1-B	DIRECTIONAL GYRO TRANSMITTER	HONEYWELL BENDIX	
17238-20-A	17238-20-A	DIRECTIONAL GYRO TRANSMITTER	HONEYWELL BENDIX	
17238-2-A	17238-2-A	DIRECTIONAL GYRO TRANSMITTER	HONEYWELL BENDIX	
17265-1A	17265-1A	DIRECTIONAL GYRO	HONEYWELL BENDIX	
17265-2A	17265-2A	DIRECTIONAL GYRO	HONEYWELL BENDIX	
1750-1	60B40025-50	BALLAST	AVTECH CORPORATI	
1776167-2	1776167-2	DIRECTIONAL GYRO	HONEYWELL BENDIX	
1776167-3	1776167-3	DIRECTIONAL GYRO	HONEYWELL BENDIX	
1777213	C-6	COMPASS INDICATOR **	HONEYWELL BENDIX	
1777214	C-6A	COMPASS INDICATOR **	HONEYWELL BENDIX	
1778686	C-6D	COMPASS INDICATOR **	HONEYWELL BENDIX	
1778686-655	C6D	COMPAS INDICATOR	HONEYWELL	
177BCL2		ELECTRIC RESISTANCE THERMOMETER >>	HORIZON AEROSPAC	
177BCL3		ELECTRICAL RESISTANCE THERMOMETER >>	HORIZON AEROSPAC	
177BCL7		ELECTRIC RESISTANCE THERMOMETER >>	HORIZON AEROSPAC	
177BCL7A		ELECTRIC RESISTANCE THERMOMETER >>	HORIZON AEROSPAC	
177BCL7W		ELECTRIC RESISTANCE THERMOMETER >>	HORIZON AEROSPAC	
177BDL2A		ELECTRIC RESISTANCE THERMOMETER >>	HORIZON AEROSPAC	
177BDL2B		ELECTRIC RESISTANCE THERMOMETER >>	HORIZON AEROSPAC	
177BDL2C		ELECTRIC RESISTANCE THERMOMETER >>	HORIZON AEROSPAC	
177BDL2W		ELECTRIC RESISTANCE THERMOMETER >>	HORIZON AEROSPAC	
177BDL3A		ELECTRIC RESISTANCE THERMOMETER >>	HORIZON AEROSPAC	
177BDL3W		ELECTRIC RESISTANCE THERMOMETER >>	HORIZON AEROSPAC	
177BL100		ELECTRIC RESISTANCE THERMOMETER >>	HORIZON AEROSPAC	
17810-2AA1	17810-2AA1	DIRECTOR IND	HONEYWELL BENDIX	
17810-2AA2	17810-2AA2	DIRECTOR IND	HONEYWELL BENDIX	
17810-2AA3	17810-2AA3	DIRECTOR IND	HONEYWELL BENDIX	
17810-2AB1	17810-2AB1	DIRECTOR IND	HONEYWELL BENDIX	
17810-2AB2	17810-2AB2	DIRECTOR IND	HONEYWELL BENDIX	
17810-2AC1	17810-2AC1	DIRECTOR IND	HONEYWELL BENDIX	
17810-2AC4	17810-2AC4	DIRECTOR IND	HONEYWELL BENDIX	
17810-2AC5	17810-2AC5	DIRECTOR IND	HONEYWELL BENDIX	
17810-2AC6	17810-2AC6	DIRECTOR IND	HONEYWELL BENDIX	
17810-2BA1	17810-2BA1	DIRECTOR IND	HONEYWELL BENDIX	
17810-2BB1	17810-2BB1	DIRECTOR IND	HONEYWELL BENDIX	
17810-2BC1	17810-2BC1	DIRECTOR IND	HONEYWELL BENDIX	
17810-2CC1	17810-2CC1	DIRECTOR IND	HONEYWELL BENDIX	
1782993	C-6F	COMPASS INDICATOR **	HONEYWELL BENDIX	
1783755	C-6H	COMPASS INDICATOR **	HONEYWELL BENDIX	
1783875-5		AMPLIFIER	SPERRY	
1784389	C-6J	COMPASS INDICATOR **	HONEYWELL BENDIX	

06-08-202

Uniserv Aviation, Inc.

Rev#: 20

Capability List

<u>PART NUMBER:</u>	<u>MODEL/TYPE:</u>	<u>DESCRIPTION:</u>	<u>MANUFACTURER:</u>	<u>Rev#</u>
1784389-653	C-6J	GYROSYN COMPAS	HONEYWELL	
1784460-655	C-6E	GYROSYN COMPASS INDICATOR	HONEYWELL BENDIX	
1812-11LW	521677	TRIM AILERON INDICATOR >>	AMETEK	
1812-12LW	521679	TRIM RUDDER INDICATOR >>	AMETEK	
1812-14LW	521701	OIL TEMPERATURE INDICATOR >>	AMETEK	
1812-18LW	522105	OIL TEMPERATURE INDICATOR >>	AMETEK	
18-1258	10-60791-1	FLAP POSITION INDICATOR	COURTER	
18-1299	10-60791-2	FLAP POSITION INDICATOR >>	HONEYWELL	
18-1299-2	10-60791-4	FLAP POSITION INDICATOR >>	HONEYWELL	
18-1299-3	10-60791-6	FLAP POSITION INDICATOR >>	HONEYWELL	
18-1299-3-2	10-60791-6	FLAP POSITION INDICATOR >>	HONEYWELL	
18-1299-4	10-60791-11	FLAP POSITION INDICATOR >>	HONEYWELL	
18-1299-4-2	10-60791-11	FLAP POSITION INDICATOR >>	HONEYWELL	
18-1299-5	10-60791-12	FLAP POSITION INDICATOR >>	HONEYWELL	
18-1299-5-2	10-60791-12	FLAP POSITION INDICATOR >>	HONEYWELL	
18-1299-6	10-60791-13	FLAP POSITION INDICATOR >>	HONEYWELL	
18-1299-6-2	10-60791-13	FLAP POSITION INDICATOR >>	HONEYWELL	
18-1505		FLAP POSITION INDICATOR	COURTER	
18-1542	18-1542	FLAP POSITION INDICATOR	COURTER	
18-1542-2	18-1542-2	FLAP POSITION INDICATOR	COURTER	
18-1542-3	18-1542-3	FLAP POSITION INDICATOR	COURTER	
18-1738-9	10-61841-9	TRANSMITER, FLAP POSITION	BENDIX	
1822-124LW	521389	AIR TEMPERATURE INDICATOR >>	AMETEK	
1822-202LW	520415	AC VOLTMETER >>	AMETEK	
1822-206LW	520580	TACHOMETER APU INDICATOR >>	AMETEK	
1822-214LW	521159	GAS TEMPERATURE APU INDICATOR >>		
1822-220LW	520577	OIL TEMPERATURE INDICATOR >>	AMETEK	
1822-226LW	521201	OIL TEMPERATURE INDICATOR >>	AMETEK	
1822-344LW	522561	TEMPERATURE INDICATOR >>	AMETEK	
1822-371LW	522823	TORQUE INDICATOR >>	AMETEK	
1822-377LW	522948	TORQUE INDICATOR >>	AMETEK	
1822-97LW	520750	TEMPERATURE INDICATOR >>	AMETEK	
1825-105LW	522794	OIL TEMPERATURE INDICATOR >>	AMETEK	
1825-107LW	522796	HYDRAULIC PRESSURE INDICATOR >>	AMETEK	
1825-130LW	523250	HYDRAULIC PRESSURE INDICATOR >>	AMETEK	
1829-18L	522690	VALVE POSTION INDICATOR >>	AMETEK	
1829-18LW	522327	VALVE POSTION INDICATOR >>	AMETEK	
182936	10-60735-1	OXIGEN PRESSURE INDICATOR	AMETEK	
1837-201LW	520642	SURFACE POSITION INDICATOR >>	AMETEK	
1837-211LW	522834	TRIM POSITION INDICATOR >>	AMETEK	
1862-2LW	248541	ELEV/RUDDER POSITION INDICATOR >>	AMETEK	
1862-3LW	260582	ELEV/RUDDER POSITION INDICATOR >>	AMETEK	
19117-1A	19117-1A	THREE AXIS GYROSCOPE	HONEYWELL BENDIX	
19118-1A	19118-1A	THREE AXIS GYROSCOPE	HONEYWELL BENDIX	
1964391-1	1964391-1	DIRECTIONAL GYRO	HONEYWELL BENDIX	
1976910-1	1976910-1	ATTITUDE INDICATOR	HONEYWELL BENDIX	
1976910-2	1976910-2	ATTITUDE INDICATOR	HONEYWELL BENDIX	
1976910-3	1976910-3	ATTITUDE INDICATOR	HONEYWELL BENDIX	
1978128-1	1978128-1	ATTITUDE INDICATOR	HONEYWELL BENDIX	
1978130-1	1978130-1	3 INCH ATTITUDE INDICATOR	HONEYWELL BENDIX	
1978179-1	1978179-1	3-INCH ATTITUDE INDICATOR	HONEYWELL BENDIX	

1

06-08-202

Uniserv Aviation, Inc.

Rev#: 20

Capability List

<u>PART NUMBER:</u>	<u>MODEL/TYPE:</u>	<u>DESCRIPTION:</u>	<u>MANUFACTURER:</u>	<u>Rev#</u>
1978191-1	1978191-1	3 INCH ATTITUDE INDICATOR	HONEYWELL BENDIX	
1978799-1		3-INCH ATTITUDE INDICATOR	HONEYWELL BENDIX	
1990088-1	1990088-1	3-INCH ATTITUDE INDICATOR	HONEYWELL BENDIX	1
1990513-1	1990531-1	3-INCH ATTITUDE INDICATOR	HONEYWELL BENDIX	1
1990529-1	1990529-1	ATTITUDE INDICATOR	HONEYWELL BENDIX	
19911-1A	19911-1A	VERTICAL GYRO	HONEYWELL BENDIX	
19911-1B	19911-1B	VERTICAL GYRO	HONEYWELL BENDIX	
19911-1C	19911-1C	VERTICAL GYRO	HONEYWELL BENDIX	
19911-2B	19911-2B	VERTICAL GYRO	HONEYWELL BENDIX	
19911-2C	19911-2C	VERTICAL GYRO	HONEYWELL BENDIX	
19911-3B	19911-3B	VERTICAL GYRO	HONEYWELL BENDIX	
19911-3C	19911-3C	VERTICAL GYRO	HONEYWELL BENDIX	
19911-4C	19911-4C	VERTICAL GYRO	HONEYWELL BENDIX	
19912-1A	19912-1A	VERTICAL GYRO	HONEYWELL BENDIX	
19912-2A	19912-2A	VERTICAL GYRO	HONEYWELL BENDIX	
19912-2C	19912-2C	VERTICAL GYRO	HONEYWELL BENDIX	
19912-3A	19912-3A	VERTICAL GYRO	HONEYWELL BENDIX	
19912-3C	19912-3C	VERTICAL GYRO	HONEYWELL BENDIX	
19913-1A	19913-1A	VERTICAL GYRO	HONEYWELL BENDIX	
19913-1B	19913-1B	VERTICAL GYRO	HONEYWELL BENDIX	
19913-1C	19913-1C	VERTICAL GYRO	HONEYWELL BENDIX	
19913-2C	19913-2C	VERTICAL GYRO	HONEYWELL BENDIX	
19913-3C	19913-3C	VERTICAL GYRO	HONEYWELL BENDIX	
1A081-0155		TOILER TIMER	YAKOMA	
1G177-15		PRESSURE SWITCH	CUSTOM COMPONEN	
1G259-1	698430-1	PRESSURE SWITCH	AIRSEARCH	
1G259-2	698430-1	PRESSURE SWITCH	CUSTOM COMPONEN	
1U149-002-2	5000F	ATTITUDE GYRO	SIGMA TEK	
1U262-001-39	4000B-30	DIRECTIONAL GYRO	SIGMA TEK	
1U262-001-7	4000B-6	DIRECTIONAL GYRO	SIGMA TEK. INC	
1U262-001-9	4000B-8	DIRECTIONAL GYRO	SIGMA TEK	
1U262-002-003-14	4000C	DIRECTIONAL GYRO	SIGMA TEK	
1U262-002-67	4000B-46	DIRECTIONAL GYRO	SIGMA TEK	1
1U262-003-14	4000C	DIRECTIONAL GYRO	SIGMA TEK	
1U262-005-19	4000D	DIRECTIONAL GYRO	SIGMA TEK	1
1U262-005-20	4000D-1	DIRECTIONAL GYRO	SIGMA TEK	
1U284-001	5000L	ATTITUDE GYRO	SIGMA TEK,INC	1
1U284-001-1	5000L-8	ATTITUDE GYRO	SIGMA TEK. INC	1
1U284-001-3	5000L-4	ATTITUDE GYRO	SIGMA TEK INC	1
1U367-006-6	44670-0008	FLIGHT DIRECTOR	SIGMA-TEK	
200-6	52D54	DIRECTIONAL GYRO	AVIATION INSTRUMEN	1
201-004-001	201-004-001	TORQUEMETER INDICATOR	GULL AIRBORNE INST	
203BC101	NO MODEL#	BATTERY CHARGE	ACME ELECTRIC	
203BC101-1	NO MODEL#	BATTERY CHARGE	ACME ELECTRIC	
203BC102-1	NO MODEL#	BATTERY CHARGE	ACME ELECTRIC	
20401	NO MODEL#	TEMPERATURE CONTROLER	PACIFIC ELECTRO DIN	
20401-2	PACIFIC ELECTRO DYNAM	WINDSHIELD TEMP. CONTROLER	PACIFIC ELECTRO DY	
2045-08-1	10-60737-16	EPR INDICATOR >>	SMITHS INDUSTRIES	
2047-02-1		ENGINE PRESSURE RATIO INDICATOR >>	SMITHS INDUSTRIES	
2054-01-1	2054-01-1	SERVOED ALTITUDE INDICATOR	HAROWE	
2056-01-1	10-61826-7	SERVOED ALTITUDE INDICATOR	SMITHS	

06-08-202

Uniserv Aviation, Inc.

Rev#: 20

Capability List

<u>PART NUMBER:</u>	<u>MODEL/TYPE:</u>	<u>DESCRIPTION:</u>	<u>MANUFACTURER:</u>	<u>Rev#</u>
2057-01-1	10-61826-8	SERVOED ALTITUD INDICATOR	GE AVIATION	
2057-02-01	10-61826-10	SERVOED ALTITUDE INDICATOR	SMITHS	
2061-11-1	10-61926-1	FLAP POSITION INDICATOR >>	SMITHS INDUSTRIES	
2061-12-1	10-61926-2	FLAP POSITION INDICATOR >>	SMITHS INDUSTRIES	
2061-13-1	10-61926-3	FLAP POSITION INDICATOR >>	SMITHS INDUSTRIES	
2061-14-1	10-61926-4	FLAP POSITION INDICATOR >>	SMITHS INDUSTRIES	
2070-05-1	10-61825-4	VERTICAL AERO SPEED	SMITHS	
2083-08-1	10-61818-151	MACH AIRSPEED INDICATOR >>	GE AVIATION	
2083-09-1	10-61818-161	MACH AIRSPEED INDICATOR >>	GE AVIATION	
2083-10-1	10-61818-161	MACH AIRSPEED INDICATOR >>	GE AVIATION	
2083-11-1	10-61818-18	MACH AIRSPEED INDICATOR >>	GE AVIATION	
208-901-001		I.I.T. INDICATOR	GULL AIRBORNE	
2092-01-1	10-61991-1	TACHOMETER INDICATOR	SMITHS	
2-107A		PRECISION FREQUENCY POWER SUPPLY	CRANE	
211-011-001	NO MODEL #	FUEL QTY REPEATER	GULL AIRBORNE	
2117404-05		ELECTRONIC CONTROL	HONEYWELL	
2117404-3		ELECTRONIC CONTROL UNIT	HONEYWELL	
214C50-2	10-2638-4	SWICHT ALTITUDE	EATON	
214C50-68	214C50-68	ALTITUDE PRESSURE SWITCH	EATON	
217-09261	217-09261	TORQUE PRESSURE IND	EDISON	
22105-25-A5-1		MAGNESYN TORQUE PRESURE TRANSMITER	BENDIX	
2-299		TRANSFORMER-RECTIFIER	ELDEC	
2300-01-1	10-61219-111	FUEL QUANTITY INDICATOR >>	SMITHS INDUSTRIES	
231-2	10-61833-1	CONTROL WINDOW HEAT	ASTRONICS ADVANCE	
2316-1		CONTROL VALVE	UNITED CONTROL	
233N3214-22	233N3214	LIGHTING CONTROL PANEL ASSEMBLY	BOEING	
233N3214-24	M10056	LIGHTING CONTROL PANEL ASSEMBLY	BOEING	
233N3214-300	M10056	LIGHTING CONTROL PANEL ASSEMBLY	BOEING	
233N3214-306	M10056	LIGHTING CONTROL PANEL ASSEMBLY	BOEING	
233N3214-31	M10056	LIGHTING CONTROL PANEL ASSEMBLY	BOEING	
233T3100-153	233T3100	APU CONTROL PANEL ASSEMBLY	BOEING	
233T3100-461	233T3100	APU CONTROL PANEL ASSEMBLY	BOEING	
233T3100-53	233T3100	APU CONTORL PANEL ASSEMBLY	BOEING	
233T3232-5	233T3232	APU CONTROL PANEL ASSEMBLY	BOEING	
23-501-016	5000B-10	ATTITUDE GYRO	SIGMA TEK	
23-501-05-2	5000E-9	ATTITUDE GYRO	SIGMA-TEK	
23-501-06-16	5000B36	ATTITUDE GYRO	SIGMATEK	
23-501-06-23	5000B-71	GYRO HORIZON	SIGMATEK	
23-501-06-3	5000B-9	ATTITUDE GYRO	SIGMA TEK	
23932-516	570	ALTIMETER	IDC	
248541	1862-2LW	ELEV/RUDDER POSITION INDICATOR >>	AMETEK	
248697	1824-16	INDICATOR >>	AMETEK	
248836	1824-17	INDICATOR >>	AMETEK	
253264	1824-18	INDICATOR >>	AMETEK	
253884	10-60775-6	SURFACE POSITION INDICATOR >>	AMETEK	
254625-902		RADIO DIGITAL DISTANCE MAGNETIC INDICATOR	HONEYWELL	
2585302	2585302	DIRECTIONAL GYRO **	HONEYWELL BENDIX	
2585302-1	DG-226	DIRECTIONAL GYROSCOPE **	HONEYWELL BENDIX	
2585703		SLAVING AMPLIFIER	HONEYWELL	
2585703-2		SLAVING AMPLIFIER	HONEYWELL	

06-08-202

Uniserv Aviation, Inc.

Rev#: 20

Capability List

<u>PART NUMBER:</u>	<u>MODEL/TYPE:</u>	<u>DESCRIPTION:</u>	<u>MANUFACTURER:</u>	<u>Rev#</u>
2586333-1	DG-231	DIRECTIONAL GYROSCOPE **	HONEYWELL BENDIX	
2586333-2	DG-231	DIRECTIONAL GYROSCOPE **	HONEYWELL BENDIX	
2586333-3	DG-231	DIRECTIONAL GYROSCOPE **	HONEYWELL BENDIX	
2587193-1	C-14	GYRO SYNCHRONIZER **	HONEYWELL BENDIX	
2587193-143	C-14A	DIRECTIONAL GYRO **	HONEYWELL BENDIX	
2587193-2	C-14	GYRO SYNCHRONIZER **	HONEYWELL BENDIX	
2587193-21	C-14	GYRO SYNCHRONIZER **	HONEYWELL BENDIX	
2587193-22	C-14	GYRO SYNCHRONIZER **	HONEYWELL BENDIX	
2587193-24	C-14	GYRO SYNCHRONIZER **	HONEYWELL BENDIX	
2587193-25	C-14	GYRO SYNCHRONIZER **	HONEYWELL BENDIX	
2587193-26	C-14	GYRO SYNCHRONIZER **	HONEYWELL BENDIX	
2587193-3	C-14	GYRO SYNCHRONIZER **	HONEYWELL BENDIX	
2587193-33	C-14	GYRO SYNCHRONIZER **	HONEYWELL BENDIX	
2587193-36	C-14	GYRO SYNCHRONIZER **	HONEYWELL BENDIX	
2587193-4	C-14	GYRO SYNCHRONIZER **	HONEYWELL BENDIX	
2587193-41	C-14A	DIRECTIONAL GYRO **	HONEYWELL BENDIX	
2587193-42	C-14A	DIRECTIONAL GYRO **	HONEYWELL BENDIX	
2587193-43	C-14A	DIRECTIONAL GYRO **	HONEYWELL BENDIX	
2587193-44	C-14A	DIRECTIONAL GYRO **	HONEYWELL BENDIX	
2587193-45	C-14A	DIRECTIONAL GYRO **	HONEYWELL BENDIX	
2587193-46	C-14A	DIRECTIONAL GYRO **	HONEYWELL BENDIX	
2587193-47	C-14A	DIRECTIONAL GYRO **	HONEYWELL BENDIX	
2587193-5	C-14	GYRO SYNCHRONIZER **	HONEYWELL BENDIX	
2587193-6	C-14	GYRO SYNCHRONIZER **	HONEYWELL BENDIX	
2587317-653	C-6L	GYROSYN COMPAS	HONEYWELL	
2587335-10	VG-310	VERTICAL GYRO >>	HONEYWELL	
2587335-11	VG-311	VERTICAL GYRO >	HONEYWELL	
2587335-111	VG-311	VERTICAL GYRO >>	HONEYWELL	
2587335-112	VG-312	VERTICAL GYRO >>	HONEYWELL	
2587335-113	VG-313	VERTICAL GYRO >>	HONEYWELL	
2587335-114	VG-314	VERTICAL GYRO >>	HONEYWELL	
2587335-12	VG-312	VERTICAL GYRO >>	HONEYWELL	
2587335-121		VERTICAL GYRO >>	HONEYWELL	
2587335-122	VG-312	VERTICAL GYRO >>	HONEYWELL	
2587335-13	VG-313	VERTICAL GYRO >>	HONEYWELL	
2587335-14	VG-314	VERTICAL GYRO >>	HONEYWELL	
2587335-21	VG-321	VERTICAL GYRO >>	HONEYWELL	
2587335-211	VG-321	VERTICAL GYRO	HONEYWELL	
2587335-22	VG-322	VERTICAL GYRO >>	HONEYWELL	
2587335-8	VG-308	VERTICAL GYRO >>	HONEYWELL	
2587335-9	VG-309	VERTICAL GYRO >>	HONEYWELL	
2587567	NO MODEL#	COMPAS INDICATOR	HONEYWELL	
2588282-656	C-6M	GYROSYN COMPASS INDICATOR	HONEYWELL	
2588302-1	DG-233	DIRECTIONAL GYROSCOPE **	HONEYWELL BENDIX	
2588302-10	DG-236	DIRECTIONAL GYROSCOPE **	HONEYWELL BENDIX	
2588302-2	DG-241	DIRECTIONAL GYROSCOPE **	HONEYWELL INDEX	
2588302-3	DG-242	DIRECTIONAL GYROSCOPE **	HONEYWELL BENDIX	
2588302-4	DG-206A	DIRECTIONAL GYRO >>	HONEYWELL	
2588302-5	DG-234	DIRECTIONAL GYROSCOPE **	HONEYWELL BENDIX	
2588302-501	DG-234	DIRECTIONAL GYROSCOPE **	HONEYWELL BENDIX	
2588302-6	DG-235	DIRECTIONAL GYROSCOPE **	HONEYWELL BENDIX	

06-08-202

Uniserv Aviation, Inc.

Rev#: 20

Capability List

<u>PART NUMBER:</u>	<u>MODEL/TYPE:</u>	<u>DESCRIPTION:</u>	<u>MANUFACTURER:</u>	<u>Rev#</u>
2588302-7	DG-243	DIRECTIONAL GYROSCOPE **	HONEYWELL BENDIX	
2588302-8	DG-244	DIRECTIONAL GYROSCOPE **	HONEYWELL BENDIX	
2589210-901	2589210	COMPAS SYSTEM RACK	HONEYWEE;L	
2589210-9012		COMPASS SYSTEM RACK	HONEYWELL	
2589210-902		COMPAS RACK	HONEYWELL	
2589417-901	2589417-901	TVI DUAL ENGINE INDICATOR **	HONEYWELL BENDIX	
2589417-902	2589417-902	TVI DUAL ENGINE INDICATOR **	HONEYWELL BENDIX	
2591092-903	AD-350	ATTITUDE DIRECTOR INDICATOR >>	HONEYWELL	
2591092-904	AD-350	ATTITUDE DIRECTOR INDICATOR >>	HONEYWELL	
2593691	VG-401	ATTITUDE REFERENCE **	HONEYWELL BENDIX	
2593691-901	VG-401	ATTITUDE REFERENCE **	HONEYWELL BENDIX	
2593966-444	2593966-444	TARSYN THREE AXIS REFERENCE **	HONEYWELL BENDIX	
2593966-333	2593966-333	TARSYN THREE AXIS REFERENCE **	HONEYWELL BENDIX	
2593966-555	2593966-555	TARSYN THREE AXIS REFERENCE **	HONEYWELL BENDIX	
2594625-902		RADIO DIGITAL DISTANCE MAGNETIC IND	HONEYWELL	
2594863-901	AD-350A	ATTITUDE INDICATOR	HONEYWELL	
2594863-904	AD-350A	ATTITUDE DIRECTOR INDICATOR	HONEYWELL	
2594863-908	AD-350A	ATTITUDE DIRECTOR INDICATOR	HONEYWELL	
260245		AC VOLTMETER >>	AMETEK	
260246		AC VOLTMETER >>	AMETEK	
260283		AC AMMETER >>	AMETEK	
260287		AC AMMMETER >>	AMETEK	
260582	1862-3LW	ELEV/RUDDER POSITION INDICATOR **	AMETEK	
262-0441-010	NO MODEL#	ANUNCIATOR	COLLINS	
262-0441-090	NO MODEL#	ANUNCIATOR	COLLINS	
26440005-01		STATIC INVERTER	SUNDSTRAD CORPOR	
266440005-01		STATIC INVERTER	SUNDSTRAND	2
285T0096-13	285T0096	ELECTRONIC ENGINE CONTROL DISCRETE	BOEING	
285T0096-17	285T0096-17	ELECTRONIC ENGINE CONTROL DISCRETE	BOEING	
285T0096-5	285T0096	ELECTRONIC ENGINE CONTROL DISCRETE	BOEING	
285T0096-7	285T0096	ELECTRONIC ENGINE CONTROL DISCRETE	BOEING	
28702-502	28702	ENCODING ALTIMETER	INTERCONTINENTAL	
29255-10A-A17	NO MODEL#	REGULATOR OXIGEN	NAVAIR	
2CM9AAA6		TACHOMETER GENERATOR >>	AMETEK	
2CM9AAC6		TACHOMETER GENERATOR >>	AMETEK	
2CM9AAH4		TACHOMETER GENERATOR >>	AMETEK	
2CM9AAV6		TACHOMETER GENERATOR >>	AMETEK	
2CM9AAZ6		TACHOMETER GENERATOR >>	AMETEK	
2CM9ABE6		TACHOMETER GENERATOR >>	AMETEK	
2CM9ABH7		TACHOMETER GENERATOR >>	AMETEK	
2CM9ABK7		TACHOMETER GENERATOR >>	AMETEK	
2CM9ABY7		TACHOMETER GENERATOR >>	AMETEK	
2CM9ABZ7		TACHOMETER GENERATOR >>	AMETEK	
2CM9ACE7		TACHOMETER GENERATOR >>	AMETEK	
2CM9ACF8		TACHOMETER GENERATOR >>	AMETEK	
2CM9ACH7		TACHOMETER GENERATOR >>	AMETEK	
2CM9ADB9		TACHOMETER GENERATOR >>	AMETEK	
2CM9ADE8		TACHOMETER GENERATOR >>	AMETEK	
2CM9ADT6		TACHOMETER GENERATOR >>	AMETEK	
300-3	300-3	HORIZON INDICATOR	AIM	
300-3CF	300-3CF	HORIZON INDICATOR	AIM	

06-08-202

Uniserv Aviation, Inc.

Rev#: 20

Capability List

<u>PART NUMBER:</u>	<u>MODEL/TYPE:</u>	<u>DESCRIPTION:</u>	<u>MANUFACTURER:</u>	<u>Rev#</u>
30-0432-1		EMERGENCY EGRESS LIGHT **	HONEYWELL GRIMES	
30-0432-13		EMERGENCY EGRESS LIGHT **	HONEYWELL GRIMES	
30-0837-21		ANTICOLLISION STROBE LIGHT	GRIMES AEROSPACE	
30-0906-104		STROBE LIGHT	GRIME AEROSPACE	
30-0909-101		TAIL POSITION LIGHT	HONEYWELL	
30-0909-103		TAIL POSITION LIGHT	HONEYWELL	
30-0909-107	NO MODEL#	TAIL POSITION LIGHT	HONEYWELL	
30-0909-201	NO MODEL#	TAIL POSITION LIGHT	HONEYWELL	
30-1098-1	NO MODEL#	LIGHT UPPER STROBE	HONEYWEL/GRIME	
30-1099-1	NO MODEL #	ANTICOLLISION STROBE LIGHT	GRIME	
30-10991A	NO MODEL#	ANTICOLLISION STROBE LIGHT	HONEYWELL	
30-1099-1A	NO MODEL#	ANTICOLLISION STROBE LIGHT	HONEYWELL	
30-1401-3		ANTICOLLISION STROBE LIGHT	GRIMES AEROSPACE	
30-2109-3	NO MODEL #	STROBE LIGHT	GRIME	
304313-1	NO MODEL#	TEMPERATURE CONTROL UNIT	HONEYWELL	
304685-2	NO MODEL#	APU CONTROL UNIT	ALLIED SIGNAL	
305454-11	305454-11	SWITCH -SPEED	HONEYWELL	
305454-11-1	305454-11-1	SWITCH SPEED	HONEYWELL	
305454-12	305454	SWITCH SPEED	HONEYWELL	
305454-12-1	305454	SWITCH SPEED	HONEYWELL	
305454-13-1	NO MODEL #	SPEED SWITCH	HONEYWELL	
305593-3	305593-3	SPEED SWITCH ASSEMBLY	HONEYWELL	
305593-4	305593	SPEED SWITCH ASSEMBLY	HONEYWELL	1
305593-5		SPEED SWITCH ASSY	HONEYWELL	
305593-7		SWITCH ASSEMBLY SPEED	HONEYWELL	
307130-1		SWITCH SPEED	HONEYWELL	
307130-1-1		SWITCH SPEED	HONEYWELL	
307130-7		SWITCH SPEED	HONEYWELL	
3081-25	3081-25	BALLAST UNIT	DIEHL	
3081-35	3081-35	BALLAST UNIT	DIEHT	
3081-65	3081-65	BALLAST UNIT	DIEHL	
31101 C	NO MODEL#	DIRECTIONAL GYRO	AERITALIA	
32005-008		TACHOMETER GENERATOR	AIRCRAFT APPLIANCE	
3273-50		WINDSHIELD HEAT CONTROL UNIT	DIEHL LUFTFAHRT	
339D-1		DISTANCE INDICATOR >>	COLLINS	
339D-1A		DISTANCE INDICATOR >>	COLLINS	
339D-3B		DISTANCE INDICATOR >>	COLLINS	
339D-3D		DISTANCE INDICATOR >>	COLLINS	
34265-1	34265-1	COCKPIT LIGHT **	HONEYWELL GRIMES	
34265-14		COCKPIT LIGHT **	HONEYWELL GRIMES	
34265-16		COCKPIT LIGHT **	HONEYWELL GRIMES	
34265-8	34265-8	COCKPIT LIGHT **	HONEYWELL GRIMES	
35.349.100		BRAKING SYSTEM TEST UNIT	AEROSPATIALE	
35.349.1003		BRAKINK SYSTEM TEST UNIT	AEROSPATIALE	
35008-38	NO MODEL #	OVERHEAT CONTROLLER PCB	FENWAL	
3567749-1501	3567749	PRESSURE TRANSMITTER **	HONEYWELL	
3567749-9401	3567749	PRESSURE TRANSMITTER **	HONEYWELL	
3567749-9502		PRESSURE TRANSMITTER **	HONEYWELL	
3571260-7001	NO MODEL#	TACHOMETER INDICATOR	BENDIX	
35805-0	35805-0	CONTROL	FENWAL	
3603281-6		IGNITION EXCITER	UNISON	

Rev#: 20

Capability List

<u>PART NUMBER:</u>	<u>MODEL/TYPE:</u>	<u>DESCRIPTION:</u>	<u>MANUFACTURER:</u>	<u>Rev#</u>
3609480-1	NO MODEL #	SWITCH ASSY CENTRIFUGAL	HONEYWELL	
36148-1AJ25A1	36148-1AJ25A1	MAGNETIC COMPASS IND	HONEYWELL BENDIX	
36148-1AJ25A2	36148-1AJ25A2	MAGNETIC COMPASS IND	HONEYWELL BENDIX	
36154-1AF25A1	36154-1AF25A1	MAGNETIC COMPASS IND	HONEYWELL BENDIX	
36154-1AF25B1	36154-1AF25B1	MAGNETIC COMPASS IND	HONEYWELL BENDIX	
36154-1AJ25A1	36154-1AJ25A1	MAGNETIC COMPASS IND	HONEYWELL BENDIX	
36154-1AJ25B1	36154-1AJ25B1	MAGNETIC COMPASS IND	HONEYWELL BENDIX	
36154-1AJ33B1	36154-1AJ33B1	MAGNETIC COMPASS IND	HONEYWELL BENDIX	
36155-1AF25A1	36155-1AF25A1	MAGNETIC COMPASS IND	HONEYWELL BENDIX	
36155-1AF25A2	36155-1AF25A2	MAGNETIC COMPASS IND	HONEYWELL BENDIX	
36155-1AJ25A1	36155-1AJ25A1	MAGNETIC COMPASS IND	HONEYWELL BENDIX	
36162-1AJ25A1	36162-1AJ25A1	MAGNETIC COMPASS IND	HONEYWELL BENDIX	
369256		IGNITION EXCITER	HONEYWELL	
373205-2	1G98-5	PRESSURE SWITCH	CUSTOM CONTRL SE	
384369-01488	384369-01488	FUEL LOAD LIMIT CONTROL **	BF GOODRICH	
384369-01825	384369-01825	FUEL LOAD LIMIT CONTROL **	BF GOODRICH	
3876259-2	NO MODEL #	SPEED SWITCH ASSEMBLY	ALLIEDSIGNAL	
3876259-4		SWITCH OUTLINE MOUTTED	ALLIEDSIGNAL	
3876259-6		SWITCH SPEED	ALLIED SIGNAL	
3876326-6		SWITCH	ALLIED SIGNAL	
393004-060	393004-060	FUEL QUANTITY INDICATOR **	BF GOODRICH	
393004-061	393004-061	FUEL QUANTITY INDICATOR **	BF GOODRICH	
393008-036	NO MODEL#	FUEL QTY INDICATOR	SIMMONDS PRECISIO	
393008-040	NO MODEL #	FUEL QTY INDICATOR	SIMMONDS PRECISIO	
393020-003	10-60722-6	LIQUID QUANTITY INDICATOR >>>	BF GOODRICH	
393020-012	10-60722-7	LIQUID QUANTITY INDICATOR >>>	BF GOODRICH	
393020-01789	10-60722-5	LIQUID QUANTITY INDICATOR >>>	BF GOODRICH	
393026-001	10-61219-31	FUEL QUANTITY INDICATOR >>>	BF GOODRICH	
393026-002	10-61219-42	FUEL QUANTITY INDICATOR >>>	BF GOODRICH	
393026-003	10-61219-33	FUEL QUANTITY INDICATOR >>>	BF GOODRICH	
393026-01837	10-61219-3	FUEL QUANTITY INDICATOR >>>	BF GOODRICH	
393026-01838	10-61219-5	FUEL QUANTITY INDICATOR >>>	BF GOODRICH	
393026-01840	10-61219-2	FUEL QUANTITY INDICATOR >>>	BF GOODRICH	
393026-01841	10-61219-4	FUEL QUANTITY INDICATOR >>>	BF GOODRICH	
393026-01880	10-61219-32	FUEL QUANTITY INDICATOR >>	BF GOODRICH	
393026-03235	393026-03235	FUEL QUANTITY INDICATOR **	BF GOODRICH	
393026-03236	10-60520-5	FUEL QUANTITY INDICATOR **	BF GOODRICH	
393026-03334	393026-03334	FUEL QUANTITY INDICATOR **	BF GOODRICH	
393026-03335	392026-03335	FUEL QUANTITY INDICATOR **	BF GOODRICH	
393026-03508	393026-03508	FUEL QUANTITY INDICATOR **	BF GOODRICH	
393026-03569	393026-03569	FUEL QUANTITY INDICATOR **	BF GOODRICH	
393026-036	393026-036	FUEL QUANTITY INDICATOR ***	BF GOODRICH	
393026-037	393026-037	FUEL QUANTITY INDICATOR **	BF GOODRICH	
393026-038	393026-038	FUEL QUANTITY INDICATOR **	BF GOODRICH	
393026-039	393026-039	FUEL QUANTITY INDICATOR **	BF GOODRICH	
393026-040	393026-040	FUEL QUANTITY INDICATOR **	BF GOODRICH	
393026-042	10-60520-50	FUEL QUANTITY INDICATOR **	BF GOODRICH	
393026-04237	393026-04237	FUEL QUANTITY INDICATOR **	BF GOODRICH	
393026-043	393026-043	FUEL QUANTITY INDICATOR **	BF GOODRICH	
393026-04337	393026-04337	FUEL QUANTITY INDICATOR **	BF GOODRICH	
393026-044	393026-044	FUEL QUANTITY INDICATOR **	BF GOODRICH	

06-08-202

Uniserv Aviation, Inc.

Rev#: 20

Capability List

<u>PART NUMBER:</u>	<u>MODEL/TYPE:</u>	<u>DESCRIPTION:</u>	<u>MANUFACTURER:</u>	<u>Rev#</u>
393026-04510	393026-04510	FUEL QUANTITY INDICATOR **	BF GOODRICH	
393026-04568	393026-04568	FUEL QUANTITY INDICATOR **	BF GOODRICH	
393026-047	10-61219-42	FUEL QUANTITY INDICATOR >>>	BF GOODRICH	
393026-048	10-61219-501	FUEL QUANTITY INDICATOR >>>	BF GOODRICH	
393026-052	10-61219-41	FUEL QUANTITY INDICATOR >>>	BF GOODRICH	
393026-053	393026-053	FUEL QUANTITY INDICATOR **	BF GOODRICH	
393026-054	393026-054	FUEL QUANTITY INDICATOR **	BF GOODRICH	
393026-064	393026-064	FUEL QUANTITY INDICATOR **	BF GOODRICH	
393026-065	10-6129-46	FUEL QUANTITY INDICATOR >>>	BF GOODRICH	
393026-071	393026-071	FUEL QUANTITY INDICATOR **	BF GOODRICH	
393026-072	393026-072	FUEL QUANTITY INDICATOR **	BF GOODRICH	
393026-073	10-61219-57	FUEL QUANTITY INDICATOR >>>	BF GOODRICH	
393026-074	10-61219-60	FUEL QUANTITY INDICATOR >>>	BF GOODRICH	
393026-076	393026-076	FUEL QUANTITY INDICATOR ***	BF GOODRICH	
393026-077	393026-077	FUEL QUANTITY INDICATOR **	BF GOODRICH	
393026-079	393026-079	FUEL QUANTITY INDICATOR **	BF GOODRICH	
393026-080	393026-080	FUEL QUANTITY INDICATOR ***	BF GOODRICH	
393026-081	393026-081	FUEL QUANTITY INDICATOR **	BF GOODRICH	
393026-082	393026-082	FUEL QUANTITY INDICATOR **	BF GOODRICH	
393026-083	393026-083	FUEL QUANTITY INDICATOR **	BF GOODRICH	
393026-084	393026-084	FUEL QUANTITY INDICATOR **	BF GOODRICH	
393026-085	393026-085	FUEL QUANTITY INDICATOR **	BF GOODRICH	
393026-086	393026-086	FUEL QUANTITY INDICATOR **	BF GOODRICH	
393026-087	393026-087	FUEL QUANTITY INDICATOR **	BF GOODRICH	
393026-088	393026-088	FUEL QUANTITY INDICATOR **	BF GOODRICH	
393026-089	393026-089	FUEL QUANTITY INDICATOR **	BF GOODRICH	
393026-090	393026-090	FUEL QUANTITY INDICATOR **	BF GOODRICH	
393026-091	393026-091	FUEL QUANTITY INDICATOR **	BF GOODRICH	
393026-092	393026-092	FUEL QUANTITY INDICATOR **	BF GOODRICH	
393026-093	393026-093	FUEL QUANTITY INDICATOR **	BF GOODRICH	
393026-094	393026-094	FUEL QUANTITY INDICATOR **	BF GOODRICH	
393026-095	393026-095	FUEL QUANTITY INDICATOR **	BF GOODRICH	
393026-096	393026-096	FUEL QUANTITY INDICATOR **	BF GOODRICH	
393027-002	393027-002	FUEL QUANTITY INDICATOR **	BF GOODRICH	
393027-003	393027-003	FUEL QUANTITY INDICATOR **	BF GOODRICH	
393027-007	393027-007	FUEL QUANTITY INDICATOR **	BF GOODRICH	
393027-009	393027-009	FUEL QUANTITY INDICATOR **	BF GOODRICH	
393027-010	393027-010	FUEL QUANTITY INDICATOR **	BF GOODRICH	
393027-012	393027-012	FUEL QUANTITY INDICATOR **	BF GOODRICH	
393027-04378	393027-04378	FUEL QUANTITY INDICATOR **	BF GOODRICH	
393080-051	393080-051	FUEL AND V-REFERENCE INDICATOR **	BG GOODRICH	
393080-103	393080-103	FUEL AND V-REFERENCE INDICATOR **	BF GOODRICH	
393080-104	393080-104	FUEL AND V-REFERENCE INDICATOR **	BF GOODRICH	
393080-105	393080-105	FUEL AND V-REFERENCE INDICATOR **	BF GOODRICH	
393080-113	393080-113	FUEL AND V-REFERENCE INDICATOR **	BF GOODRICH	
393080-114	393080-114	FUEL AND V-REFERENCE INDICATOR **	BF GOODRICH	
393080-115	393080-115	FUEL AND V-REFERENCE INDICATOR **	BF GOODRICH	
393080-116	393080-116	FUEL AND V-REFERENCE INDICATOR **	BF GOODRICH	
393080-117	393080-117	FUEL AND V-REFERENCE INDICATOR **	BF GOODRICH	
393080-118	393080-118	FUEL AND V-REFERENCE INDICATOR **	BF GOODRICH	
393080-121	393080-121	FUEL AND V-REFERENCE INDICATOR **	BF GOODRICH	

06-08-202

Uniserv Aviation, Inc.

Rev#: 20

Capability List

<u>PART NUMBER:</u>	<u>MODEL/TYPE:</u>	<u>DESCRIPTION:</u>	<u>MANUFACTURER:</u>	<u>Rev#</u>
393081-103	393081-103	FUEL QUANTITY TOTALIZER INDICATOR **	BF GOODRICH	
393081-105	393081-105	FUEL QUANTITY TOTALIZER INDICATOR **	BF GOODRICH	
393081-107	393081-107	FUEL QUANTITY TOTALIZER INDICATOR **	BF GOODRICH	
393081-109	393081-109	FUEL QUANTITY TOTALIZER INDICATOR **	BF GOODRICH	
393081-111	393081-111	FUEL QUANTITY TOTALIZER INDICATOR **	BF GOODRICH	
393081-113	393081-113	FUEL QUANTITY TOTALIZER INDICATOR **	BF GOODRICH	
393081-115	393081-115	FUEL QUANTITY TOTALIZER INDICATOR **	BF GOODRICH	
393082-101	393082-101	FUEL QUANTITY REPEATER INDICATOR **	BF GOODRICH	
393082-103	393082-103	FUEL QUANTITY REPEATER INDICATOR **	BF GOODRICH	
393082-105	393082-105	FUEL QUANTITY REPEATER INDICATOR **	BF GOODRICH	
393082-107	393082-107	FUEL QUANTITY REPEATER INDICATOR **	BF GOODRICH	
393082-109	393082-109	FUEL QUANTITY REPEATER INDICATOR **	BF GOODRICH	
393082-111	393082-111	FUEL QUANTITY REPEATER INDICATOR **	BF GOODRICH	
393082-113	393082-113	FUEL QUANTITY REPEATER INDICATOR **	BF GOODRICH	
393084-031	393084-031	FUEL QUANTITY INDICATOR ***	BF GOODRICH	
393084-036	393084-036	FUEL QUANTITY INDICATOR ***	BF GOODRICH	
393084-04359	393084-04359	LIQUID QUANTITY INDICATOR **	BF GOODRICH	
393084-04408	393084-04408	LIQUID QUANTITY INDICATOR **	BF GOODRICH	
393084-04596	393084-04596	LIQUID QUANTITY INDICATOR **	BF GOODRICH	
393084-054	393084-054	FUEL QUANTITY INDICATOR **	BF GOODRICH	
393084-22488	393084-22488	FUEL QUANTITY INDICATOR **	BD GOODRICH	
393084-22825	393084-22825	FUEL QUANTITY INDICATOR **	BF GOODRICH	
393086-01235	393086-01235	FUEL QUANTITY INDICATOR **	BF GOODRICH	
393086-01236	393086-01236	FUEL QUANTITY INDICATOR **	BF GOODRICH	
393086-01334	393086-01334	FUEL QUANTITY INDICATOR **	BF GOODRICH	
393086-01335	393086-01335	FUEL QUANTITY INDICATOR **	BF GOODRICH	
393086-01508	393086-01508	FUEL QUANTITY INDICATOR **	BF GOODRICH	
393086-01569	393086-01569	FUEL QUANTITY INDICATOR **	BF GOODRICH	
393086-02237	393086-02237	FUEL QUANTITY INDICATOR **	BF GOODRICH	
393086-02337	393086-02337	FUEL QUANTITY INDICATOR **	BF GOODRICH	
393086-02510	393086-02510	FUEL QUANTITY INDICATOR **	BF GOODRICH	
393086-02568	393086-02568	FUEL QUANTITY INDICATOR **	BF GOODRICH	
39499-A1131		PNEUMATIC ALTIMETER	INTERCONTINENTAL	
39499-B1131		PNEUMATIC ALTIMETER	INTERCONTINENTAL	
396-02740	396-02740	OIL PRESSURE IND	ARMTEC	
396-05740	396-05740	OIL PRESSURE IND	ARMTEC	
3S2060DC168A1	6110-01-052-4851	GENERATOR CONTROL UNIT	GENERAL ELECTRIC	
3S2060DC168A1A	3S2060DC168A1A	GENERATOR CONTROL UNIT	G.E	
40-0074-11	NO MODEL#	ANTICOLLIION LOWER	GRIMES	
4001808-901	VG-14	VERTICAL GYRO **	HONEYWELL BENDIX	
4003733-903	NO MODEL#	HORIZON SITUATION IND.	HONEYWELL	
4004255-901	AD-350B	ATTITUDE DIRECTOR INDICATOR	HONEYWELL	
4004255-902	AD-350B	ATTITUDE DIRECTOR INDICATOR	HONEYWELL	
4005123-907	NO MODEL#	ALTIMETER	HONEYWELL	
40057-1	10-3067-3	PRESSURE SWITCH	CUSTOM COMPONEN	
4006584-901	AD-300B	ATTITUDE DIRECTOR INDICATOR	HONEYWELL	
4006584-902	AD-300B	ATTITUDE DIRECTOR	HONEYWELL	
4014879-901		RAIDO DIGITAL DISTANCE MAGNETIC INDICATOR	HONEYWELL	
4019190-3	C-14A	GYRO SYNCHRONIZER >>	HONEYWELL	
4019700-902	AD-300C	ATTITUDE DIRECTOR INDICATOR >>	HONEYWELL	

06-08-202

Uniserv Aviation, Inc.

Rev#: 20

Capability List

<u>PART NUMBER:</u>	<u>MODEL/TYPE:</u>	<u>DESCRIPTION:</u>	<u>MANUFACTURER:</u>	<u>Rev#</u>
4019700-903		ATTITUDE DIRECTOR INDICATOR >>	HONEYWELL BENDIX	
4019700-904		ATTITUDE DIRECTOR INDICATOR >>	HONEYWELL BENDIX	
4019700-905		ATTITUDE DIRECTOR INDICATOR >>	HONEYWELL BENDIX	
4019700-906		ATTITUDE DIRECTOR INDICATOR >>	HONEYWELL BENDIX	
4019700-907		ATTITUDE DIRECTOR INDICATOR >>	HONEYWELL BENDIX	
4019700-908		ATTITUDE DIRECTOR INDICATOR >>	HONEYWELL BENDIX	
4020577-3	CD-14D	DIRECTIONAL GYRO	HONEYWELL	
4020577-6	CD-14D	DIRECTIONAL GYRO	HONEYWELL	
4020577-8	CD-14D	DIRECTIONAL GYRO	HONEYWELL	
4020917-901	AD-300E	ATTITUDE DIRECTOR INDICATOR	HONEYWELL	
4024130-903	NO MODEL #	RAT THUST RATIG IND	HONEYWELL	
40400-105		PNEUMATIC ALTIMETER	KOLLSMAN	
4050270-903	RD-800K	HORIZON SITUATION INDICATOR	HONEYWELL	
40-817		WHELL SPEED TRANSDUCER	CRANE	
40D33-1		DIFERENCIAL PRESSURE SWITCH		
42074		IGNITION EXCITER	SIMMONDS PRESITIO	
4-245-02	ST282T002-2	BATTERY CHARGER	CRANE ELDEC	
42721		IGNITION EXCITER	UNISION	
42D107A1		DIFERENCIAL PRESSURE SWITCH	CUSTOM CONTROL S	
42D109-1A	7958522-507	PRESSURE SWITCH	CUSTOM CONTROL	
42D110	NO MODEL\$	PRESS SWITCH	CUSTOM COMPONEN	
42D185		PRESSURE SWITCH		
43932-052		ALTIMETER >>	KOLLSMAN	
44387		IGNITION EXCITER	UNISION	
44906		IGNITION EXCITER	UNISION	
44933-1	NO MODEL#	IGNITION EXITER	UNISION	
45-0057-1	NO MODEL#	LANDING LIGHT	HONEYWELL	
45-0350-3-2	NO MODEL#	RETRACTABLE LANDING LIGHT	GIMES	
45D16-1	NO MODEL#	DIFFERENCIAL PRESSURE SWITCH	CUSTOM CONTROL	
45D31	NO MODEL#	PRESSURE SWITCH	CUSTOM	
46650-001		FUEL FLOW INDICATOR >>	KOLLSMAN	
46650-002		FUEL FLOW INDICATOR >>	KOLLSMAN	
467-0001-1	NO MODEL#	COFFEE MAKER	B/E AEROSPACE	
473597-4-07	NO MODEL #	SMOKE DETECTOR	KIDD AEROSPACE	
473597-5	NO MODEL#	SMOKER DETECTOR	KIDDE AEROSPACE	
48016		IGNITION EXCITER	UNISION	
49965		IGNITION EXCITER	SIMMONDS PRECISIO	
49988		IGNITION EXCITER	SIMMONDS PRECISIO	
500	500 SERIES	HORIZON INDICATOR	AIM	
501-1160-01	VG-240	DISPLACEMENT GYROSCOPE	BF GOODRICH	
501-1657-02	ADI-333B	ATTITUD INDICATOR	L3 COMUNICATION	
501-1682-01	PS-834A	EMERGENCY POWER SUPPLY	L3 COMMUNICATIONS	
501-1682-02	PS-834B	POWER SUPPLY	L3 COMMU8NICATION	
50233-4	50233-4	PRESSURE INDICATOR	KRATOS	
5035P-P22	NO MODEL#	ENCODING ALTIMETER	UNITED CONTROL	
504-0002-920	500E-2C	ATTITUDE INDICATOR	BF GOODRICH	
504-0010-904	500DCF(28)	HORIZON REFERENCE INDICATOR	BF GOODRICH	
504-0017-913	510-17A	ATTITUD GYRO	BF GOODRICH	
504-0017-930	510-1K	ATTITUD GYROS	BF GOODRICH	
5040033930	305-2BL	ATTITUD HORIZON	BF GOODRICH	
509-001-909	TS-200-2B	TURN AND SLIP INDICATOR	BC GOODRICH	

06-08-202

Uniserv Aviation, Inc.

Rev#: 20

Capability List

<u>PART NUMBER:</u>	<u>MODEL/TYPE:</u>	<u>DESCRIPTION:</u>	<u>MANUFACTURER:</u>	<u>Rev#</u>
510	510 SERIES	ATTITUDE GYRO	AIM	
510784-1	510784-1	ENG PRESS RATIO IND	GARRETT	
5107841-7-1	510784-7-1	ENG PRESS RATIO IND	GARRETT	
510784-5-1	510784-5-1	ENG PRESS RATIO IND	GARRETT	
510784-6-1	510784-6-1	ENG PRESS RATIO IND	GARRETT	
51530-001		DC GENERATOR CONTROL UNIT	LUCAS AEROSPACE	
51530-001A		DC GENERATOR CONTROL UNIT	LUCAS AEROSPACE	
51530-001E		DC GENERATOR CONTROL UNIT	LUCAS AEROSPACE	
51530-001EI		DC GENERATOR CONTROL UNIT	LUCAS AEROSPACE	
51530-006	51530	D.C .GENERATOR CONTROL UNIT	LEAR SIEGLER	
51530-007B	51530-007	D.C.GENERATOR CONTROL UNIT	LUCAS AEROSPACE	
520104		AC AMMETER >>	AMETEK	
520108		AC AMMETER >>	AMETEK	
520109		AC AMMTER >>	AMETEK	
520127		AC VOLTMETER >>	AMETEK	
520415	1822-202LW	AC VOLTMETER >>	AMETEK	
520479		AC VOLTMETER >>	AMETEK	
520577	1822-220LW	OIL TEMPERATURE INDICATOR >>	AMETEK	
520580	1822-206LW	TACHOMETER APU INDICATOR >>	AMETEK	
520642	1837-201LW	SURFACE POSITION INDICATOR >>	AMETEK	
520750	1822-97LW	TEMPERATURE INDICATOR >>	AMETEK	
521159	1822-214LW	GAS TEMPERATURE APU INDICATOR >>	AMETEK	
521201	1822-226LW	OIL TEMPERATURE INDICATOR >>	AMETEK	
521-29007-202	521-29007	ENCODING ALTIMETER	INTERCONTINENTAL	
521389	1822-124LW	AIR TEMPERATURE INDICATOR >>	AMETEK	
521677	1812-11LW	TRIM AIELERON INDICATOR >>	AMETEK	
521679	1812-12LW	TRIM RUDDER INDICATOR >>	AMETEK	
521701	1812-14LW	OIL TEMPERATURE INDICATOR >>	AMETEK	
521874	1822-118LW	WATT/VAR INDICATOR >>	AMETEK	
522-0690-003	331C-4	DISTANCE HEADING IND **	COLLINS	
522-0974-003	331C-4A	DISTANCE HEADING IND **	COLLINS	
522105	1812-18LW	OIL TEMPERATURE INDICATOR >>	AMETEK	
522-1771-003	331C-4E	DISTANCE HEADING IND **	COLLINS	
522-1859-003	339D-1	DISTANCE INDICATOR >>	COLLINS	
522-1859-013	339D-1	DISTANCE INDICATOR >>	COLLINS	
522-1859-023	339D-1	DISTANCE INDICATOR >>	COLLINS	
522-1859-033	339D-1	DISTANCE INDICATOR >>	COLLINS	
522-1859-043	339D-1	DISTANCE INDICATOR >>	COLLINS	
522-1859-053	339D-1	DISTANCE INDICATOR >>	COLLINS	
522-1859-063	339D-1	DISTANCE INDICATOR >>	COLLINS	
522-1859-064	339D-1	DISTANCE INDICATOR >>	COLLINS	
522-1859-065	339D-1	DISTANCE INDICATOR >>	COLLINS	
522-1859-066	339D-1	DISTANCE INDICATOR >>	COLLINS	
522-1859-067	339D-1	DISTANCE INDICATOR >>	COLLINS	
522-1859-068	339D-1	DISTANCE INDICATOR >>	COLLINS	
522-1859-069	339D-1	DISTANCE INDICATOR >>	COLLINS	
522-1859-070	339D-1	DISTANCE INDICATOR >>	COLLINS	
522-1859-071	339D-1	DISTANCE INDICATOR >>	COLLINS	
522-2604-003	339D-1A	DISTANCE INDICATOR >>	COLLINS	
522-2604-013	339D-1A	DISTANCE INDICATOR >>	COLLINS	
522-2604-023	339D-1A	DISTANCE INDICATOR >>	COLLINS	

06-08-202

Uniserv Aviation, Inc.

Rev#: 20

Capability List

<u>PART NUMBER:</u>	<u>MODEL/TYPE:</u>	<u>DESCRIPTION:</u>	<u>MANUFACTURER:</u>	<u>Rev#</u>
522-2604-024	339D-1A	DISTANCE INDICATOR >>	COLLINS	
522-2604-025	339D-1A	DISTANCE INDICATOR >>	COLLINS	
522-2604-026	339D-1A	DISTANCE INDICATOR >>	COLLINS	
522-2638-000	331A-3G	COURSE INDICATOR **	COLLINS	1
522-2638-003	331A-3G	COURSE INDICATOR **	COLLINS	
522-2638-006	331A-3G	COURSE INDICATOR **	COLLINS	
522-2643-000	323A-3G	FLUX DETECTOR **	COLLINS	
522-2644-000	328A-3G	SLAVING ACCESSORY **	COLLINS	
522-2644-001	328A-3G	SLAVING ACCESSORY **	COLLINS	
522-2644-011	328A-3G	SLAVING ACCESSORY **	COLLINS	
522-2644-013	328A-3G	SLAVING ACCESSORY **	COLLINS	
522-2919-003	339D-3B	DISTANCE INDICATOR >>	COLLINS	
522-2919-013	339D-3B	DISTANCE INDICATOR >>	COLLINS	
522-2919-015	339D-3B	DISTANCE INDICATOR >>	COLLINS	
522-2919-016	339D-3B	DISTANCE INDICATOR >>	COLLINS	
522-2920-003	522-2920	DISTANCE INDICATOR >>	COLLINS	
522-3082-000	331A-3F	COURSE INDICATOR **	COLLINS	
522-3082-001	331A-3F	COURSE INDICATOR **	COLLINS	
522-3082-002	331A-3F	COURSE INDICATOR **	COLLINS	
522-3206-004	329-7A	FLIGHT DIRECTOR INDICATOR	COLLINS	
522-3241-000	332E-4	DIRECTIONAL GYRO **	COLLINS	
522327	1829-18LW	VALVE POSITION INDICATOR >>	AMETEK	
522-3340-025		DISTANCE INDICATOR >>	COLLINS	
522-3342-002	331A-6E	COURSE INDICATOR	COLLINS	
522-3343-000	339D-3D	DISTANCE INDICATOR >>	COLLINS	
522-3343-011	339D-3D	DISTANCE INDICATOR >>	COLLINS	
522-3343-013	339D-3D	DISTANCE INDICATOR >>	COLLINS	
522-3343-023		DISTANCE INDICATOR >>	COLLINS	
522-3343-024		DISTANCE INDICATOR >>	COLLINS	
522-3343-026		DISTANCE INDICATOR >>	COLLINS	
522-3487-002	329-7C	FLIGHT DIRECTOR INDICATOR **	COLLINS	
522-3487-007	329-7C	FLIGHT DIRECTOR INDICATOR	COLLINS	
522349		AC AMMETER >>	AMETEK	
522-3700-004	329-8A	FLIGHT DIRECTOR INDICATOR	COLLINS	
522-3875-001	331A-6K	COURSE INDICATOR	COLLINS	
522-3908-001	329B7M	FLIGHT DIRECTOR INDICATOR	COLLINS	
522-3985-001	332D-11A	VERTICAL REFERENCE **	COLLINS	
522-4114-003	339H-1	RADIO ALTITUDE INDICATOR	ROCKWELL	
522-4141-06	339H1	RADIO ALTITUDE INDICATOR	COLLINS	
522-4363-002	339H-1B	RADIO ALTITUDE INDICATOR	COLLINS	
522-4430-001	329B-8F	FLIGHT DIRECTOR INDICATOR **	COLLINS	
522-4430-002	3298F	FLIGHT DIRECTOR INDICATOR **	COLLINS	
522-4430-005	329-8F	FLIGHT DIRECTOR INDICATOR **	COLLINS	
522-4504-001	339H-1C	RADIO ALTITUDE INDICATOR	COLLINS	
522-4825-002	339H-2	RADIO ALTITUDE INDICATOR	ROCKWELL INDICATO	
522-4825-008	339H-2	RADIO ALTITUDE INDICATOR	COLLINS	
522-4945-001	323A-2G	FLUX DETECTOR **	COLLINS	
522561	1822-344LW	TEMPERATURE INDICATOR >>	AMETEK	
522690	1829-18L	VALVE POSITION INDICATOR >>	AMETEK	
522794	1825-105LW	OIL TEMPERATURE INDICATOR >>	AMETEK	
522795		OIL TEMPERATURE INDICATOR >>	AMETEK	

06-08-202

Uniserv Aviation, Inc.

Rev#: 20

Capability List

<u>PART NUMBER:</u>	<u>MODEL/TYPE:</u>	<u>DESCRIPTION:</u>	<u>MANUFACTURER:</u>	<u>Rev#</u>
522796	1825-107LW	HYDRAULIC PRESSURE INDICATOR >>	AMETEK	
522823	1822-371LW	TORQUE INDICATOR >>	AMETEK	
522834	1837-211LW	TRIM POSITION INDICATOR >>	AMETEK	
522861		INTER TURBINE TEMPERATURE INDICATOR >>	AMETEK	
522948	1822-377LW	TORQUE INDICATOR >>	AMETEK	
523250	1825-130LW	HYDRAULIC PRESSURE INDICATOR >>	AMETEK	
523347		INTER TURBINE TEMPERATURE INDICATOR >>	AMETEK	
523402		INTER TURBINE TEMPERATURE INDICATOR >>	AMETEK	
523466		INTER TURBINE TEMPERATURE INDICATOR >>	AMETEK	
523535		OIL TEMPERATURE INDICATOR >>	AMETEK	
5426-214-8		THERMOMETRIC INDICATOR	THALES	
5426-215-8		THERMOMETRIC INDICATOR	THALLES	
5426-216-8		THERMOMETRIC INDICATOR	THALES	
5502636-1	ET-B4	TD AMPLIFIER CONTROL	HONEYWELL BENDIX	
5502636-2	ET-B4	TD AMPLIFIER CONTROL	HONEYWELL BENDIX	
5550-7070-1		TURN AND SLIP INDICATOR	GENERAL DESIGN	
570-23932	570-23932	PNEUMATIC ALTIMETER	I D C	
570-23932-516	NO MODEL#	ALTIMETER	IDC	
570-23932-919		PNEUMATIC ALTIMETER >>	KOLLSMAN	
570-23932-920		PNEUMATIC ALTIMETER >>	KOLLSMAN	
570-33934-919		PNEUMATIC ALTIMETER >>	KOLLSMAN	
570-33934-920		PNEUMATIC ALTIMETER >>	KOLLSMAN	
570-487	NO MODEL#	FRECUENCY METER	HICKOK	
581AK	NO MODEL#	PITOT TUBE	ROSEMOUNT AEROSP	
5934P-1	5934	PRESSURE ALTIMETER	UNITED INSTRUMENT	
5934P-3		PRESSURE ALTIMETER	UNITED INSTRUMENT	
6002089-1	NO MODEL#	BRAKE TEMP MONITOR		
60-0304-31	NO MODEL #	BATTERY POWER SUPPLY	HONEYWELL	
60-0304-51	NO MODEL#	BATTERY POWER SUPPLY	HONEYWELL	
60-1177-7	NO MODEL#	BATTERY POWER SUPPLY	GRIMES AEROSPACE	
60-1177-9		BATTERY POWER SUPPLY	HONEYWELL	
60-1321-1	NO MODEL#	BATTERY POWER SUPPLY **	HONEYWELL GRIMES	
60-1321-1LB	60-1321-1LB	BATTERY POWER SUPPLY **	HONEYWELL GRIMES	
60-1321-5	60-1321-5	BATTERY POWER SUPPLY **	HONEYWELL GRIMES	
60-1321-5LB	60-1321-5LB	BATTERY POWER SUPPLY **	HONEYWELL GRIMES	
60-1750-3		GRIME STROBE LIGTH	GRIMES	
60-3550-1		BATTERY POWER SUPPLY	GRIMES HONEYWELL	
607510-3		CONTROL TEMPERATURE	HONEYWELL	
607518-1		TEMPERATURE CONTROL	HONEYWELL	
607518-2		TEMPERATURE CONTROL	HONEYWELL	
607518-3		TEMPERATURE CONTROL	HONEYWELL	
607518-4		TEMPERATURE CONTROL	HONEYWELL	
60B40141-4	NO MODEL #	FUEL FLOW INDICATOR	GE	
61-0478-1		BATTERY ASSEMBLY	HONEYWELL GRIMES	
61-0478-9	61-0478-9	BATTERY ASSEMBLY **	HONEYWELL GRIMES	
610BL24B		ELECTRIC RESISTANCE THERMOMETER >>	HORIZON AEROSPAC	
610BL29		ELECTRIC RESISTANCE THERMOMETER >>	HORIZON AEROSPAC	
610BL3		ELECTRIC RESISTANCE THERMOMETER >>	HORIZON AEROSPAC	

06-08-202

Uniserv Aviation, Inc.

Rev#: 20

Capability List

<u>PART NUMBER:</u>	<u>MODEL/TYPE:</u>	<u>DESCRIPTION:</u>	<u>MANUFACTURER:</u>	<u>Rev#</u>
610BL3B		ELECTRIC RESISTANCE THERMOMETER >>	HORIZON AEROSPAC	
610BL4		ELECTRIC RESISTANCE THERMOMETER >>	HORIZON AEROSPAC	
610BL4B		ELECTRIC RESISTANCE THERMOMETER >>	HORIZON AEROSPAC	
610BL4D		ELECTRIC RESISTANCE THERMOMETER >>	HORIZON AEROSPAC	
610BL4E		ELECTRIC RESISTANCE THERMOMETER >>	HORIZON AEROSPAC	
610BL4H		ELECTRIC RESISTANCE THERMOMETER >>	HORIZON AEROSPAC	
610BL9		ELECTRIC RESISTANCE THERMOMETER >>	HORIZON AEROSPAC	
613260-3	DG-224	DIRECTIONAL GYROSCOPE **	HONEYWELL BENDIX	
614937-10	614937	COMPAS SYSTEM RACK	HONEYWELL	1
614937-101	614937-101	COMPAS SYSTEM RACK	HONEYWELL	1
614937-11	614937	COMPAS SYSTEM RACK	HONEYWELL	1
617-1	NO MODEL#	WINDSHIELD TEMPERATURE CONTROLLER	PRIMEX AEROSPACE	
617908	S-3B	DIRECTIONAL GYRO CONTROL **	HONEYWELL BENDIX	
622-0555-001	332C-10	RADIO MAGNETIC INDICATOR **	COLLINS	
622-0555-002	332C-10	RADIO MAGNETIC INDICATOR **	COLLINS	
622-0555-003	332C-10	RADIO MAGNETIC INDICATOR **	COLLINS	
622-0555-004	332C-10	RADIO MAGNETIC INDICATOR **	COLLINS	
622-0555-005	332C-10	RADIO MAGNETIC INDICATOR **	COLLINS	
622-0555-006	332C-10	RADIO MAGNETIC INDICATOR **	COLLINS	
622-0555-008	332C-10	RADIO MAGNETIC INDICATOR **	COLLINS	
622-0944-003	614E-20R	FLIGHT MODE SELECTOR **	COLLINS	
622-0945-003	614E-23R	FLIGHT MODE SELECTOR **	COLLINS	
622-0950-002	614E-37	FLIGHT MODE SELECTOR **	COLLINS	
622-3915-001	IND-40	DME INDICATOR	COLLINS	
622-4096-001	346-2B	PASSENGER ADDRESS	COLLINS	
622-4298-001	HIS-45	HORIZONTAL SITUATION INDICATOR	COLLINS	
622-4424-001	332D-11V	VERTICAL REFERENCE **	COLLINS	
622-4465-002	332D-11T	VERTICAL REFERENCE **	COLLINS	
622-4487-001	346D-2	PASSENGER ADDRESS AMPLIFIER	COLLINS	
622-4488-001	332D-11B	VERTICAL REFERENCE **	COLLINS	
622-4507-001	ADI-55V-2	ATTITUDE DIRECTOR	COLLINS	
622-4565-001	332D-11T	VERTICAL REFERENCE **	COLLINS	
622-4565-002	332D11T	VERTICAL REFERENCE **	COLLINS	
622-5002-701	RMI-703	RADIO MAGNETIC INDICATOR	COLLINS	
622-5374-002	S241T120-1	AUTOLAND ANNUNCIATOR	COLLINS	
622-8001-350	NO MODEL#	EFIS PANEL	COLLINS	
64040-860-1	NO MODEL#	AIRSPEED INDICATOR	THALES	
64040-863-1	NO MODEL#	AIRSPEED INDICATOR	THALES	
643-24-10P	643-24-10P	CLOCK	WAKMANN	
6501-1039	035A-986418-40	SINGLE TACHOMETER INDICATOR	INSCO	
65-24917-137	65-24917	AUTOPILOT ACCESSORY UNIT	BOEING	
65-24917-194	65-24917	AUTOPILOT ACCESSORY UNIT	BOEING	
652525-9	N MODEL #	OIL PRESSURE SWITCH	ALLIED SIGNAL	
65-40180-1	65-40180-1	PUBLIC ADDRESS ACCY UNIT	BOEING	
65-40180-5	65-40180-5	PUBLIC ADDRESS ACCY UNIT	BOEING	
65-52803-1		WINDOW HEAT ACCESSORY UNIT	BOEING	
65-52803-8		WINDOW HEAT ACCESSORY UNIT	BOEING	
65-52809-15	65-52809-15	FIRE DETECTION UNIT	BOEING	
65-52810-25	65-52810	AIR CONDITIONING ACCESSORY UNIT	BOEING	
65-52810-28	65-52810-28	AIR CONDITION ACCESSORY UNIT	BOEING	
65-52810-50	65-52810-50	ACCESSORY UNIT ASSY	BOEING	

06-08-202

Uniserv Aviation, Inc.

Rev#: 20

Capability List

<u>PART NUMBER:</u>	<u>MODEL/TYPE:</u>	<u>DESCRIPTION:</u>	<u>MANUFACTURER:</u>	<u>Rev#</u>
65-52810-6	65-52810-6	AIR CONDITION ACCESSORY UNIT	BOEING	
65-52811-111		LANDING GEAR ACCESSORY UNIT	BOEING	
65B42317-1	NO MODEL #	PANEL	BAE SYSTEM	
65C33409-1	NO MODEL#	DIMMING RELAY MODULE	BOEING	
660-1-000	0-1551/APN	AURAL TONE GENERATOR	HARMAN SYSTEM	
660-1-000-2	0-1551	AURAL TONE GENERATOR	HARMAN SYSTEM	
661102	661102	PHASE ADAPTER **	HONEYWELL BENDIX	
673447	S-3A	DIRECTIONAL GYRO CONTROL **	HONEYWELL BENDIX	1
683478-1	NO MODEL#	THERMAL SWITCH	HONEYWELL	
683478-1-1	NO MODEL #	THERMAL SWITCH	HONEYWELL	
69-17317-1	69-17317-1	PITOT STATIC HEAT MODULE ASSY	BOEING	
69-17317-10	69-17317-10	PITOT STATIC HEAT MODULE ASSY	BOEING	
69-17317-11	69-17317-11	PITOT STATIC HEAT MODULE ASSY	BOEING	
69-17317-12	69-17317-12	PITOT STATIC HEAT MODULE ASSY	BOEING	
69-17317-13	69-17317-13	PITOT STATIC HEAT MODULE ASSY	BOEING	
69-17317-14	69-17317-14	PITOT STATIC HEAT MODULE ASSY	BOEING	
69-17317-2	69-17317-2	PITOT STATIC HEAT MODULE ASSY	BOEING	
69-17317-3	69-17317-3	PITOT STATIC HEAT MODULE ASSY	BOEING	
69-17317-4	69-17317-4	PITOT STATIC HEAT MODULE ASSY	BOEING	
69-17317-6	69-17317-6	PITOT STATIC HEAT MODULE ASSY	BOEING	
69-17317-7	6917317-7	PITOT STATIC HEAT MODULE ASSY	BOEING	
692525-7	NO MODEL #	OIT PRESSURE	ALILIED -SIGNAL	
692525-9		OIL PRESSURE SWITCH	ALLIED SIGNAL	
69-3717-36	69-3717-36	HYD PUMP MOD.	BOEING	
69-37314-12		AC SYSTEM GEN AND APU UNIT	BOEING	
69-37314-19		AC SYSTEM GEN AND APU MODULE	BOEING	
69-37315-32	69-37315-32	GENERATOR STAMBY CONTRO	BOEING	
69-37315-37	69-37315-37	GENERATOR STAMBY UNIT	BOEING	
69-37315-52	69-37315-52	GENERATOR STAMBY CONTROL	BOEING	
69-37315-70	69-37315-70	GENERATOR STAMBY CONTROL	BOEING	
69-37317-14		HYDRAULIC PUMPS MODULE ASSEMBLY	BOEING	
69-37317-20	69-37317-20	HYD. PUMP MOD	BOEING	
69-37317-55	69-37317-55	HYD PUMP MOD	BOEING	
69-37317-84		HYDRAULIC PUMPS MODULE ASSEMBLY	BOEING	
69-37319-125		AIR CONDITIONING MODULE ASSEMBLY	BOEING	
69-37319-145		AIR CNODITIONING MODULE ASSEMBLY	BOEING	
69-37319-189		AIR CONDITIONING MODULE ASSEMBLY	BOEING	
69-37319-301		AIR CONDITIONING MODULE ASSEMBLY	BOEING	
69-37321-30		ELECTRIC METER ASSY	BOEING	
69-37321-5		ELECTRIC METER ASSY	BOEING	
69-37335-129	NO MODEL#	MODULE ASSY FUEL SYSTEM	BAES SYSTEMS	
69-37335-31		FUEL SYSTEM MODULE	BOEING	
69-37335-67		FUEL SYSTEM MODULE ASSEMBLY	BOEING	
69-55179-53		IND.LIGHT DIMMING MODULE	BOEING	
698430-1	1G259-1	PRESURE SWITCH	CUSTOM COMPONEN	
698430-2	1G259-2	PRESSURE SWITCH	CSTOM COMPONENT	
7000622-901	7000622-901	VERTICAL GYRO **	HONEYWELL BENDIX	
7001179-952	RD-550A	HORIZON SITUATION INDICATOR	HONEYWELL	
70-0366-7	NO MODEL#	BALLAST	HONEYWELL	
700662	10-61433-1	LOAD CONTROL	SUNDSTRAND	
701363	NO MODEL#	STROBE LIGHT	BFGOODRICH	

06-08-202

Uniserv Aviation, Inc.

Rev#: 20

Capability List

<u>PART NUMBER:</u>	<u>MODEL/TYPE:</u>	<u>DESCRIPTION:</u>	<u>MANUFACTURER:</u>	<u>Rev#</u>
702084	NO MODEL#	LIGHT AND POWER SUPPLY	HOSKINS	
702242	NO MODEL #	STROBE LIGH	HOSKINS	
702495	NO MODEL#	STROBE LIGHT	HOSKINS	
702496	NO MODEL#	STROBE LIGHT	GOODRICH	
702536	NO MODEL#	STROBE LIGHT	BFGOODRICH	
705-15V10	705-15V10	GYROSCOPIC HORIZON	SFENA	
705-15V1M1	705-15V1M1	GYROSCOPIC HORIZON	THALES	
705-15V3	705-15V3	GYROSCOPIC HORIZON	SFENA	
705-15V4	705-15V4	GYROSCOPIC HORIZON	SFENA	
705-15V9	705-15V9	GYROSCOPIC HORIZON	SFENA	
705-16V3		GYROSCOPIC HORIZON	THALES	
705-19	705-19	GYROSCOPIC HORIZON	SFENA	
705-7V4	705-7V4	GYROSCOPIC HORIZON	THALES	
705-7V42M1	705-7V42M1	GYROSCOPIC HORIZON	THALES	
705-7V4M1	705-7V4M1	GYROSCOPIC HORIZON	THALES	
705-7V7	NO MODEL#	GYROSCOPIC HORIZON	SFENA	
705-7V81	705-7V81	GYROSCOPIC HORIZON	SFENA	
705-7V81M1	705-7V81M1	GYROSCOPIC HORIZON	SFENA	
705-7V91	705-7V91	GYROSCOPIC HORIZON	SEXTANT	
705-7V91M1	705-7V91M1	GYROSCOPIC HORIZON	SEXTANT	
705-7V92M1	705-7V92M1	GYROSCOPIC HORIZON	SFENA	
705-7V9M1	705-7V9M1	GYROSCOPIC HORIZON	SEXTANT	
711002-3		PRESSURE CONTROL PANEL	HAMILTON SUNDSTRA	
711002-4				
711002-5	PSL102-1	PRESSURE CONTROL PANEL	HAMILTON SUNDSTRA	
7237-3B-14-A1		FLIGHT PATH DEVIATION INDICATOR >>	HONEYWELL BENDIX	
7237-3B-14-B1		FLIGHT PATH DEVIATION INDICATOR >>	HONEYWELL BENDIX	
7609-37-M5-2		PRESSURE TRNSMITER	BENDIX	
7609-37M5-2		PRESSURE TRANSMITER	BENDIX	
764805	764805	TANK UNITS	INTERTECHNIQUE	
766804	766804	TANK UNITS	INTERTECHNIQUE	
772-5005-005	329-8J	FLIGHT DIRECTOR INDICATOR **	COLLINS	
772-5005-009	329B-8J	FLIGHT DIRECTOR INDICATOR	COLLINS	
772-5025-001	331A-8A	HORIZON SITUATION INDICATOR	COLLINS	
7725025-001				
772-5025-008	331A-8A	HORIZON SITUATION IND	COLLINS	
772-5431-001	329B-8N	FLIGHT DIRECTOR INDICATOR	COLLINS	
792-6091-015	331A-9G	HORIZONTAL SITUATION INDICATOR	COLLINS	
792-6694-001	332D-11A	VERTICAL REFERENCE **	COLLINS	
792-6781-03	334C-1	SERVO MOTOR	COLLINS	
794167-1	794167-1	TANK UNITS	INTERTECHNIQUE	
7958522-507	42D109-1A	DIFERENCIAL PRESSURE SWITCH	CUSTOM CONTRO	
797-6694-002	332D-11A	VERTICAL REFERENCE **	COLLINS	
7977-01	7977-01	TRANS CONTROL SURFACE	CLIFTON	
7977-05-01	7977-05-01	TRANS CONTROL SURFACE	CLIFTON	
7977-18-01	60B40042-3	TRANS CONTROL SURFACE	CLIFTON	
803900-1	EMBC250	BATTERY POWER SUPPLY	ENGINEERED MAGNE	
8047/10	8047/10	2-INCH COUNTER-POINTER ALTIMETER	FLIGHTLINE AIRCRAF	
8047/10B	8047/10B	2 INCH COUNTER-POINTER ALTIMETER	AERO MECHANISM	
8047/10DHB	8047/10DHB	2 INCH COUNTER-POINTER ALTIMETER	AERO MECHANISM	
8047/20	8047/20	2 INCH COUNTER-POINTER ALTIMETER	AERO MECHANISM	

06-08-202

Uniserv Aviation, Inc.

Rev#: 20

Capability List

<u>PART NUMBER:</u>	<u>MODEL/TYPE:</u>	<u>DESCRIPTION:</u>	<u>MANUFACTURER:</u>	<u>Rev#</u>
8047/20A	8047/20A	2 INCH COUNTER-POINTER ALTIMETER	AERO MECHANISM	
8047/20B	8047/20B	2 INCH COUNTER- POINTER ALTIMETER	AERO MECHANISM	
8047/20DH	8047/20DH	2-INCH COUNTER-POINTER ALTIMETER	AERO MECHANISM	
8047/20DHB	8047/20DHB	2-INCH COUNTER-POINTER ALTIMETER	AERO MECHANISM	
8048	8048	2-INCH COUNTER-POINTER ALTIMETER	AERO MECHANISM	
8048/1	8047/1	2-INCH COUNTER-POINTER ALTIMETER	AERO MECHANISM	
8059-2		AIRSPPEED INDICATOR	FLIGHTLINE AIRCRAF	
8059-2B		AIRSPPEED INDICATOR	FLIGHTLINE AIRCRAF	
831S-G-250-20R		PRESSURE TRANSDUCER	SPARTON TECHNOLO	
851AH		PITOT TUBE		
851AK	NO MODEL#	PITOT TUBE	ROSEMOUNT AEROSP	
851JB	NO MODEL #	PITOT TUBE	ROSEMOUT AEROSPA	
8550-20	NO MODEL#	SMOKE DETECTOR	MEGGITT	
899580-3		IGNITION EXCITER	HONEYWELL	
8AW43AAA217		AC AMMETER/VOLTMETER >>	AMETEK	
8AW43AAA218		AC AMMETER/VOLTMETER >>	AMETEK	
8AW43AAA219		AC AMMETER/VOLTMETER >>	AMETEK	
8AW43AAA220		AC AMMETER/VOLTMETER >>	AMETEK	
8AW43AAA221		AC AMMETER/VOLTMETER >>	AMETEK	
8AW43AAA222		AC AMMETER/VOLTMETER >>	AMETEK	
8AW43AAA223		AC AMMETER/VOLTMETER >>	AMETEK	
8AW43AAA225		AC AMMETER/VOLTMETER >>	AMETEK	
8AW43AAA240		AC AMMETER/VOLTMETER >>	AMETEK	
8AW43AAA245		AC AMMETER/VOLTMETER >>	AMETEK	
8AW43VAA205		AC AMMETER/VOLTMETER >>	AMETEK	
8AW43VAA3		AC AMMETER/VOLTMETER >>	AMETEK	
8AW43VAB1		AC AMMETER/VOLTMETER >>	AMETEK	
8AW43VAB204		AC AMMETER/VOLTMETER >>	AMETEK	
8AW43VAB225		AC AMMETER/VOLTMETER >>	AMETEK	
8AW59FAA1		FREQUENCY METER >>	AMETEK	
8AW59FAC1		FREQUENCY METER >>	AMETEK	
8AW60F1AA1		FREQUENCY METER >>	AMETEK	
8AW60F2AA1		FREQUENCY METER >>	AMETEK	
8AW60LFA1		FREQUENCY METER >>	AMETEK	
8AW60LFD2		FREQUENCY METER >>	AMETEK	
8AW60LFE1		FREQUENCY METER >>	AMETEK	
8AW60LFZ1		FREQUENCY METER >>	AMETEK	
8AW61A1AA1		AC AMMETER-VOLTMETER >>	AMETEK	
8AW61A1AD1		AC LOAD METER/VOLTMETER INDICATOR >>	AMETEK	
8AW61A1AG1		AC AMMETER-VOLTMETER >>	AMETEK	
8AW61A1AH1		AC LOAD METER/VOLTMETER INDICATOR >>	AMETEK	
8AW61A1AR1		AC AMMETER-VOLTMETER >>	AMETEK	
8AW61A1AS1		AC AMMETER-VOLTMETER >>	AMETEK	
8AW61A2AA1		AC AMMETER-VOLTMETER >>	AMETEK	
8AW61LAA1		AC AMMETER-VOLTMETER >>	AMETEK	
8AW61LAA210		AC AMMETER-VOLTMETER >>	AMETEK	
8AW61LAA211		AC AMMETER-VOLTMETER >>	AMETEK	
8AW61LAB1		AC AMMETER-VOLTMETER >>	AMETEK	
8AW61LAC2		AC AMMETER-VOLTMETER >>	AMETEK	
8AW61LAD2		AC AMMETER-VOLTMETER >>	AMETEK	
8AW61LAH1		AC AMMETER-VOLTMETER >>	AMETEK	

06-08-202

Uniserv Aviation, Inc.

Rev#: 20

Capability List

<u>PART NUMBER:</u>	<u>MODEL/TYPE:</u>	<u>DESCRIPTION:</u>	<u>MANUFACTURER:</u>	<u>Rev#</u>
8AW61LAH214		AC AMMETER-VOLTMETER >>	AMETEK	
8AW61LAH215		AC AMMETER-VOLTMETER >>	AMETEK	
8AW61LAH216		AC AMMETER-VOLTMETER >>	AMETEK	
8AW61LAL3		AC LOAD METER/VOLTMETER INDICATOR >>	AMETEK	
8AW61LAM1		AC AMMETER-VOLTMETER >>	AMETEK	
8AW61LAS1		AC LOAD METER/VOLTMETER INDICATOR >>	AMETEK	
8AW61LAT1		AC AMMETER-VOLTMETER >>	AMETEK	
8AW61LAT213		AC AMMETER-VOLTMETER >>	AMETEK	
8AW61LAT221		AC AMMETER-VOLTMETER >>	AMETEK	
8AW61LAZ1		AC AMMETER-VOLTMETER >>	AMETEK	
8AW61LBA1		AC LOAD METER/VOLTMETER INDICATOR >>	AMETEK	
8AW61LVA1		AC AMMETER-VOLTMETER >>	AMETEK	
8AW61LVA218		AC LOAD METER/VOLTMETER INDICATOR >>	AMETEK	
8AW61LVA221		AC AMMETER-VOLTMETER >>	AMETEK	
8AW61LVD211		AC AMMETER-VOLTMETER >>	AMETEK	
8AW61LVD220		AC LOAD METER/VOLTMETER INDICATOR >>	AMETEK	
8AW61LVF1		AC LOAD METER/VOLTMETER INDICATOR >>	AMETEK	
8AW61LVK1		AC AMMETER-VOLTMETER >>	AMETEK	
8AW61LVZ1		AC LOAD METER/VOLTMETER INDICATOR >>	AMETEK	
8AW61V1AA1		AC LOAD METER/VOLTMETER INDICATOR >>	AMETEK	
8AW61V5AA1		AC AMMETER-VOLTMETER >>	AMETEK	
8DJ100WAA1	EHU-15/A	SERVO TEMPERATURE INDICATOR	NAVAIR	
8DJ125GAD2		FLOWMETER INDICATOR >>	AMETEK	
8DJ125GAD3		FLOWMETER INDICATOR >>	AMETEK	
8DJ125GAD4		FLOWMETER INDICATOR >>	AMETEK	
8DJ125LAA2		FLOWMETER INDICATOR >>	AMETEK	
8DJ125LAA3		FLOWMETER INDICATOR >>	AMETEK	
8DJ125LAA4		FLOWMETER INDICATOR >>	AMETEK	
8DJ125LAB2		FLOWMETER INDICATOR >>	AMETEK	
8DJ125LAB3		FLOWMETER INDICATOR >>	AMETEK	
8DJ125LAB4		FLOWMETER INDICATOR >>	AMETEK	
8DJ125LAE4		FLOWMETER INDICATOR >>	AMETEK	
8DJ125LWA1		FLOWMETER INDICATOR >>	AMETEK	
8DJ125LWB2		FLOWMETER INDICATOR >>	AMETEK	
8DJ125LWB3		FLOWMETER INDICATOR >>	AMETEK	
8DJ125LWB4		FLOWMETER INDICATOR >>	AMETEK	
8DJ125LWB5	8DJ125	FUEL FLOW INDICATOR	AMETEK	
8DJ125LWC2		FLOWMETER INDICATOR >>	AMETEK	
8DJ125LWC3		FLOWMETER INDICATOR >>	AMETEK	
8DJ125LWC4		FLOWMETER INDICATOR >>	AMETEK	
8DJ125LWE2		FLOWMETER INDICATOR >>	AMETEK	
8DJ125LWE3		FLOWMETER INDICATOR >>	AMETEK	
8DJ125LWE4		FLOWMETER INDICATOR >>	AMETEK	
8DJ125LWF2		FLOWMETER INDICATOR >>	AMETEK	
8DJ125LWF3		FLOWMETER INDICATOR >>	AMETEK	
8DJ125LWF4		FLOWMETER INDICATOR >>	AMETEK	
8DJ125LWG1		FLOWMETER INDICATOR >>	AMETEK	
8DJ125LWG2		FLOWMETER INDICATOR >>	AMETEK	
8DJ125LWG3		FLOWMETER INDICATOR >>	AMETEK	
8DJ125LWG4		FLOWMETER INDICATOR >>	AMETEK	
8DJ125LWH1		FLOWMETER INDICATOR >>	AMETEK	

06-08-202

Uniserv Aviation, Inc.

Rev#: 20

Capability List

<u>PART NUMBER:</u>	<u>MODEL/TYPE:</u>	<u>DESCRIPTION:</u>	<u>MANUFACTURER:</u>	<u>Rev#</u>
8DJ125LWH2		FLOWMETER INDICATOR >>	AMETEK	
8DJ125LWH3		FLOWMETER INDICATOR >>	AMETEK	
8DJ125LWK2		FLOWMETER INDICATOR >>	AMETEK	
8DJ125LWK3		FLOWMETER INDICATOR >>	AMETEK	
8DJ125LWK4		FLOWMETER INDICATOR >>	AMETEK	
8DJ125LWR3		FLOWMETER INDICATOR >>	AMETEK	
8DJ125LWR4		FLOWMETER INDICATOR >>	AMETEK	
8DJ125LWS3		FLOWMETER INDICATOR >>	AMETEK	
8DJ125LWS4		FLOWMETER INDICATOR >>	AMETEK	
8DJ125LWT3		FLOWMETER INDICATOR >>	AMETEK	
8DJ125LWT4		FLOWMETER INDICATOR >>	AMETEK	
8DJ125LWV3		FLOWMETER INDICATOR >>	AMETEK	
8DJ125LWV4		FLOWMETER INDICATOR >>	AMETEK	
8DJ125LWX3		FLOWMETER INDICATOR >>	AMETEK	
8DJ125LWX4		FLOWMETER INDICATOR >>	AMETEK	
8DJ125LWY3		FLOWMETER INDICATOR >>	AMETEK	
8DJ125LWY4		FLOWMETER INDICATOR >>	AMETEK	
8DJ125LXB3		FLOWMETER INDICATOR >>	AMETEK	
8DJ125LXB4		FLOWMETER INDICATOR >>	AMETEK	
8DJ125LXC3		FLOWMETER INDICATOR >>	AMETEK	
8DJ125LXC4		FLOWMETER INDICATOR >>	AMETEK	
8DJ125LXD4		FLOWMETER INDICATOR >>	AMETEK	
8DJ125LXD5	8DJ125	FUEL FLOW INDICATOR	AMETEK	
8DJ125LXE4		FLOWMETER INDICATOR >>	AMETEK	
8DJ125LXF4		FLOWMETER INDICATOR >>	AMETEK	
8DJ125LXF5	8DJ125	FUEL FLOW INDICATOR	AMETEK	
8DJ125LXG4		FLOWMETER INDICATOR >>	AMETEK	
8DJ125LXG5	8DJ125	FUEL FLOW INDICATOR	AMETEK	
8DJ125LXK3		FLOWMETER INDICATOR >>	AMETEK	
8DJ125LXK4		FLOWMETER INDICATOR >>	AMETEK	
8DJ125LXP3		FLOWMETER INDICATOR >>	AMETEK	
8DJ125LXV5		FUEL FLOW INDICATOR >>	AMETEK	
8DJ125LXW5		FUEL FLOW INDICATOR >>	AMETEK	
8DJ125LXX5		FUEL FLOW INDICATOR >>	AMETEK	
8DJ125LXY5		FUEL FLOW INDICATOR >>	AMETEK	
8DJ125LYA5		FUEL FLOW INDICATOR >>	AMETEK	
8DJ125LYB5		FUEL FLOW INDICATOR >>	AMETEK	
8DJ125MWA4		FLOWMETER INDICATOR >>	AMETEK	
8DJ125MWB4		FLOWMETER INDICATOR >>	AMETEK	
8DJ125MWC4		FLOWMETER INDICATOR >>	AMETEK	
8DJ125MWD4		FLOWMETER INDICATOR >>	AMETEK	
8DJ142GAC2		FLOWMETER INDICATOR >>	AMETEK	
8DJ142GAD2	DJ142	FLOWMETER INDICATOR >>	AMETEK	
8DJ142GAH2	DJ142	FLOWMETER INDICATOR >>	AMETEK	
8DJ142GAT2	DJ142	FLOWMETER INDICATOR >>	AMETEK	
8DJ142GAX2	DJ142	FLOWMETER INDICATOR >>	AMETEK	
8DJ142GBB2	DJ142	FLOWMETER INDICATOR >>	AMETEK	
8DJ142GBC2	DJ142	FLOWMETER INDICATOR >>	AMETEK	
8DJ142GBD2	DJ142	FLOWMETER INDICATOR >>	AMETEK	
8DJ142GBG2	DJ142	FLOWMETER INDICATOR >>	AMETEK	
8DJ142GBL2	DJ142	FLOWMETER INDICATOR >>	AMETEK	

06-08-202

Uniserv Aviation, Inc.

Rev#: 20

Capability List

<u>PART NUMBER:</u>	<u>MODEL/TYPE:</u>	<u>DESCRIPTION:</u>	<u>MANUFACTURER:</u>	<u>Rev#</u>
8DJ142LAA2	DJ142	FLOWMETER INDICATOR >>	AMETEK	
8DJ142LAD2	DJ142	FLOWMETER INDICATOR >>	AMETEK	
8DJ142LAH2	DJ142	FLOWMETER INDICATOR >>	AMETEK	
8DJ142LAS2	DJ142	FLOWMETER INDICATOR >>	AMETEK	
8DJ142LWA2	DJ142	FLOWMETER INDICATOR >>	AMETEK	
8DJ142LWB2	DJ142	FLOWMETER INDICATOR >>	AMETEK	
8DJ142LWE2	DJ142	FLOWMETER INDICATOR >>	AMETEK	
8DJ142LWH2	DJ142	FLOWMETER INDICATOR >>	AMETEK	
8DJ142LWM2	DJ142	FLOWMETER INDICATOR >>	AMETEK	
8DJ142LWN2	DJ142	FLOWMETER INDICATOR >>	AMETEK	
8DJ175LXP2		ENGINE EXHAUST TEMP. IND.	AMETEK	
8DJ177LWN1	8DJ177	TEMPERATURE INDICATOR **	AMETEK	
8DJ177LWP1	8DJ177	TEMPERATURE INDICATOR **	AMETEK	
8DJ177LWR1	8DJ177	TEMPERATURE INDICATOR **	AMETEK	
8DJ177LWS1	8SJ177	TEMPERATURE INDICATOR **	AMETEK	
8DJ177LWV1	8DJ177	TEMPERATURE INDICATOR **	AMETEK	
8DJ177LWW1	8DJ177	TEMPERATURE INDICATOR **	AMETEK	
8DJ177LWX1	8DJ177	TEMPERATURE INDICATOR **	AMETEK	
8DJ181LWC2	8DJ181	ENGINE TORQUE INDICATOR >>	AMETEK	
8DJ181LWD2	8DJ181	ENGINE TORQUE INDICATOR >>	AMETEK	
8DJ64GAF1	8DJ64GAF1	FLOWMETER INDICATOR **	AMETEK	
8DJ64GAS1	8DJ64GAS1	FLOWMETER INDICATOR **	AMETEK	
8DJ64GAT1	8DJ64GAT1	FLOWMETER INDICATOR **	AMETEK	
8DJ64GAX1	8DJ64GAX1	FLOWMETER INDICATOR **	AMETEK	
8DJ64GAB1	8DJ64GAB1	FLOWMETER INDICATOR **	AMETEK	
8DJ64GBC1	8DJ64GBC1	FLOWMETER INDICATOR **	AMETEK	
8DJ77LAC1	8DJ77	FLOWMETER INDICATOR **	AMETEK	
8DJ77LAC2	8DJ77	FLOWMETER INDICATOR **	AMETEK	
8DJ77LAD1	8DJ77	FLOWMETER INDICATOR **	AMETEK	
8DJ77LAD2	8DJ77	FLOWMETER INDICATOR **	AMETEK	
8DJ77LAE1	8DJ77	FLOWMETER INDICATOR **	AMETEK	
8DJ77LAE2	8DJ77	FLOWMETER INDICATOR **	AMETEK	
8DJ77LAF1	8DJ77	FLOWMETER INDICATOR **	AMETEK	
8DJ77LAF2	8DJ77	FLOWMETER INDICATOR **	AMETEK	
8DJ77LAM2	8DJ77	FLOWMETER INDICATOR **	AMETEK	
8DJ77LWB2	8DJ77	FLOWMETER INDICATOR **	AMETEK	
8DJ77LWE2	8DJ77	FLOWMETER INDICATOR **	AMETEK	
8DJ77LWF2	8DJ77	FLOWMETER INDICATOR **	AMETEK	
8DJ77LWH2	8DJ77	FLOWMETER INDICATOR **	AMETEK	
8DJ77LWK2	8DJ77	FLOWMETER INDICATOR **	AMETEK	
8DJ81AAA1		TACHOMETER INDICATOR >>	AMETEK	
8DJ81AAB1		TACHOMETER INDICATOR >>	AMETEK	
8DJ81AAC1		TACHOMETER INDICATOR >>	AMETEK	
8DJ81BAA1		TACHOMETER INDICATOR >>	AMETEK	
8DJ81BLB4		TACHOMETER INDICATOR >>	AMETEK	
8DJ81BLC4		TACHOMETER INDICATOR >>	AMETEK	
8DJ81CAA1		TACHOMETER INDICATOR >>	AMETEK	
8DJ81CAA2		TACHOMETER INDICATOR >>	AMETEK	
8DJ81CAB2		TACHOMETER INDICATOR >>	AMETEK	
8DJ81CAC1		TACHOMETER INDICATOR >>	AMETEK	
8DJ81CAC2		TACHOMETER INDICATOR >>	AMETEK	

06-08-202

Uniserv Aviation, Inc.

Rev#: 20

Capability List

<u>PART NUMBER:</u>	<u>MODEL/TYPE:</u>	<u>DESCRIPTION:</u>	<u>MANUFACTURER:</u>	<u>Rev#</u>
8DJ81CAE1		TACHOMETER INDICATOR >>	AMETEK	
8DJ81CAE2		TACHOMETER INDICATOR >>	AMETEK	
8DJ81CAF1		TACHOMETER INDICATOR >>	AMETEK	
8DJ81CAF2		TACHOMETER INDICATOR >>	AMETEK	
8DJ81CAH1		TACHOMETER INDICATOR >>	AMETEK	
8DJ81CAH2		TACHOMETER INDICATOR >>	AMETEK	
8DJ81CAK1		TACHOMETER INDICATOR >>	AMETEK	
8DJ81CAK2		TACHOMETER INDICATOR >>	AMETEK	
8DJ81CAL1		TACHOMETER INDICATOR >>	AMETEK	
8DJ81CAM1		TACHOMETER INDICATOR >>	AMETEK	
8DJ81CAM2		TACHOMETER INDICATOR >>	AMETEK	
8DJ81CAN1		TACHOMETER INDICATOR >>	AMETEK	
8DJ81CAN2		TACHOMETER INDICATOR >>	AMETEK	
8DJ81CAS2		TACHOMETER INDICATOR >>	AMETEK	
8DJ81CAX2		TACHOMETER INDICATOR >>	AMETEK	
8DJ81CAY2		TACHOMETER INDICATOR >>	AMETEK	
8DJ81CAZ2		TACHOMETER INDICATOR >>	AMETEK	
8DJ81CBA2		TACHOMETER INDICATOR >>	AMETEK	
8DJ81CBB2		TACHOMETER INDICATOR >>	AMETEK	
8DJ81CBK2		TACHOMETER INDICATOR >>	AMETEK	
8DJ81CBX2		TACHOMETER INDICATOR >>	AMETEK	
8DJ81CCK2		TACHOMETER INDICATOR >>	AMETEK	
8DJ81CCL2		TACHOMETER INDICATOR >>	AMETEK	
8DJ81CCM2		TACHOMETER INDICATOR >>	AMETEK	
8DJ81CDC2		TACHOMETER INDICATOR >>	AMETEK	
8DJ81CDE2		TACHOMETER INDICATOR >>	AMETEK	
8DJ81CDH2		TACHOMETER INDICATOR >>	AMETEK	
8DJ81CDY2		TACHOMETER INDICATOR >>	AMETEK	
8DJ81FAA1		TACHOMETER INDICATOR >>	AMETEK	
8DJ81FAA2		TACHOMETER INDICATOR >>	AMETEK	
8DJ81LAA1		TACHOMETER INDICATOR >>	AMETEK	
8DJ81LAA2		TACHOMETER INDICATOR >>	AMETEK	
8DJ81LAA4		TACHOMETER INDICATOR >>	AMETEK	
8DJ81LAB2		TACHOMETER INDICATOR >>	AMETEK	
8DJ81LAC1		TACHOMETER INDICATOR >>	AMETEK	
8DJ81LAC2		TACHOMETER INDICATOR >>	AMETEK	
8DJ81LAD1		TACHOMETER INDICATOR >>	AMETEK	
8DJ81LAD2		TACHOMETER INDICATOR >>	AMETEK	
8DJ81LAE1		TACHOMETER INDICATOR >>	AMETEK	
8DJ81LAE2		TACHOMETER INDICATOR >>	AMETEK	
8DJ81LAK1		TACHOMETER INDICATOR >>	AMETEK	
8DJ81LAK2		TACHOMETER INDICATOR >>	AMETEK	
8DJ81LAN2		TACHOMETER INDICATOR >>	AMETEK	
8DJ81LAT1		TACHOMETER INDICATOR >>	AMETEK	
8DJ81LAT2		TACHOMETER INDICATOR >>	AMETEK	
8DJ81LAV2		TACHOMETER INDICATOR >>	AMETEK	
8DJ81LAW1		TACHOMETER INDICATOR >>	AMETEK	
8DJ81LAW2		TACHOMETER INDICATOR >>	AMETEK	
8DJ81LAX2		TACHOMETER INDICATOR >>	AMETEK	
8DJ81LAY2		TACHOMETER INDICATOR >>	AMETEK	
8DJ81LAZ2		TACHOMETER INDICATOR >>	AMETEK	

06-08-202

Uniserv Aviation, Inc.

Rev#: 20

Capability List

<u>PART NUMBER:</u>	<u>MODEL/TYPE:</u>	<u>DESCRIPTION:</u>	<u>MANUFACTURER:</u>	<u>Rev#</u>
8DJ81LBC2		TACHOMETER INDICATOR >>	AMETEK	
8DJ81LBD2		TACHOMETER INDICATOR >>	AMETEK	
8DJ81LBE2		TACHOMETER INDICATOR >>	AMETEK	
8DJ81LBF2		TACHOMETER INDICATOR >>	AMETEK	
8DJ81LBH2		TACHOMETER INDICATOR >>	AMETEK	
8DJ81LBK2		TACHOMETER INDICATOR >>	AMETEK	
8DJ81LBL2		TACHOMETER INDICATOR >>	AMETEK	
8DJ81LBS2		TACHOMETER INDICATOR >>	AMETEK	
8DJ81LBT2		TACHOMETER INDICATOR >>	AMETEK	
8DJ81LBX2		TACHOMETER INDICATOR >>	AMETEK	
8DJ81LCB2		TACHOMETER INDICATOR >>	AMETEK	
8DJ81LCD2		TACHOMETER INDICATOR >>	AMETEK	
8DJ81LCF2		TACHOMETER INDICATOR >>	AMETEK	
8DJ81LCK2		TACHOMETER INDICATOR >>	AMETEK	
8DJ81LCP4		TACHOMETER INDICATOR >>	AMETEK	
8DJ81LCR4		TACHOMETER INDICATOR >>	AMETEK	
8DJ81LCT4		TACHOMETER INDICATOR >>	AMETEK	
8DJ81LSC4		TACHOMETER INDICATOR >>	AMETEK	
8DJ81LVA4		TACHOMETER INDICATOR >>	AMETEK	
8DJ81LVB4		TACHOMETER INDICATOR >>	AMETEK	
8DJ81LVF4		TACHOMETER INDICATOR >>	AMETEK	
8DJ81LVG4		TACHOMETER INDICATOR >>	AMETEK	
8DJ81LVL4		TACHOMETER INDICATOR >>	AMETEK	
8DJ81LWA1		TACHOMETER INDICATOR >>	AMETEK	
8DJ81LWA2		TACHOMETER INDICATOR >>	AMETEK	
8DJ81LWA4		TACHOMETER INDICATOR >>	AMETEK	
8DJ81LWB2		TACHOMETER INDICATOR >>	AMETEK	
8DJ81LWC2		TACHOMETER INDICATOR >>	AMETEK	
8DJ81LWC4		TACHOMETER INDICATOR >>	AMETEK	
8DJ81LWH2		TACHOMETER INDICATOR >>	AMETEK	
8DJ81LWM2		TACHOMETER INDICATOR >>	AMETEK	
8DJ81LWN2		TACHOMETER INDICATOR >>	AMETEK	
8DJ81LWR2		TACHOMETER INDICATOR >>	AMETEK	
8DJ81LWR4		TACHOMETER INDICATOR >>	AMETEK	
8DJ81LWS2		TACHOMETER INDICATOR >>	AMETEK	
8DJ81LWS4		TACHOMETER INDICATOR >>	AMETEK	
8DJ81LWT2		TACHOMETER INDICATOR >>	AMETEK	
8DJ81LWT4		TACHOMETER INDICATOR >>	AMETEK	
8DJ81LWV2		TACHOMETER INDICATOR >>	AMETEK	
8DJ81LWY2		TACHOMETER INDICATOR >>	AMETEK	
8DJ81LWY4		TACHOMETER INDICATOR >>	AMETEK	
8DJ81LWZ2		TACHOMETER INDICATOR >>	AMETEK	
8DJ81LWZ4		TACHOMETER INDICATOR >>	AMETEK	
8DJ81LXC2		TACHOMETER INDICATOR >>	AMETEK	
8DJ81LXD2		TACHOMETER INDICATOR >>	AMETEK	
8DJ81LXE2		TACHOMETER INDICATOR >>	AMETEK	
8DJ81LXF2		TACHOMETER INDICATOR >>	AMETEK	
8DJ81LXF4		TACHOMETER INDICATOR >>	AMETEK	
8DJ81LXG2		TACHOMETER INDICATOR >>	AMETEK	
8DJ81LXG4		TACHOMETER INDICATOR >>	AMETEK	
8DJ81LXH2		TACHOMETER INDICATOR >>	AMETEK	

06-08-202

Uniserv Aviation, Inc.

Rev#: 20

Capability List

<u>PART NUMBER:</u>	<u>MODEL/TYPE:</u>	<u>DESCRIPTION:</u>	<u>MANUFACTURER:</u>	<u>Rev#</u>
8DJ81LXH4		TACHOMETER INDICATOR >>	AMETEK	
8DJ81LXK2		TACHOMETER INDICATOR >>	AMETEK	
8DJ81LXK4		TACHOMETER INDICATOR >>	AMETEK	
8DJ81LXL2		TACHOMETER INDICATOR >>	AMETEK	
8DJ81LXM2		TACHOMETER INDICATOR >>	AMETEK	
8DJ81LXN2		TACHOMETER INDICATOR >>	AMETEK	
8DJ81LXP2		TACHOMETER INDICATOR >>	AMETEK	
8DJ81LXT2		TACHOMETER INDICATOR >>	AMETEK	
8DJ81LXT4		TACHOMETER INDICATOR >>	AMETEK	
8DJ81LXV2		TACHOMETER INDICATOR >>	AMETEK	
8DJ81LXW2		TACHOMETER INDICATOR >>	AMETEK	
8DJ81LXY2		TACHOMETER INDICATOR >>	AMETEK	
8DJ81LXZ2		TACHOMETER INDICATOR >>	AMETEK	
8DJ81LYA2		TACHOMETER INDICATOR >>	AMETEK	
8DJ81LYB2		TACHOMETER INDICATOR >>	AMETEK	
8DJ81LYC2		TACHOMETER INDICATOR >>	AMETEK	
8DJ81LYP2		TACHOMETER INDICATOR >>	AMETEK	
8DJ81LYP4		TACHOMETER INDICATOR >>	AMETEK	
8DJ81LYT2		TACHOMETER INDICATOR >>	AMETEK	
8DJ81LYT4		TACHOMETER INDICATOR >>	AMETEK	
8DJ81LYV2		TACHOMETER INDICATOR >>	AMETEK	
8DJ81LYV4		TACHOMETER INDICATOR >>	AMETEK	
8DJ81LYW2		TACHOMETER INDICATOR >>	AMETEK	
8DJ81LYX2		TACHOMETER INDICATOR >>	AMETEK	
8DJ81LYX4		TACHOMETER INDICATOR >>	AMETEK	
8DJ81LYZ2		TACHOMETER INDICATOR >>	AMETEK	
8DJ81LZB2		TACHOMETER INDICATOR >>	AMETEK	
8DJ81LZC2		TACHOMETER INDICATOR >>	AMETEK	
8DJ81LZC4		TACHOMETER INDICATOR >>	AMETEK	
8DJ81LZE2		TACHOMETER INDICATOR >>	AMETEK	
8DJ81LZE4		TACHOMETER INDICATOR >>	AMETEK	
8DJ81LZF2		TACHOMETER INDICATOR >>	AMETEK	
8DJ81LZF4		TACHOMETER INDICATOR >>	AMETEK	
8DJ81WAG2		TACHOMETER INDICATOR >>	AMETEK	
8DJ81WAG4		TACHOMETER INDICATOR >>	AMETEK	
8DJ81WAL4		TACHOMETER INDICATOR >>	AMETEK	
8DJ81WAP4		TACHOMETER INDICATOR >>	AMETEK	
8DJ81WAY4		TACHOMETER INDICATOR >>	AMETEK	
8DJ81WBA4		TACHOMETER INDICATOR >>	AMETEK	
8DJ81WBB4		TACHOMETER INDICATOR >>	AMETEK	
8DJ81WBC4		TACHOMETER INDICATOR >>	AMETEK	
8DJ81WBD4		TACHOMETER INDICATOR >>	AMETEK	
8DJ81WBF4		TACHOMETER INDICATOR >>	AMETEK	
8DJ81WBG4		TACHOMETER INDICATOR >>	AMETEK	
8DJ81WBL4		TACHOMETER INDICATOR >>	AMETEK	
8DJ81WBM4		TACHOMETER INDICATOR >>	AMETEK	
8DJ81WBS4		TACHOMETER INDICATOR >>	AMETEK	
8DJ81WBT4		TACHOMETER INDICATOR >>	AMETEK	
8DJ81WCF4		TACHOMETER INDICATOR >>	AMETEK	
8DJ81WCG4		TACHOMETER INDICATOR >>	AMETEK	
8DJ81WCR4		TACHOMETER INDICATOR >>	AMETEK	

06-08-202

Uniserv Aviation, Inc.

Rev#: 20

Capability List

<u>PART NUMBER:</u>	<u>MODEL/TYPE:</u>	<u>DESCRIPTION:</u>	<u>MANUFACTURER:</u>	<u>Rev#</u>
8DJ81WCS4		TACHOMETER INDICATOR >>	AMETEK	
8DJ81WCT4		TACHOMETER INDICATOR >>	AMETEK	
8DJ81WCW4		TACHOMETER INDICATOR >>	AMETEK	
8DJ81WCX4		TACHOMETER INDICATOR >>	AMETEK	
8DJ81WDK4		TACHOMETER INDICATOR >>	AMETEK	
8DJ81WDL4		TACHOMETER INDICATOR >>	AMETEK	
8DJ86LAA1	DJ-86	FLOWMETER INDICATOR **	AMETEK	
8DJ86LAH1	DJ-86	FLOWMETER INDICATOR **	AMETEK	
8DJ88GAC1		FLOWMETER INDICATOR >>	AMETEK	
8DJ88GAJ3		FLOWMETER INDICATOR >>	AMETEK	
8DJ88LAB1		FLOWMETER INDICATOR >>	AMETEK	
8DJ88LAB2		FLOWMETER INDICATOR >>	AMETEK	
8DJ88LAB3		FLOWMETER INDICATOR >>	AMETEK	
8DJ88LWB1		FLOWMETER INDICATOR >>	AMETEK	
8DJ88LWC2		FLOWMETER INDICATOR >>	AMETEK	
8DJ88LWC3		FLOWMETER INDICATOR >>	AMETEK	
8DJ88LWD2		FLOWMETER INDICATOR >>	AMETEK	
8DJ88LWD3		FLOWMETER INDICATOR >>	AMETEK	
8DJ88LWE3		FLOWMETER INDICATOR >>	AMETEK	
8DJ88LWF2		FLOWMETER INDICATOR >>	AMETEK	
8DJ88LWF3		FLOWMETER INDICATOR >>	AMETEK	
8DJ88LWG3		FLOWMETER INDICATOR >>	AMETEK	
8DJ88LWH3		FLOWMETER INDICATOR >>	AMETEK	
8DJ88LWK3		FLOWMETER INDICATOR >>	AMETEK	
8DJ88LWM3		FLOWMETER INDICATOR >>	AMETEK	
8DJ88LWN3		FLOWMETER INDICATOR >>	AMETEK	
8DJ88LWS3		FLOWMETER INDICATOR >>	AMETEK	
8DJ88LWX3		FLOWMETER INDICATOR >>	AMETEK	
8DJ88LWY3		FLOWMETER INDICATOR >>	AMETEK	
8DJ88LXA3		FLOWMETER INDICATOR >>	AMETEK	
8DJ88LXC3		FLOWMETER INDICATOR >>	AMETEK	
8DJ88LYF3		FLOWMETER INDICATOR >>	AMETEK	
8DW53ACB10		DC AMMETER VOLTMETER >>	AMETEK	
8DW53ACB230		DC AMMETER VOLTMETER >>	AMETEK	
8DW53ACC10		DC AMMETER VOLTMETER >>	AMETEK	
8DW53ACC227		DC AMMETER VOLTMETER >>	AMETEK	
8DW53ACC231		DC AMMETER VOLTMETER >>	AMETEK	
8DW53ACF10		DC AMMETER VOLTMETER >>	AMETEK	
8DW53BAC208		VOLTMETER >>	AMETEK	
8DW53BAC216		VOLTMETER >>	AMETEK	
8DW53BAC221		VOLTMETER >>	AMETEK	
8DW53BAD213		VOLTMETER >>	AMETEK	
8DW53BAD224		VOLTMETER >>	AMETEK	
8DW53BAD225		VOLTMETER >>	AMETEK	
8DW53BAD226		VOLTMETER >>	AMETEK	
8DW53BCB220		VOLTMETER >>	AMETEK	
8DW53VBA10		DC AMMETER VOLTMETER >>	AMETEK	
8DW53VBA207		DC AMMETER VOLTMETER >>	AMETEK	
8DW53VBA211		DC AMMETER VOLTMETER >>	AMETEK	
8DW53VBB202		DC AMMETER VOLTMETER >>	AMETEK	
8DW84A18AA1		DC AM/VOL METER >>	AMETEK	

06-08-202

Uniserv Aviation, Inc.

Rev#: 20

Capability List

<u>PART NUMBER:</u>	<u>MODEL/TYPE:</u>	<u>DESCRIPTION:</u>	<u>MANUFACTURER:</u>	<u>Rev#</u>
8DW84A19AA1		DC AM/VOL METER >>	AMETEK	
8DW84A1AA1		DC AM/VOL METER >>	AMETEK	
8DW84A22AA1		DC AM/VOL METER >>	AMETEK	
8DW84A23AA1		DC AM/VOL METER >>	AMETEK	
8DW84A24AA1		DC AM/VOL METER >>	AMETEK	
8DW84A25AA1		DC AM/VOL METER >>	AMETEK	
8DW84A26AA1		DC AM/VOL METER >>	AMETEK	
8DW84A2AA1		DC AM/VOL METER >>	AMETEK	
8DW84A4AA1		DC AM/VOL METER >>	AMETEK	
8DW84A6AA1		DC AM/VOL METER >>	AMETEK	
8DW84A7AA1		DC AM/VOL METER >>	AMETEK	
8DW84LAA1		DC AM/VOL METER >>	AMETEK	
8DW84LAA210		DC AM/VOL METER >>	AMETEK	
8DW84LAA215		DC AM/VOL METER >>	AMETEK	
8DW84LAA216		DC AM/VOL METER >>	AMETEK	
8DW84LAC1		DC AM/VOL METER >>	AMETEK	
8DW84LAC211		DC AM/VOL METER >>	AMETEK	
8DW84LAN1		DC AM/VOL METER >>	AMETEK	
8DW84LAT1		DC AM/VOL METER >>	AMETEK	
8DW84LAY60		DC AM/VOL METER >>	AMETEK	
8DW84LBA1		DC AM/VOL METER >>	AMETEK	
8DW84LVA1		DC AM/VOL METER >>	AMETEK	
8DW84LVA218		DC AM/VOL METER >>	AMETEK	
8DW84LVA221		DC AM/VOL METER >>	AMETEK	
8DW84LVD211		DC AM/VOL METER >>	AMETEK	
8DW84LVD220		DC AM/VOL METER >>	AMETEK	
8DW84LVH1		DC AM/VOL METER >>	AMETEK	
8DW84LVZ1		DC AM/VOL METER >>	AMETEK	
8DW84V1AA1		DC AM/VOL METER >>	AMETEK	
8DW84V3AA1		DC AM/VOL METER >>	AMETEK	
8G441-1	NO MODEL#	PRESSURE SWITCH	CUSTOM	
8KE25GAC1		FLOWMETER AMPLIFIER >>	AMETEK	
8KE25GAD1		FLOWMETER AMPLIFIER >>	AMETEK	
8KE25GAE1		FLOWMETER AMPLIFIER >>	AMETEK	
8KE25GAF1		FLOWMETER AMPLIFIER >>	AMETEK	
8KE25GAN1		FLOWMETER AMPLIFIER >>	AMETEK	
8KE91AAB1		ENGINE TORQUE ELECTRONIC UNIT >>	AMETEK	
8KE91AAB2		ENGINE TORQUE ELECTRONIC UNIT >>	AMETEK	
8TJ51GAA5	8TJ51	FLOMETER POWER SUPPLY **	AMETEK	1
8TJ51GBB5	TJ51	FLOMETER POWER SUPPLY **	AMETEK	1
8TJ88GAC1	8TJ88	POWER SUPPLY **	AMETEK	
8TJ88GAD1		POWER SUPPLY **	AMETEK	
8TJ88GAD3		POWER SUPPLY **	AMETEK	
8TJ88GAE1	8TJ88	POWER SUPPLY **	AMETEK	
8TJ88GAF1	8TJ88	POWER SUPPLY **	AMETEK	
8TJ88GAH3	8TJ88	POWER SUPPLY **	AMETEK	
8TJ88GAN1		POWER SUPPLY **	AMETEK	
8TJ88GAN3		POWER SUPPLY **	AMETEK	
8TJ88GAP1		POWER SUPPLY	GENERAL ELECTRIC	
8TJ88GAP3	8TJ88	POWER SUPPLY **	AMETEK	
8TJ88GAR3	8TJ88	POWER SUPPLY **	AMETEK	

Rev#: 20

Capability List

<u>PART NUMBER:</u>	<u>MODEL/TYPE:</u>	<u>DESCRIPTION:</u>	<u>MANUFACTURER:</u>	<u>Rev#</u>
8TJ88GAV3	8TJ88	POWER SUPPLY **	AMETEK	
8TJ88GBC1	8TJ88	POWER SUPPLY **	AMETEK	
8TJ88GBD1		POWER SUPPLY **	AMETEK	
8TJ88GBD3		POWER SUPPLY **	AMETEK	
8TJ88GBE1	8TJ88	POWER SUPPLY **	AMETEK	
8TJ88GBF1	8TJ88	POWER SUPPLY **	AMETEK	
8TJ88GBN1		POWER SUPPLY **	AMETEK	
8TJ88GBN3		POWER SUPPLY **	AMETEK	
8TJ95GAA1		FLOWMETER POWER SUPPLY	AMETEK	
8TJ95GAB3		FLOWMETER POWER SUPPLY	AMETEK	
9005-2	9005-2	BATTERY PACK	BELL INDUSTRIES	
9005-42	10-61784-4	BATTERY POWER SUPPLY	IDD AEROSPACE COR	
9008-3	9008	BATTERY POWER SUPPLY	IDD AEROSPACE	
9008-3-5A		BATTERY ASSEMBLY	HONEYWELL GRIMES	
9008-4	9008-4	BATTERY POWER SUPPLY	IDD AEROSPACE	
9008D09-1	AVB79A	RELAY	HAMILTON SUNSTRAND	
9008D09-2	AVB79A	POWER RELAY	HAMILTON SUNSTRAN	
9008D09-3	AVB79A	POWER RELAY	HAMILTON SUNDSTRA	
9021-1004	104-384020-1	IND. DUAL DC AMMETER&VOLTMETER	INSCO	
90-42603-1	NO MODEL#	CARGO CTRL JOYSTICK	AVTECHYEE	
9045000-1		IGNITION EXCITER	UNISON	
9045000-1B		IGNITION EXCITER	UNISON	
90G118-2		PRESSURE SWITCH	CUSTOM COMPONEN	
90G183	10-60552-11	PRESSURE SWITCH	CUSTOM COMPONEN	
90G223	10-60552-31	HYD PRESSURE SWITCH	CUSTOM COMPONEN	
90G62-9	NO MODEL#	PRESSURE SWITCH	CUSTOM	
91-380012-1	SR-2AF	TORQUE PRESSURE INDICATOR >>	AMETEK	
91-380012-3	SR-2AG	TORQUE PRESSURE INDICATOR >>	AMETEK	
91-380015-1	SR-154C	TORQUE PRESSURE INDICATOR >>	AMETEK	
914F565-4	AVP99C	AC BUS CONTROL PANEL	HAMILTON SUNSDTRA	
914F565-5	AVP99D	AC BUS CONTROL PANEL	HAMILTON SUNSTRAN	
914F569-4	914F569-4	GENERATOR CONTROL UNIT	SUNDSTRAND	
914F569-5	914F569-5	GENERATOR CONTROL UNIT	SUNDSTRAND AEROS	
914F569-6	914F569-6	GENERATOR CONTROL UNIT	SUNDSTRAN AEROSP	
915F212-4	10-61224-3	GENERATOR CONTROL UNIT >>	HAMILTON SUNDSTRA	
915F212-5	10-61224-3	GENERATOR CONTROL UNIT >>	HAMILTON SUNDSTRA	
915F212-6	10-61224-3	GENERATOR CONTROL UNIT >>	HAMILTON SUNDSTRA	
915F212-7	10-61224-3	GENERATOR CONTROL UNIT >>	HAMILTON SUNDSTRA	
915F212-8	10-61224-3	GENERATOR CONTROL UNIT >>	HAMILTON SUNDSTRA	
915F213-2	10-61224-4	BUS PROTECTION PANEL	SUNDSTRAND AEROS	
915F213-3		BUS PROTECTION PANEL >>	HAMILTON SUNDSTRA	
915F213-4	915F213-4	BUS PROTECTION PANEL >>	HAMILTON SUNDSTRA	
9207-10296	NO MODEL#	RELAY	LEACH	
9210296	NO MODEL#	RELAY	LEACH	
9227-10127	NO MODEL#	RELAY	LEACH	
9274-3642	NO MODEL#	RELAY	LEACH	
93D150	NO MODEL#	VOLTAGE REGULATOR	HAMILTON SUNDSTRA	
93D150-2	NO MODEL#	VOLTAGE REGULATOR	SUNDSTRAND	
948F458-1		GENERATOR CONTROL UNIT >>	HAMILTON SUNDSTRA	
948F458-2		GENERATOR CONTROL UNIT >>	HAMILTON SUNDSTRA	
948F458-3		GENERATOR CONTROL UNIT >>	HAMILTON SUNDSTRA	

06-08-202

Uniserv Aviation, Inc.

Rev#: 20

Capability List

<u>PART NUMBER:</u>	<u>MODEL/TYPE:</u>	<u>DESCRIPTION:</u>	<u>MANUFACTURER:</u>	<u>Rev#</u>
948F458-4		GENERATOR CONTROL UNIT >>	HAMILTON SUNDSTRA	
948F458-5		GENERATOR CONTROL UNIT >>	HAMILTON SUNDSTRA	
961-5059-002		WINDSHIELD TEMPERATURE	ALLIEDSIGNAL	
969-0053-001	NO MODEL#	TEMP SENSOR	HONEYWELL	
97-384010-1	SR-2W	TORQUE PRESSURE INDICATOR >>	AMETEK	
97-384010-3	SR-2Y	TORQUE PRESSURE INDICATOR >>	AMETEK	
97-384010-5	SR-2Z	TORQUE PRESSURE INDICATOR >>	AMETEK	
976J254-4		AC GENERATOR CONTROL PANEL	HAMILTON SUNDSTRA	
976J902-2	NO MODEL#	GENERATOR CONTROL UNIT	WESTINGHOUSE	
976J902-4	NO MODEL#	GENERATOR CONTROL UNIT	WESTINGHOUSE	
9807-47	9807-47	OIL QTY INDICATOR	LITTON	
9807-47-02	9807-47-02	OIL QTY INDICATOR	LITTON	
9821-15-03	9821-15-03	ALT ALERT CONTROLLER	CLIFTON	
99-384029	SR-2AE	TORQUE PRESSURE INDICATOR >>	AMETEK	
99-384030-1	SR-2AB	TORQUE PRESSURE INDICATOR >>	AMETEK	
99-384030-3	SR-2AC	TORQUE PRESSURE INDICATOR >>	AMETEK	
99-384030-5	SR-2AD	TORQUE PRESSURE INDICATOR >>	AMETEK	
99-384030-7	SR-2AP	TORQUE PRESSURE INDICATOR >>	AMETEK	
9A-375	EHU-15A/A	TEMPERATURE INDICATOR	NAVAIR	
9A-400	MS24569-1	TEMPERATURE INDICATOR	NAVAIR	
A1050	NO MODEL#	TURN AND SLIP INDICATOR	R.CALLEN	
A31191-10-701		MACH NUMBER TRANSMITTER >>	KOLLSMAN	
A31191-10-702		MACH NUMBER TRANSMITTER >>	KOLLSMAN	
A32437-10-001		ELECTRICAL TACHOMETER INDICATOR >>	KOLLSMAN	
A32437-10-021		ELECTRICAL TACHOMETER INDICATOR >>	KOLLSMAN	
A35AAU8A/AF				
A35AAU8AAF	A35-AAU-8A/AF	ALTIMETER PRESSURE	AEROSONIC	
A36157102260		AIRSPPEED AND MAXIMUM ALLOWABLE	KOLLSMAN INSTRUME	
A3615910007		AIRSPPEED INDICATOR >>	KOLLSMAN	
A3615910024		AIRSPPEED INDICATOR >>	KOLLSMAN	
A3811910006		PRESSURE ALTIMETER	KOLLSMAN	
A3811910008		PRESSURE ALTIMETER >>	KOLLSMAN	
A3811910016		PRESSURE ALTIMETER >>	KOLLSMAN	
A3868910005		SERVOED ALTIMETER >>	KOLLSMAN	
A3872910004		PRESSURE ALTIMETER >>	KOLLSMAN	
A3946910025		AIRSPPEED AND MACH NUMBER INDICATOR >>	KOLLSMAN	
A3946910028		MACH AIRSPPEED INDICATOR >>	KOLLSMAN	
A3946910029		MACH AIRSPPEED INDICATOR >>	KOLLSMAN	
A40169-10-021		PRESSURE ALTIMETER >>	KOLLSMAN	
A4017910010		PRESSURE ALTIMETER >>	KOLLSMAN	
A4017910016		PRESSURE ALTIMETER >>	KOLLSMAN	
A4017910020		PRESSURE ALTIMETER >>	KOLLSMAN	
A40179-10-025		PRESSURE ALTIMETER >>	KOLLSMAN	
A4017910028		PRESSURE ALTIMETER >>	KOLLSMAN	
A40179-10-034		PRESSURE ALTIMETER >>	KOLLSMAN	
A4086910121		SERVO ALTIMETER	KOLLSMAN	
A40A1750-2	NO MODEL #	VOLTAGE REGULATOR	WESTINGHOUSE	
A4101710021		AIRSPPEED INDICATOR AND TRANSMITTER >>	KOLLSMAN	
A4101910004		AIRSPPEED INDICATOR AND TRANSMITTER >>	KOLLSMAN	
A4143710024		AIRSPPEED INDICATOR AND TRANSMITTER >>	KOLLSMAN	

06-08-202

Uniserv Aviation, Inc.

Rev#: 20

Capability List

<u>PART NUMBER:</u>	<u>MODEL/TYPE:</u>	<u>DESCRIPTION:</u>	<u>MANUFACTURER:</u>	<u>Rev#</u>
A4143910019		AIRSPED INDICATOR AND TRANSMITTER >>	KOLLSMAN	
A4186910015		SERVOED ALTIMETER >>	KOLLSMAN	
A4186910021		SERVOED ALTIMETER >>	KOLLSMAN	
A42899-10-016	A4289910016	SERVOED ALTIMETER	KOLLSMAN	
A4289910115		SERVOED ALTIMETER >>	KOLLSMAN	
A42899--10-216	A42899-10-216	SERVOED ALTIMETER	KOLLSMAN	
A4289910217	A428991027	SERVO ALTIMETER	KOLLSMAN	
A42899-10-217	A42899-10-217	SERVOED ALTIMETER	KOLLSMAN	
A4304910004		SERVOED INDICATOR ALTIMETER >>	KOLLSMAN	
A4619710003		STANDBY ALTIMETER >>	KOLLSMAN	
A4619710004		STANDBY ALTIMETER >>	KOLLSMAN	
A-846-6	695224-1	RELAY FRECUENCY	HARTMAN ELECTRICA	
A9-550	MS24569-1	TEMPERATURE INDICATOR	NAVAIR	
AD--P4-01-0049	EPU-301	BATTERY PACK	AERODESIGN,INC	
AIM 300	300-3	HORIZON REFERENCE	BF GOODRICH	1
AIM 300-3	300-3	HORIZON REFERENCE INDICATOR	BF GOODRICH	1
AIM200	AIM200	GYRO DIRECTIONAL INDICATOR	BF GOODRICH	1
AIM500E	NO MODEL#	HORIZON REFERENCE INDICATOR	GOODRICH	
AYLF-9714-1	NO MODEL#	TEMPERATURE ELEMENT	GE AVIATION	
-AYLF-9732-1	NO MODEL#	TEMPERATURE SENSOR	SMITHS	
AYLF-9732-1	NO MODEL #	TEMPERATURE SENSOR	SMITHS	
B0706 10003				
B0706-10001		OVERSPEED LIMIT SENSOR >>	SMITHS INDUSTRIES	
B0706-10002		OVERSPEED LIMIT SENSOR >>	SMITHS INDUSTRIES	
B0706-10003		MACH AIRPSEED WARNING SWITCH >>	SMITHS INDUSTRIES	
B0706-10004		MACH AIRSPEED WARNING SWITCH >>	SMITHS INDUSTRIES	
B0706-10005		OVERSPEED LIMIT SENSOR >>	SMITHS INDUSTRIES	
B0706-10007		OVERSPEED LIMIT SENSOR >>	SMITHS INDUSTRIES	
B0707 10001	B0707 10001	OVERSPEED LIMIT SENSOR >>	SMITHS INDUSTRIES	
B0707 10003	10-60747-2	OVERSPEED LIMIT SENSOR >>	SMITHS INDUSTRIES	
B0707 10006	B0707 10006	OVERSPEED LIMIT SENSOR >>	SMITHS INDUSTRIES	
B0707 10007	B0707 10007	OVERSPEED LIMIT SENSOR >>	SMITHS INDUSTRIES	
B1077-1	B1077-1	ENGINE OIL QUANTITY INDICATOR **	BF GOODRICH	
B1077-2	B1077-2	ENGINE OIL QUANTITY INDICATOR **	BF GOODRICH	
B1077-3	B1077-3	ENGINE OIL QUANTITY INDICATOR **	BF GOODRICH	
B1077-3W	B1077-3W	ENGINE OIL QUANTITY INDICATOR **	BF GOODRICH	
B1077-4	B1077-4	ENGINE OIL QUANTITY INDICATOR **	BF GOODRICH	
B118-101	B118-101	FUEL QUANTITY INDICATOR **	BE GOODRICH	
B118-124	B118-124	FUEL QUANTITY INDICATOR **	BF GOODRICH	
B118-125	B118-125	FUEL QUANTITY INDICATOR **	BF GOODRICH	
B118-126	B118-126	FUEL QUANTITY INDICATOR **	BF GOODRICH	
B118-143	B118-143	FUEL QUANTITY INDICATOR **	BF GOODRICH	
B118-144	B118-144	FUEL QUANTITY INDICATOR **	BF GOODRICH	
B118-145	B118-145	FUEL QUANTITY INDICATOR **	BF GOODRICH	
B118-161	B118-161	LIQUID QUANTITY INDICATOR **	BF GOODRICH	
B118-244	B118-244	FUEL QUANTITY INDICATOR **	BF GOODRICH	
B118-312	B118-312	FUEL QUANTITY INDICATOR **	BF GOODRICH	
B118-312W	B118-312W	FUEL QUANTITY INDICATOR **	BF GOODRICH	
B118-312XW	B118-312XW	FUEL QUANTITY INDICATOR **	BF GOODRICH	
B118-313	B118-313	FUEL QUANTITY INDICATOR **	BF GOODRICH	
B118-313W	B118-313W	FUEL QUANTITY INDICATOR **	BF GOODRICH	

Capability List

<u>PART NUMBER:</u>	<u>MODEL/TYPE:</u>	<u>DESCRIPTION:</u>	<u>MANUFACTURER:</u>	<u>Rev#</u>
B118-313XW	B118-313XW	FUEL QUANTITY INDICATOR **	BF GOODRICH	
B118-314	B118-314	FUEL QUANTITY INDICATOR **	BF GOODRICH	
B118-314W	B118-314W	FUEL QUANTITY INDICATOR **	BF GOODRICH	
B118-314XW	B118-314XW	FUEL QUANTITY INDICATOR **	BF GOODRICH	
B118-315	B118-315	FUEL QUANTITY INDICATOR **	BF GOODRICH	
B118-315W	B118-315W	FUEL QUANTITY INDICATOR **	BF GOODRICH	
B118-315XW	B118-315XW	FUEL QUANTITY INDICATOR **	BF GOODRICH	
B118-316	B118-316	FUEL QUANTITY INDICATOR **	BF GOODRICH	
B118-316W	B118-316W	FUEL QUANTITY INDICATOR **	BF GOODRICH	
B118-316XW	B118-316XW	FUEL QUANTITY INDICATOR **	BF GOODRICH	
B118-317	B118-317	FUEL QUANTITY INDICATOR **	BF GOODRICH	
B118-324	B118-324	FUEL QUANTITY INDICATOR **	BF GOODRICH	
B118-324W	B118-324W	FUEL QUANTITY INDICATOR **	BF GOODRICH	
B118-324XW	B118-324XW	FUEL QUANTITY INDICATOR **	BF GOODRICH	
B118-336	B118-336	FUEL QUANTITY INDICATOR **	BF GOODRICH	
B118-337	B118-337	FUEL QUANTITY INDICATOR **	BF GOODRICH	
B118-338	B118-338	FUEL QUANTITY INDICATOR **	BF GOODRICH	
B118-339	B118-339	FUEL QUANTITY INDICATOR **	BF GOODRICH	
B118-340	B118-340	FUEL QUANTITY INDICATOR **	BF GOODRICH	
B118-341	B118-341	FUEL QUANTITY INDICATOR **	BF GOODRICH	
B118-342	B118-342	FUEL QUANTITY INDICATOR **	BF GOODRICH	
B118-356	B118-356	FUEL QUANTITY INDICATOR **	BF GOODRICH	
B118-357	B118-357	FUEL QUANTITY INDICATOR **	BF GOODRICH	
B118-58	B118-58	FUEL QUANTITY INDICATOR ***	BF GOODRICH	
B118-59	B118-59	FUEL QUANTITY INDICATOR ***	BF GOODRICH	
B118-60	B118-60	FUEL QUANTITY INDICATOR **	BF GOODRICH	
B118-61	B118-61	FUEL QUANTITY INDICATOR **	BF GOODRICH	
B118-62	B118-62	FUEL QUANTITY INDICATOR **	BF GOODRICH	
B118-63	B118-63	FUEL QUANTITY INDICATOR **	BF GOODRICH	
B118-64	B118-64	FUEL QUANTITY INDICATOR **	BF GOODRICH	
B118-65	B118-65	FUEL QUANTITY INDICATOR **	BF GOODRICH	
B118-66	B118-66	FUEL QUANTITY INDICATOR **	BF GOODRICH	
B118-67	B118-67	FUEL QUANTITY INDICATOR **	BF GOODRICH	
B118-68	B118-68	FUEL QUANTITY INDICATOR **	BF GOODRICH	
B118-69	B118-69	FUEL QUANTITY INDICATOR **	BF GOODRICH	
B118-70	B118-70	FUEL QUANTITY INDICATOR **	BF GOODRICH	
B118-71	B118-71	FUEL QUANTITY INDICATOR **	BF GOODRICH	
B118-72	B118-72	FUEL QUANTITY INDICATOR **	BF GOODRICH	
B118-95	B118-95	FUEL QUANTITY INDICATOR **	BF GOODRICH	
B118-97	B118-97	FUEL QUANTITY INDICATOR **	BF GOODRICH	
B175-16	B175-16	FUEL QUANTITY TOTALIZER INDICATOR **	BF GOODRICH	
B175-17	B175-17	FUEL QUANTITY TOTALIZER INDICATOR **	BF GOODRICH	
B175-21W	B175-21W	FUEL QUANTITY INDICATOR **	BF GOODRICH	
B175-22W	B175-22W	FUEL QUANTITY INDICATOR **	BF GOODRICH	
B175-24W	B175-24W	FUEL QUANTITY INDICATOR **	BF GOODRICH	
B175-25W	B175-25W	FUEL QUANTITY INDICATOR **	BF GOODRICH	
B1800 81108		SERVO INDICATOR	GE AVIATION	
B2771000002		AMPLIFIER ASSEMBLY >>	KOLLSMAN	
B2771000003		AMPLIFIER ASSEMBLY >>	KOLLSMAN	
B3083910006		PRESSURE ALTIMETER >>	KOLLSMAN	
B353-18		FUEL QUANTITY REPEATER INDICATOR	SIMMONDS	

06-08-202

Uniserv Aviation, Inc.

Rev#: 20

Capability List

<u>PART NUMBER:</u>	<u>MODEL/TYPE:</u>	<u>DESCRIPTION:</u>	<u>MANUFACTURER:</u>	<u>Rev#</u>
B3623710056		CORRECTED PRESSURE ALTIMETER >>	KOLLSMAN	
B3727710001		MASTER TRUE AIRSPEED INDICATOR >>	KOLLSMAN	
B3727710021		MASTER TRUE AIRSPEED INDICATOR >>	KOLLSMAN	
B3727710022		MASTER TRUE AIRSPEED INDICATOR >>	KOLLSMAN	
B3733610006		PRESSURE ALTIMETER >>	KOLLSMAN	
B3904110206		PRESSURE ALTIMETER >>	KOLLSMAN	
B3904110226		PRESSURE ALTIMETER >>	KOLLSMAN	
B3904910226		PRESSURE ALTIMETER >>	KOLLSMAN	
B4018710026		CABIN RATE CLIMB INDICATOR	KOLLSMAN	
B4018710032		CABIN RATE CLIMB	KOLLSMAN	
B4033110246		PRESSURE ALTIMETER >>	KOLLSMAN	
B4361710001	NO MODEL#	ALTIMETER	KOLLSMAN	
B44519-10-006		PRESSURE ALTIMETER >>	KOLLSMAN	
B45152-10-002		ENCODER ALTIMETER >>	KOLLSMAN	
B4515210003		ENCODER ALTIMETER	KOLLSMAN	
B4515210004	NO MODEL#	ENCODER ALTIMETER	KOLLSMAN	
B45152-10004				
B45152-10-004		ENCODER ALTIMETER >>	KOLLSMAN	
B45152-10-005		ENCODER ALTIMETER >>	KOLLSMAN	
B45152-10-009		ENCODER ALTIMETER >>	KOLLSMAN	
B45152-10-013		ENCODER ALTIMETER >>	KOLLSMAN	
B45152-10-113		PRESSURE ALTIMETER >>	KOLLSMAN	
B711-1	B711-1	HYDRAULIC OIL QUANTITY INDICATOR ***	BF GOODRICH	
B711-3	B711-3	HYDRAULIC OIL QUANTITY INDICATOR ***	BF GOODRICH	
B711-6	B711-6	HYDRAULIC OIL QUANTITY INDICATOR ***	BF GOODRICH	
BA170-11	NO MODEL#	BALLAST	ELECTRONIKA	
BA170-11-3	NO MODEL#	BALLAST TRANSFORMER	ELECTRONIKA	
BO707 10013		OVERSPEED LIMIT SENSOR	ASTEK	
BPS7-2				
BPS7-3	2012-1	BATTERY POWER SUPPLY	RADIANT POWER SUP	
C16195BA	NO MODEL#	PITOT TUBE	THALES	
C4154510003	NO MODEL#	ALTIMETER-ENCODER	NAVAIR	
D22061-04-004		PRESSURE SENSITIVE ALTIMETER >>	KOLLSMAN	
D22061-04-010		PRESSURE SENSITIVE ALTIMETER >>	KOLLSMAN	
D22061-22-010		PRESSURE SENSITIVE ALTIMETER >>	KOLLSMAN	
D39059 10 226		SET ALTIMETER	KOLLSMAN	
D773-11-001	NO MODEL#	BALLAST-DUAL	PAGE AEROSPACE	
DST-16,	DST-16	TERMOCOUPLE TEMPERATURE INDICATOR	NAVY NAVAIR	
DST-29-1	DST-29-1	THERMOCOUPLE TEMPERATURE INDICATOR		
DST-29-2	DST-29-2	TEMPERATURE INDICATOR		
DST29-2		TEMPERATURE INDICATOR		
DST-29-3	DST-29-3	TEMPERATURE INDICATOR		
DST-49	DST-49	TERMOCUPLE INDICATOR		
E-308A	E-308A	VOLTAGE SENSING RELAY	HARTMAN ELECTRICA	
E42459-10-118		ALTI-CODER ALTIMETER >>	KOLLSMAN	
E42459-10-121		ALTI-CODER ALTIMETER >>	KOLLSMAN	
E42459-10-123		ALTI-CODER ALTIMETER >>	KOLLSMAN	
E42459-10-218		ALTI-CODER ALTIMETER >>	KOLLSMAN	
EA100ANH-134H		INDICATOR OIL QUANTITY	GOODRICH	
EA100ANH-153H	EA100ANH-153H	HYD OIL QTY IND	B.F. GOODRICH	
EA100ANH-153H-1	EA100ANH-153H-1	HYD OIL QTY IND	B.F. GOODRICH	

06-08-202

Uniserv Aviation, Inc.

Rev#: 20

Capability List

<u>PART NUMBER:</u>	<u>MODEL/TYPE:</u>	<u>DESCRIPTION:</u>	<u>MANUFACTURER:</u>	<u>Rev#</u>
EA102ANH-149H	EA102ANH-149H	HYD OIL QTY IND	B.F. GOODRICH	
EA1093A-3679		LIQUID QUANTITY TRANSMITER	BF GOODRICH	
EA173E-2		TRANSMITTER POSITION	LIQUIDOMETER	
ED747201-1	1092-1000	ENGINE PRESSURE RATIO TRANSMITER	UNITED TECHNOLOGI	
ED747201-2	1092-1000	ENGINE PRESSURE RATIO TRANSMITTER	UNITED TECHNOLOGII	
EMBS139-2	NO MODEL#	BATTERY POWER SUPPLY	ENGINEERED MAGNE	
F281-1	F281-1	FLAP POSITION INDICATOR	UNITED CONTROL CO	
FG120P33	FG120P33	TANK UNIT FUEL QUANTITY	HONEYWELL	
FG243A1	FG243A1	OIL TANK UNIT	HONEYWELL	
FG243A2	FG2432	OIL TANK UNIT	HONEYWELL	
FG243A3	FG243A3	OIL TANK UNIT	HONEYWELL	
FG243A4	FG243A4	OIL TANK UNIT	HONEYWELL	
G3122 B	NO MODEL#	INTERPHONE AMPLIER	GABLE	
G-3122 B	NO MODEL #	INTERPHONE AMPLIFIER	GABLES ENGINEERIN	
G5515	NO MODEL #	COCKPIT SPEAKER	GABLES ENGINEERIN	
G6076	G6076	VHF COMM CONTROL PANEL	GABLES ENGINEERIN	
G-610-11	NO MODEL#	INTERFONE	GABLE	
GE16720-010-2	NO MODEL #	LIGHT ASSY AFT	GOODRICH	
GE1672-010-2	NO MODEL #	LIGHT ASSY AFT	GOODRICH	
H321AAM1	H321AAM1	GYROSCOPIC HORIZON	SFENA	
H321ABM1	H321ABM1	GYROSCOPIC HORIZON	SFENA	
H321ACM1	H321ACM1	GYROSCOPIC HORIZON	SFENA	
H321AFM1	H321AFM1	GYROSCOPIC HORIZON	SFENA	
H321AGM	H321AGM	GYROSCOPIC HORIZON	SFENA	
H321AKM1	H321AKM1	GYROSCOPIC HORIZON	SFENA	
H321ALM1	H321ALM1	GYROSCOPIC HORIZON	SFENA	
H321AMM1	H321AMM1	GYROSCOPIC HORIZON	SFENA	
H321ANM1	H321ANM1	GYROSCOPIC HORIZON	SFENA	
H321AQM1	H321AQM1	GYROSCOPIC HORIZON	SFENA	
H321ASM1	H321ASM1	GYROSCOPIC HORIZON	SFENA	
H321AYM1	H321AYM1	GYROSCOPIC HORIZON	SFENA	
H321AZM1	H321AZM1	GYROSCOPIC HORIZON	SFENA	
H321BAM1	H321BAM1	GYROSCOPIC HORIZON	SFENA	
H321BDM1	H321BDM1	GYROSCOPIC HORIZON	SFENA	
H321BEM2	H321BEM2	GYROSCOPIC HORIZON	SFENA	
H321BFM2	H321BFM2	GYROSCOPIC HORIZON	SFENA	
H321BGM1	H321BGM1	GYROSCOPIC HORIZON	SFENA	
H321BHM1	H321BHM1	GYROSCOPIC HORIZON	SFENA	
H321BNM	H321BNM	GYROSCOPIC HORIZON	SFENA	
H321BTM	H321BTM	GYROSCOPIC HORIZON	SFENA	
H321BVM	H321BVM	GYROSCOPIC HORIZON	SFENA	
H321CCM	H321CCM	GYROSCOPIC HORIZON	SFENA	
H341ANM	NO MODEL#	GYROSCOPIC HORIZON	SEXTANT	
H341ANM1	H341ANM1	GYROSCOPIC HORIZON	THALES	
H505B	S250N104-5	TRANSMITER CONTROL	NOVATRONICS	
H532B	S251A304-1	RVDT SENSOR	NOVATRONICS INC	
H60-000		TACHOMETER GENERATOR	JACK & HEINTZ	
H903K204	NO MODEL #	AUTOTEMP INDICATOR	HONEYWELL	
H903K-204	NO MODEL#	AUTO TEMP INDICACOR	HONEYWELL	
IU262-001-30	4000B&4000HR	DIRECTIONAL GYRO	SIGMA-TEX	
IU262-002-51	4000B&4000HR	DIRECTIONAL GYRO	SIGMA-TEX	

06-08-202

Uniserv Aviation, Inc.

Rev#: 20

Capability List

<u>PART NUMBER:</u>	<u>MODEL/TYPE:</u>	<u>DESCRIPTION:</u>	<u>MANUFACTURER:</u>	<u>Rev#</u>
IU262-007-33	4000& 4000HR	DIRECTIONAL GYRO	SIGMA-TEX	
J8000-7	RCA11A-10	DIRECTIONAL GYRO	A.I.D./R.C.ALLEN	1
JG130A35	JG130A35	FUEL QUANTITY INDICATOR	HONEYWELL	
JG130A62	JG130A62	FUEL QUANTITY INDICATOR	HONEYWELL	
JG130A68	JG130A68	FUEL QUANTITY INDICATOR	HONEYWELL	
JG130A95	JG130A95	FUEL QUANTITY INDICATOR	HONEYWELL	
JG130C1	JG130C1	OIL QUANTITY INDICATOR	HONEYWELL	
JG130C2	JG130C2	OIL QUANTITY INDICATOR	HONEYWELL	
JG130C5	10-3230-2	OIL QUANTITY INDICATOR	HONEYWELL	
JG130C9	JG130C9	OIL QUANTITY INDICATOR	HONEYWELL	
JG131A20	JG131A20	FUEL QUANTITY INDICATOR	HONEYWELL	
JG131A35	JG131A35	FUEL QUANTITY INDICATOR	HONEYWELL	
JG131A36	JG131A36	FUEL QUANTITY INDICATOR	HONEYWELL	
JG131A37	JG131A37	FUEL QUANTITY INDICATOR	HONEYWELL	
JG131A38	JG131A38	FUEL QUANTITY INDICATOR	HONEYWELL	
JG131A40	JG131A40	FUEL QUANTITY INDICATOR	HONEYWELL	
JG131A41	JG131A41	FUEL QUANTITY INDICATOR	HONEYWELL	
JG131A42	JG131A42	FUEL QUANTITY INDICATOR	HONEYWELL	
JG131A43	JG131A43	FUEL QUANTITY INDICATOR	HONEYWELL	
JG131A45	JG131A45	FUEL QUANTITY INDICATOR	HONEYWELL	
JG131A51	JG131A51	FUEL QUANTITY INDICATOR	HONEYWELL	
JG131A53	JG131A53	FUEL QUANTITY INDICATOR	HONEYWELL	
JG131A54	JG131A54	FUEL QUANTITY INDICATOR	HONEYWELL	
JG131A55	JG131A55	FUEL QUANTITY INDICATOR	HONEYWELL	
JG131A56	JG131A56	FUEL QUANTITY INDICATOR	HONEYWELL	
JG131A57	JG131A57	FUEL QUANTITY INDICATOR	HONEYWELL	
JG131A58	JG131A58	FUEL QUANTITY INDICATOR	HONEYWELL	
JG131A59	JG131A59	FUEL QUANTITY INDICATOR	HONEYWELL	
JG131A60	JG131A60	FUEL QUANTITY INDICATOR	HONEYWELL	
JG131A61	JG131A61	FUEL QUANTITY INDICATOR	HONEYWELL	
JG131A66	JG131A66	FUEL QUANTITY INDICATOR	HONEYWELL	
JG131A67	JG131A67	FUEL QUANTITY INDICATOR	HONEYWELL	
JG131A68	JG131A68	FUEL QUANTITY INDICATOR	HONEYWELL	
JG131A69	JG131A69	FUEL QUANTITY INDICATOR	HONEYWELL	
JG131A70	JG131A70	FUEL QUANTITY INDICATOR	HONEYWELL	
JG131A71	JG131A71	FUEL QUANTITY INDICATOR	HONEYWELL	
JG131A72	JG131A72	FUEL QUANTITY INDICATOR	HONEYWELL	
JG131A73	JG131A73	FUEL QUANTITY INDICATOR	HONEYWELL	
JG131A74	JG131A74	FUEL QUANTITY INDICATOR	HONEYWELL	
JG131A75	JG131A75	FUEL QUANTITY INDICATOR	HONEYWELL	
JG131A76	JG131A76	FUEL QUANTITY INDICATOR	HONEYWELL	
JG131A77	JG131A77	FUEL QUANTITY INDICATOR	HONEYWELL	
JG131A79	JG131A79	FUEL QUANTITY INDICATOR	HONEYWELL	
JG131A80	JG131A80	FUEL QUANTITY INDICATOR	HONEYWELL	
JG131A83	JG131A83	FUEL QUANTITY INDICATOR	HONEYWELL	
JG140A11	JG140A11	FUEL QUANTITY INDICATOR	HONEYWELL	
JG140A12	JG140A12	FUEL QUANTITY INDICATOR	HONEYWELL	
JG140A13	JG140A13	FUEL QUANTITY INDICATOR	HONEYWELL	
JG140A17	JG140A17	FUEL QUANTITY INDICATOR	HONEYWELL	
JG140A20	JG140A20	FUEL QUANTITY INDICATOR	HONEYWELL	
JG140A25	JG140A25	FUEL QUANTITY INDICATOR	HONEYWELL	

06-08-202

Uniserv Aviation, Inc.

Rev#: 20

Capability List

<u>PART NUMBER:</u>	<u>MODEL/TYPE:</u>	<u>DESCRIPTION:</u>	<u>MANUFACTURER:</u>	<u>Rev#</u>
JG140A26	JG140A26	FUEL QUANTITY INDICATOR	HONEYWELL	
JG140A27	JG140A27	FUEL QUANTITY INDICATOR	HONEYWELL	
JG140A28	JG140A28	FUEL QUANTITY INDICATOR	HONEYWELL	
JG140A29	JG140A29	FUEL QUANTITY INDICATOR	HONEYWELL	
JG140A30	JG140A30	FUEL QUANTITY INDICATOR	HONEYWELL	
JG141A11	JG141A11	FUEL QUANTITY INDICATOR	HONEYWELL	
JG141A12	JG141A12	FUEL QUANTITY INDICATOR	HONEYWELL	
JG141A16	JG141A16	FUEL QUANTITY INDICATOR	HONEYWELL	
JG141A17	JG141A17	FUEL QUANTITY INDICATOR	HONEYWELL	
JG141A18	JG141A18	FUEL QUANTITY INDICATOR	HONEYWELL	
JG141A19	JG141A19	FUEL QUANTITY INDICATOR	HONEYWELL	
JG141A22	JG141A22	FUEL QUANTITY INDICATOR	HONEYWELL	
JG141A23	JG141A23	FUEL QUANTITY INDICATOR	HONEYWELL	
JG141A3	JG141A3	FUEL QUANTITY INDICATOR	HONEYWELL	
JG141A8	JG141A8	FUEL QUANTITY INDICATOR	HONEYWELL	
JG141A9	JG141A9	FUEL QUANTITY INDICATOR	HONEYWELL	
JG298A1	JG298A1	PRESS RATIO INDICATOR	HONEYWELL	
JG298A11	JG298A11	PRESS RATIO INDICATOR	HONEYWELL	
JG298A2	JG298A2	PRESS RATIO INDICATOR	HONEYWELL	
JG298A3	JG298A3	PRESS RATIO INDICATOR	HONEYWELL	
JG298A4	JG298A4	PRESS RATIO INDICATOR	HONEYWELL	
JG298A5	JG298A5	PRESS RATIO INDICATOR	HONEYWELL	
JG298A6	JG298A6	PRESS RATIO INDICATOR	HONEYWELL	
JG298A7	JG298A7	PRESS RATIO INDICATOR	HONEYWELL	
JG298A8	JG298A8	PRESS RATIO INDICATOR	HONEYWELL	
JG298B1	JG298B1	PRESS RATIO INDICATOR	HONEYWELL	
JG298H1	JG298H1	PRESSURE RATIO INDICATOR	HONEYWELL	
JG298H2	JG298H2	PRESSURE RATIO INDICATOR	HONEYWELL	
JG402A2	JG402A2	FUEL QUANTITY INDICATOR	HONEYWELL	
JG402A3	JG402A3	FUEL QUANTITY INDICATOR	HONEYWELL	
JG402A32	JG402A32	FUEL QUANTITY INDICATOR	HONEYWELL	
JG402A4	JG402A4	FUEL QUANTITY INDICATOR	HONEYWELL	
JG402A52	JG402A52	FUEL QUANTITY INDICATOR	HONEYWELL	
JG402A53	JG402A53	FUEL QUANTITY INDICATOR	HONEYWELL	
JG402A54	JG402A54	FUEL QUANTITY INDICATOR	HONEYWELL	
JG402A55	JG402A55	FUEL QUANTITY INDICATOR	HONEYWELL	
JG412A1	JG412A1	FUEL QUANTITY INDICATOR	HONEYWELL	
JG412A10	NO MODEL #	FUEL QUANTITY INDICATOR	HONEYWELL	
JG412A11	JG412A11	FUEL QUANTITY INDICATOR	HONEYWELL	
JG412A2	NO MODEL#	FUEL QUANTITY INDICATOR	HONEYWELL	
JG412A3	NO MODEL#	FUEL QUANTITY INDICATOR	HONEYWELL	
JG412A4	NO MODEL#	FUEL QUANTITY INDICATOR	HONEYWELL	
JG412A52	NO MODEL#	FUEL QUANTITY INDICATOR	HONEYWELL	
JG412A53	NO MODEL#	FUEL QUANTITY INDICATOR	HONEYWELL	
JG412A54	NO MODEL #	FUEL QUANTITY INDICATOR	HONEYWELL	
JG412A55	NO MODEL#	FUEL QUANTITY INDICATOR	HONEYWELL	
JG412A56	JG412A56	FUEL QUANTITY INDICATOR	HONEYWELL	
JG413G1	JG413G1	FUEL QUANTITY INDICATOR	HONEYWELL	
JG413G2	JG413G2	FUEL QUANTITY INDICATOR	HONEYWELL	
JG413G7	JG413G7	FUEL QUANTITY INDICATOR	HONEYWELL	
JG413G8	JG413G8	FUEL QUANTITY INDICATOR	HONEYWELL	

06-08-202

Uniserv Aviation, Inc.

Rev#: 20

Capability List

<u>PART NUMBER:</u>	<u>MODEL/TYPE:</u>	<u>DESCRIPTION:</u>	<u>MANUFACTURER:</u>	<u>Rev#</u>
JG433A3	JG433A3	OIL QUANTITY IND	HONEYWELL	
JG433A4	JG433A4	OIL QUANTITY IND	HONEYWELL	
JG613C1	JG613C1	FUEL QUANTITY INDIC ATOR	HONEYWELL	
JG613C45	JG613C45	FUEL QUANTITY INDICATOR	HONEYWELL	
JG613C53	JG613C53	FUEL QUANTITY INDICATOR	HONEYWELL	
JG613C54	JG613C54	FUEL QUANTITY INDICATOR	HONEYWELL	
JG613C68	JG613C68	FUEL QUANTITY INDICATOR	HONEYWELL	
JG613C71	JG613C71	FUEL QUANTITY INDICATOR	HONEYWELL	
JG613C74	JG613C74	FUEL QUANTITY INDICATOR	HONEYWELL	
JG613C75	JG613C75	FUEL QUANTITY INDICATOR	HONEYWELL	
JG613C76	JG613C76	FUEL QUANTITY INDICATOR	HONEYWELL	
JG865C1	JG865C1	ELECTRIC ALTIMETER	HONEYWELL	
JG865C3	JG865C3	ELECTRIC ALTIMETER	HONEYWELL	
JG873A1-2		MASTER TRUE AIRSPEED INDICATOR	HONEYWELL	
JG908A1	JG908A1	RAT/EPR INDICATOR	HONEYWELL	
JG908A10	JG908A10	RAT/EPR INDICATOR	HONEYWELL	
JG908A11	JG908A11	RAT/EPR INDICATOR	HONEYWELL	
JG908A12	JG908A12	RAT/EPR INDICATOR	HONEYWELL	
JG908A13	JG908A13	RAT/EPR INDICATOR	HONEYWELL	
JG908A14	JG908A14	RAT/EPR INDICATOR	HONEYWELL	
JG908A15	JG908A15	RAT/EPR INDICATOR	HONEYWELL	
JG908A16	JG908A16	RAT/EPR INDICATOR	HONEYWELL	
JG908A17	JG908A17	RAT/EPR INDICATOR	HONEYWELL	
JG908A18	JG908A18	RAT/EPR INDICATOR	HONEYWELL	
JG908A21	JG908A21	RAT/EPR INDICATOR	HONEYWELL	
JG908A25	JG908A25	RAT/EPR INDICATOR	HONEYWELL	
JG908A27	JG908A27	RAT/EPR INDICATOR	HONEYWELL	
JG908A29	JG908A29	RAT/EPR INDICATOR	HONEYWELL	
JG908A3	JG908A3	RAT/EPR INDICATOR	HONEYWELL	
JG908A30	JG908A30	RAT/EPR INDICATOR	HONEYWELL	
JG908A33	JG908A33	RAT/EPR INDICATOR	HONEYWELL	
JG908A4	JG908A4	RAT/EPR INDICATOR	HONEYWELL	
JG908A41	JG908A41	RAT/EPR INDICATOR	HONEYWELL	
JG908A5	JG908A5	RAT/EPR INDICATOR	HONEYWELL	
JG908A57	JG908A57	RAT/EPR INDICATOR	HONEYWELL	
JG908A58	JG908A58	RAT/EPR INDICATOR	HONEYWELL	
JG908A6	JG908A6	RAT/EPR INDICATOR	HONEYWELL	
JG908A7	JG908A7	RAT/EPR INDICATOR	HONEYWELL	
JG908A8	JG908A8	RAT/EPR INDICATOR	HONEYWELL	
JG908A9	JG908A9	RAT/EPR INDICATOR	HONEYWELL	
LG14C11		PRESSURE RATIO TRANSDUCER	HONEYWELL	
LG14C12		PRESSURE RATIO TRANSDUCER	HONEYWELL	
LG14C13		PRESSURE RATIO TRANSDUCER	HONEYWELL	
LG14C14		PRESSURE RATIO TRANSDUCER	HONEYWELL	
LG14C7		PRESSURE RATIO TRANSDUCER	HONEYWELL	
LG14C8		PRESSURE RATIO TRANSDUCER	HONEYWELL	
LG80A11	LG80	PRESSURE RATIO TRANSMITER	HONEYWELL	
LG80A12	LG80	PRESSURE RATIO TRANSMITER	HONEYWELL	
LG80A18	LG80	PRESSURE RATIO TRANSMITER	HONEYWELL	
LG80A2	LG80	PRESSURE RATIO TRANSMITER	HONEYWELL	
LG80A6	10-60737-10	PRESSURE RATIO TRANSMITER	HONEYWELL	

06-08-202

Uniserv Aviation, Inc.

Rev#: 20

Capability List

<u>PART NUMBER:</u>	<u>MODEL/TYPE:</u>	<u>DESCRIPTION:</u>	<u>MANUFACTURER:</u>	<u>Rev#</u>
LG80A7	LG80	PRESSURE RATIO TRANSMITER	HONEYWELL	
LG80A9	LG80	PRESSURE RATIO TRANSMITER	HONEYWELL	
M.L1.74.95		CABIN AIR PRESSURE CONTROL	AIRSEARCH	
M.L1.74.97		CABIN AIR PRESSURE CONTRL	AIR/SEARCH	
P4-01-0049	EPU-301	BATTERY PACK	DME	
P4-01-2049	EPU-301	BATTERY PACK	DME CORPORATION	
PC-15BC		STATIC INVERTER	FLITE-TRONICS	
PDC1-1B-16		AIRSPED SWITCH	AVOX SYSTEM	
PDC1-1B-161	PDC1-1B	AIRSPED SWITCH	SCOTT	
PTX300-8009	NO MODEL#	HYD.PRESS TRANSDUCER	GE	
PTX300-8009-1				
PTX300-8009-2	NO MODEL#	HYD PRESS TRANSDUCER	GE	
PTX300-8009-3		HYD. PRESS TRANSDUCER	GE	
PW0401KID-1	PW0401KID-1	FUEL QUANTITY INDICATOR >>	SMITHS INDUSTRIES	
PW0405KID-1	PW0405KID-1	FUEL QUANTITY INDICATOR >>	SMITHS INDUSTRIES	
PW0406KID-1	PW0406KID-1	FUEL QUANTITY INDICATOR >>	SMITHS INDUSTRIES	
RC-20-ILB	RC-20ILB	RATE OF CLIMB INDICATOR	AEROSONIC CORPOR	
RC30V10-1	NO MODEL#	VERTICAL SPEAD INDICATOR	AEROSONIC	
RCA22-1	RCA22	GYROSCOPE	A.D./R.C. ALLEN	
RCA26BK-9	102-0060-02	GYROSCOPE INDICATOR	A.I.D./R.C. ALLEN	
RG14D3		TOTALIZER		
RG14D7		TOTALIZER	HONEYWELL	
RPS1-B	100865	BATTERY POWER SUPPLY	RADIANT POWER CO	
S1356A36		CELLING EMERGENCY LIGHT	SODERBERG MFG.CO	
S1356B37		CELLING, EMERGENCY LIGTH	SODERBERG MFG.CO	
SEL-OC19AG		TEMPERATURE INDICATOR >>	AMETEK	
SEL-OC19D		TEMPERATURE INDICATOR >>	AMETEK	
SEL-OC19E		TEMPERATURE INDICATOR >>	AMETEK	
SEL-OC19F		TEMPERATURE INDICATOR >>	AMETEK	
SEL-OC19G		TEMPERATURE INDICATOR >>	AMETEK	
SEL-OC420P	NO MODEL#	CABIN PRESSURE IND.	AMETEK	
SETL-OC420L	S231N210-15	CABIN PRESSURE INDICATOR	AMETEK	
SETL-OC420M	S2131N210-14	CABIN PRESSURE INDICATOR	AMETEK	
SETL-OC420P	NO MODEL#	CABIN PRESSURE IND	AMETEK	
SLZ9145		VERTICAL SPEED	TELEDYNE AVIONIC	
SP2979G		LIGHTING CONTROLER	AERONAUTIQUE SYST	
SP-7581-1CES	C-661001-0501	GYRO HORIZON	STANDARD PRECISIO	
SP-7581-1CES-				
SP7581-1CES-	C661001-0501	GYRO HORIZON	CESSNA	
SR-153C		TORQUE PRESSURE INDICATOR >>	AMETEK	
SR-154C	91-380015-1	TORQUE PRESSURE INDICATOR >>	AMETEK	
SR-2AB	99-384030-1	TORQUE PRESSURE INDICATOR >>	AMETEK	
SR-2AC	99-384030-3	TORQUE PRESSURE INDICATOR >>	AMETEK	
SR-2AD	99-384030-5	TORQUE PRESSURE INDICATOR >>	AMETEK	
SR-2AE	99-384029	TORQUE PRESSURE INDICATOR >>	AMETEK	
SR-2AF	91-380012-1	TORQUE PRESSURE INDICATOR >>	AMETEK	
SR-2AG	91-380012-3	TORQUE PRESSURE INDICATOR >>	AMETEK	
SR-2AH	100-384048-1	TORQUE PRESSURE INDICATOR >>	AMETEK	
SR-2AJ	100-384048-3	TORQUE PRESSURE INDICATOR >>	AMETEK	
SR-2AK	100-384048-5	TORQUE PRESSURE INDICATOR >>	AMETEK	
SR-2AM	101-384008-3	TORQUE PRESSURE INDICATOR >>	AMETEK	

06-08-202

Uniserv Aviation, Inc.

Rev#: 20

Capability List

<u>PART NUMBER:</u>	<u>MODEL/TYPE:</u>	<u>DESCRIPTION:</u>	<u>MANUFACTURER:</u>	<u>Rev#</u>
SR-2AP	99-384030-7	TORQUE PRESSURE INDICATOR >>	AMETEK	
SR-2AR	100-384116-5	TORQUE PRESSURE INDICATOR >>	AMETEK	
SR-2AT	100-384048-15	TORQUE PRESSURE INDICATOR >>	AMETEK	
SR-2W	97-384010-1	TORQUE PRESSURE INDICATOR >>	AMETEK	
SR-2Y	97-384010-3	TORQUE PRESSURE INDICATOR >>	AMETEK	
SR-2Z	97-384010-5	TORQUE PRESSURE INDICATOR >>	AMETEK	
SR-6A	NO MODEL#	PRESSURE INDICATOR	US.GAGE	
SR-C-2AS	104-384012-5	TORQUE PRESSURE INDICATOR >>	AMETEK	
SRDL-7G		HYD BRAKE PRESSURE IND	AMETEK	
SRDL-7H		HYDRAULIC PRESSURE DUAL INDICATOR >>	AMETEK	
SRL-027A		OXYGEN PRESSURE INDICATOR >>	AMETEK	
SRL-09C		DUCT PRESSURE INDICATOR >>	AMETEK	
SRL-7D		HYD PRESSURE INDICATOR	AMETEK	
SRL-92D		PRESSURE INDICATOR	AMETEK	
SRL-92E	NO MODEL#	SUPPLY AIR PRESSURE INDICATOR	AMETEK	
SRL-92F	SRL-92F	PNEUMATIC PRESSURE INDICATOR >>	AMETEK	
SRL-92G		VALVE POSITION INDICATOR >>	AMETEK	
SRL-92H	SRL-92H	PNEUMATIC PRESSURE INDICATOR >>	AMETEK	
SRL92P	NO MODEL#	PNEUMATIC PRESSURE INDICATOR	AMETEK	
SRL-92P	SRL-92P	PNEUMATIC PRESSURE INDICATOR >>	AMETEK	
SRL-O4L	SRL-O4L	OIL PRESSURE INDICATOR **	AMETEK	
ST-0109C	NO MODEL#	PRESSURE TRANSMITTER	AMETEK	
ST-104A	ST-104A	OIL PRESSURE TRANS	AMETEK	
ST-104Y	ST-104Y	OIL PRESSURE TRASMITTER **	AMETEK	
ST-104Z		OIL PRESSURE TRANSMITER **	AMETEK	
ST-106AB	ST-106AB	PRESSURE TRANSMITTER **	AMETEK	
ST107Q		TRANSMITTER HYDRAULIC	AMETEK	
ST-107Q	NO MODEL#	HYDRAULIC PRESSURE TRANSMITER	AMETEK	
ST-107R	ST-107R	HYDRAULIC PRESSURE TRANSMITTER **	AMETEK	
ST-12U-1		POSITION TRANSMITER		
ST-4N	NO MODEL #	OIL PRESSURE TRANSMITTER **	AMETEK	
ST-4N-M1		OIL PRESSURE TRANSMITER	AMETEK	
ST509A		PRESSURE TRANSMITER	AMETEK	
ST509A-M1	NO MODEL#	PRESSURE TRANSMITER	AMETEK	
ST7R	ST7R	HYDRAULIC PRESSURE TRANSMITTER **	AMETEK	
ST-7T	ST-7T	HYDRAULIC PRESSURE TRANSMITTER >>	AMETEK	
STO-0109C	NO MODEL#	PRESSURE TRANSMITTER	AMETEK	
SYLZ50683-1	697639-35	LOW LIMIT TERMERATUTE CONTROL	BARBER COLEMAN	
SYLZ50684	697639-37	TEMPERATURE CONTROLER	BARBE COLEMAN	
SYLZ50685	697639-39	TEMPERATURE CONTROLER	BARBE COLEMAN	
TC100(12	TC100(12)	ELECTRIC TURN CORDINATOR	BRITTAIN INDUSTRIES	2
TC100(24)	TC(100)24	ELECTRIC TURN COORDINATOR	BRITTAIN INDUSTRIES	1
TD1514-1002	60B50058-3	TOILET TIMER SWITCH	LEACH INTERNATION	
TD1535-1002	60B50058-4	TOILET TIMER SWITCH	LEACH INTERNATION	
TD1702-1002	60B50058-6	TOILET TIMER SWITCH	LEACH INTERNACION	
TD1715-1002	60B50058-5	TOILET TIMER SWITCH	LEACH INTERNATION	
TD1836-5001	NO MODEL#	RELAY	LEACH	
TGS420-102	MODEL#	STATIC INVERTER	THALES	
TSG420-102	NO MODEL#	STATIC INVERTER	SFENA	
VIL-O4A	NO MODEL#	INDICATOR OIL PRESS	AMETEK	
VIL-OC4A	NO MODEL#	OIL PRESS INDICATOR	AMETEK	

06-08-202

Uniserv Aviation, Inc.

Rev#: 20

Capability List

<u>PART NUMBER:</u>	<u>MODEL/TYPE:</u>	<u>DESCRIPTION:</u>	<u>MANUFACTURER:</u>	<u>Rev#</u>
VSDL-OC410A	VSDL-OC410A	DIGITAL FAN SPEED INDICATOR >>	AMETEK	
VSDL-OC410A-1	VSDL-OC410A-1	DIGITAL FAN SPEED INDICATOR >>	AMETEK	
VSDL-OC410H	VSDL-OC410H	DIGITAL FAN SPEED INDICATOR >>	AMETEK	
VT-0306D	NO MODEL#	PRESSURE TRANSMITER	AMETEK	
WL/105AMA/JA/1		MACH AIRSPEED INDICATOR >>	SMITH INDUSTRIES	
WL/105AMA/JA/10		MACH AIRSPEED INDICATOR >>	SMITHS INDUSTRIES	
WL/105AMA/JA/15		MACH AIRSPEED INDICATOR >>	SMITHS INDUSTRIES	
WL/105AMA/JA/18		MACH AIRSPEED INDICATOR >>	SMITHS INDUSTRIES	
WL/105AMA/JA/19		MACH AIRSPEED INDICATOR >>	SMITHS INDUSTRIES	
WL/105AMA/JA/21		MACH AIRSPEED INDICATOR >>	SMITHS INDUSTRIES	
WL/105AMA/JA/22		MACH AIRSPEED INDICATOR >>	SMITHS INDUSTRIES	
WL/105AMA/JA/23		MACH AIRSPEED INDICATOR >>	SMITHS INDUSTRIES	
WL/105AMA/JA/24		MACH AIRSPEED INDICATOR >>	SMITHS INDUSTRIES	
WL/105AMA/JA/25		MACH AIRSPEED INDICATOR >>	SMITHS INDUSTRIES	
WL/105AMA/JA/26		MACH AIRSPEED INDICATOR >>	SMITHS INDUSTRIES	
WL/105AMA/JA/28		MACH AIRSPEED INDICATOR >>	SMITHS INDUSTRIES	
WL/105AMA/JA/29		MACH AIRSPEED INDICATOR >>	SMITHS INDUSTRIES	
WL/105AMA/JA/3		MACH AIRSPEED INDICATOR >>	SMITHS INDUSTRIES	
WL/105AMA/JA/30		MACH AIRSPEED INDICATOR >>	SMITHS INDUSTRIES	
WL/105AMA/JA/32		MACH AIRSPEED INDICATOR >>	SMITHS INDUSTRIES	
WL/105AMA/JA/33		MACH AIRSPEED INDICATOR >>	SMITHS INDUSTRIES	
WL/105AMA/JA/34		MACH AIRSPEED INDICATOR >>	SMITHS INDUSTRIES	
WL/105AMA/JA/35		MACH AIRSPEED INDICATOR >>	SMITHS INDUSTRIES	
WL/105AMA/JA/36		MACH AIRSPEED INDICATOR >>	SMITHS INDUSTRIES	
WL/105AMA/JA/37		MACH AIRSPEED INDICATOR >>	SMITHS INDUSTRIES	
WL/105AMA/JA/38		MACH AIRSPEED INDICATOR >>	SMITHS INDUSTRIES	
WL/105AMA/JA/4		MACH AIRSPEED INDICATOR >>	SMITHS INDUSTRIES	
WL/105AMA/JA/7		MACH AIRSPEED INDICATOR >>	SMITHS INDUSTRIES	
WL/105AMA/JA/8		MACH AIRSPEED INDICATOR >>	SMITHS INDUSTRIES	
WL/105AMA/JA/9		MACH AIRSPEED INDICATOR >>	SMITHS INDUSTRIES	
WL/105AMA/MS/12		MACH AIRSPEED INDICATOR >>	SMITHS INDUSTRIES	
WL/105AMA/MS/17		MACH AIRSPEED INDICATOR >>	SMITHS INDUSTRIES	
WL/105AMA/MS/41		MACH AIRSPEED INDICATOR >>	SMITHS INDUSTRIES	
WL/105AMA/MS/45		MACH AIRSPEED INDICATOR >>	SMITHS INDUSTRIES	
WL/106AMA1		MACH AIRSPEED INDICATOR >>	SMITHS INDUSTRIES	
WL/106AMA2	WL106	MACH AIRSPEED INDICATOR >>	SMITHS INDUSTRIES	
WL/106AMA3		MACH AIRSPEED INDICATOR >>	SMITHS INDUSTRIES	
WL/106AMA31		MACH AIRSPEED INDICATOR >>	SMITHS INDUSTRIES	
WL/106AMA32		MACH AIRSPEED INDICATOR >>	SMITHS INDUSTRIES	
WL/106AMA44		MACH AIRSPEED INDICATOR >>	SMITHS INDUSTRIES	
WL/106AMA6		MACH AIRSPEED INDICATOR >>	SMITHS INDUSTRIES	
WL/107AMA1		MACH AIRSPEED INDICATOR >>	SMITHS INDUSTRIES	
WL/107AMA2		MACH AIRSPEED INDICATOR >>	SMITHS INDUSTRIES	
WL/107AMA3		MACH AIRSPEED INDICATOR >>	SMITHS INDUSTRIES	
WL/107AMA31		MACH AIRSPEED INDICATOR >>	SMITHS INDUSTRIES	
WL/107AMA4		MACH AIRSPEED INDICATOR >>	SMITHS INDUSTRIES	
WL/1103/AM/MS/10		SERVO ALTIMETER >>	SMITHS INDUSTRIES	
WL/1103/AM/MS10				
WL/1103AM-MS7		SERVO ALTIMETER >>	SMITHS INDUSTRIES	
WL/1103AM-MS9		SERVO ALTIMETER >>	SMITHS INDUSTRIES	
WL/1106AM-MS2		SERVO ALTIMETER >>	SMITHS INDUSTRIES	

06-08-202

Uniserv Aviation, Inc.

Rev#: 20

Capability List

<u>PART NUMBER:</u>	<u>MODEL/TYPE:</u>	<u>DESCRIPTION:</u>	<u>MANUFACTURER:</u>	<u>Rev#</u>
WL/1106AM-MS5		SERVO ALTIMETER >>	SMITHS INDUSTRIES	
WL/1108AM/MS/1		SERVO ALTIMETER	SMITHS	
WL/1108AM-MS1		SERVO ALTIMETER >>	SMITHS INDUSTRIES	
WL/1109AM-MS3		SERVO ALTIMETER >>	SMITHS INDUSTRIES	
WL/1110AM-MS1		SERVO ALTIMETER >>	SMITHS INDUSTRIES	
WL/1110AM-MS2		SERVO ALTIMETER >>	SMITHS INDUSTRIES	
WL/1110AM-MS3		SERVO ALTIMETER >>	SMITHS INDUSTRIES	
WL/1110AM-MS4		SERVO ALTIMETER >>	SMITHS INDUSTRIES	
WL/1112AM-MS1		SERVO ALTIMETER >>	SMITHS INDUSTRIES	
WL/1112AM-MS2		SERVO ALTIMETER >>	SMITHS INDUSTRIES	
WL/1112AM-MS3		SERVO ALTIMETER >>	SMITHS INDUSTRIES	
WL/1112AM-MS4		SERVO ALTIMETER >>	SMITHS INDUSTRIES	
WL/1112AM-MS5		SERVO ALTIMETER >>	SMITHS INDUSTRIES	
WL/1150AM-MS5		SERVO ALTIMETER >>	SMITHS INDUSTRIES	
WL/122AMA/JA/2		MACH AIRSPEED INDICATOR >>	SMITHS INDUSTRIES	
WL/122AMA/JA/3		MACH AIRSPEED INDICATOR >>	SMITHS INDUSTRIES	
WL/122AMA/JA/4		MACH AIRSPEED INDICATOR >>	SMITHS INDUSTRIES	
WL/122AMA/JA/5		MACH AIRSPEED INDICATOR >>	SMITHS INDUSTRIES	
WL/122AMA/JA/8		MACH AIRSPEED INDICATOR >>	SMITHS INDUSTRIES	
WL/122AMA/JA/9		MACH AIRSPEED INDICATOR >>	SMITHS INDUSTRIES	
WL/820AM/MS/1	NO MODEL#	STANDBY ALTIMETER	GE AVIATION	
WL101AMS1	NO MODEL#	ALTIMETER/AIRSPEED INDICATOR	GE	
WL101EED2	10-62028-2	N1%RPM INDICATOR	GENERAL ELECTRIC	
WL101EED3	10-62028-3	N1% RPM INDICATOR	GENERAL ELECTRIC	
WL102AMS1	WL/102AMS1	ALTIMETER/AIRSPEED INDICATOR >>	GE AVIATION	
WL102AMS2	WL/102AMS2	ALTIMETER/AIRSPEED INDICATOR >>	GE AVIATION	
WL102AMS3	WL/102AMS3	ALTIMETER/AIRSPEED INDICATOR >>	GE AVIATION	
WL102AMS4	WL/102AMS4	ALTIMETER/AIRSPEED INDICATOR >>	SMITHS INDUSTRIES	
WL102AMS5	WL/102AMS5	ALTIMETER/AIRSPEED INDICATOR >>	GE AVIATION	
WL102AMS6	WL/102AMS6	ALTIMETER/AIRSPEED INDICATOR >>	GE AVIATION	
WL1110AM-MS3		SERVO ALTIMETERS >>	SMITH INDUSTRIES	
WL1704AM9	NO MODEL #	STANBY ALTIMETER	GE	
WL202EED3	NO MODEL#	INDICATOR EGT	GE	
WL202EED6	NO MODEL#	INDICATOR-ENG EGT	GE	
WL220EED3	NO MODEL #	INDICATOR -ENG EGT	GE	
WL501RC1	NO MODEL#	CABIN RATE OF CLIMB INDICATOR	GE	
WL820AMMS5		MECHANICAL COUNTER POINTER ALTIMATER	SMITHS	